

Installation guide for ZFORCE 1000-800 half-door

- 1- Using a star screwdriver, remove the 3 screws from the door. Insert the 3 new screws 1 1/4 " (30 mm) supplied in the CFMOTO kit.



- 2- Drill 2 19/64 " holes and insert the push rivets in the CFMOTO kit.



- 3- Remove the original push rivets and install the door stop using the same rivet.



- 4- Using a star screwdriver, remove the 2 star screws on the door inside the vehicle. Then install the bottom of the door with the 2 screws (25 mm) provided in the CFMOTO kit.



5- Drill 2 19/64 " holes and install the 2 push rivets provided in the CFMOTO kit.



Final result :

