How to Ornament –



Materials:

Medium weight cut away or tear away stabilizer (2) 5" x 5" "gingerbread" vinyl 1/4" grosgrain ribbon 1/4" 2 piece grommet 505 spray or painter tape

Step 1: Hey, guess what step 1 is? If you guessed "hoop a piece of stabilizer" YOU WIN!



Step 4: Take your hoop out of the machine and flip it over



Step 5: tape your second piece of marine vinyl TO THE BACK of your hoop and run the LAST color stop

*You may want to match your bobbin thread to your top thread for a neater look



Step 2: run color stop 1. This is the die line for your first piece of marine vinyl



Step 6: un-hoop your ornament and carefully cut 1/8" – 1/4" from the final bean stitch



Step 3: float marine vinyl over the die line and run color stop 2 &



Step 7: Using a leather punch and hammer or a cropodile, punch a ¼" hole in the ornament hanger




*There are only 2 detail colors in this pattern -red and white





Step 8: use your eyelet tool to set the 2 piece grommet as directed in the grommet set.







Be sure to check out our YouTube channel: https://www.youtube.com/channel/UCsFTIoQIMQs HpSVCOXWWjjw/videos

Our store: https://stringtheoryfabricart.com/

AND our Facebook Fan Group where you will find more helpful hints, discounts, and coupons: https://www.facebook.com/groups/STFAFanGroup/

