




Pos No	Part #	Description	Pos No	Part #	Description
D01	202002	Bottom Plate w/ Rubber	26-1	202624	O-Ring (Kit Only)
D01-1	201968	Strainer - solid, R400D only	27	204257	Power Cable w/ Gland - 115V, 1 PH
D01-2-3-4-5	202017	Non-Return Valve Assembly	27	201684	Power Cable w/ Gland - 230V, 1 PH, No Plug
03	202890	Impeller Nut	27-1	202624	O-Ring (Kit Only)
05	202054	Impeller: Fiberglass Reinf. Plastic	27-2	202624	O-Ring (Kit Only)
07	202195	Pump Housing/Suction Cover	31E	203145	Ground Wire w/Ring Term.
07-1	202624	O-Ring (Kit Only)	32	203161	Power Cord Line Clip
08	202207	Oil Chamber Cover	34	203169	Handle
08-1	202624	O-Ring (Kit Only)	35	202675	Rod Bolts
09	202229	Lip Seal Buna-N	38	202551	Disch. Nipple NPT Cast Iron 1-1/2"
09	202230	Lip Seal FKM (Optional)	38	202531	Disch. Nipple NPT Cast Iron 2"
09	203050	Lip Seal EPDM (Optional)	38F	202565	Discharge Flange Kit 1-1/2"
10	202258	Shaft Sleeve	38F	202568	Discharge Flange Kit 2"
13	202259	Mechanical Seal Buna-N	50-01-3	202688	Stud with Nuts (R400D)
13	202260	Mechanical Seal FKM**	50-07	203239	Screw for Suction Cover
14	200493	Lower Ball Bearing	50-08	203215	Screw for Oil Chamber Cover
16	202287	Pump Casing Outer	50-11	203218	Screw for Oil Fill
17	202300	Rotor w/ Shaft 115, 1PH	50-11-1	202624	O-Ring (Kit Only)
17	202300	Rotor w/ Shaft 230, 1PH	50-12	203218	Screw - Pressure Test
18	200508	Stator Coil w/ Casing 115, 1PH	50-12-1	202624	O-Ring (Kit Only)
18	200523	Stator Coil w/ Casing 230, 1PH	50-16	203220	Screw for Outer Casing
20	200957	Upper Ball Bearing	50-27	203216	Screw for Power Cord
21A	200499	Oil Chamber	50-31E	202692	Screw for Ground Wire
21A-1	202624	O-Ring (Kit Only)	50-32	203220	Screw for Line Clip
21B	204154	Motor Cover (Upper)	50-34	203220	Screw for Handle
24	202422	Capacitor 115	50-38N	203182	Acorn Nut for Flange
24	202423	Capacitor 230	50-38W	202902	Washer for Flange
26	202425	Pump Top Cover			