






REPLACEMENT PARTS/ORDER FORM

Doc #: SHPOBS1

VC30 iBuyGrillParts.com 888-634-4289

✓	REF	DESCRIPTION	QTY	VC30
☐	1	BOTTOM PANEL ASSY	1	50001310
☐	2	LEG KIT	1	50001503
☐	3	FRONT PANEL - CHARCOAL	1	50001290
☐	4	CASTER (POP IN)	4	50000090
☐	NS	CASTER INSERT	4	50002534
☐	5	BASE ASSY - THROUGH DEALER ONLY	1	50001462
☐	6	REAR LID ASSY - Also send 50000355.	1	50003512
☐	7	FLASH TUBE	1	50001300B
☐	8	GREASE PAN SUPPORT	2	50001302
☐	9	BURNER GASKET	3	50000892
☐	10	BURNER W. LONG ELECTRODE	2	50003133
☐		BURNER W. SHORT ELECTRODE	1	50003100
☐	11A	VALVE ASSY - NG - THROUGH DEALER ONLY	1	50001439
☐	11B	VALVE ASSY - LP - THROUGH DEALER ONLY	1	50001438
☐	12	CONSOLE ASSY VC 30	1	50001432
☐	NS	CONSOLE HEAT SHIELD	1	50001286B
☐	13A	REGULATOR - THROUGH DEALER ONLY	1	50001308
☐	13B	12' NG HOSE - THROUGH DEALER ONLY	1	50000198
☐	14	PIVOT PIN & BOLT SET Send with lid assembly.	1	50000355
☐	15	FRONT LID ASSY CHARCOAL Also send 5-0355.	1	50001281
☐	16	GREASE PAN	1	50001301
☐	17	COOKING GRIDS; SET OF 2, NO SINGLE GRIDS	1	50001314
☐	18	BEZEL	3	50001327
☐	19	CONTROL KNOB	3	50001328
☐	20	HEAT PLATE - S/S	3	50000777
☐	21	WARMING RACK - ENAMEL	1	50001311
☐	22	GREASE CUP	1	50001845
☐	23	GREASE CUP HOLDER	1	50001319
☐	24	ELECTRODE - MAIN SHORT	1	50000431
☐	25	ELECTRODE - MAIN LONG	2	50000523
☐	26	LID BUMPERS	4	50000177
☐	27	SUPPORT SHELF LEFT - BLACK	2	50001418
☐	28	SUPPORT SHELF RIGHT - BLACK	2	50001419
☐	29	FRONT LIP	1	50001482
✓	REF	DESCRIPTION	QTY	VC30



REPLACEMENT PARTS/ORDER FORM

Doc #: SHPOBS1

VC30 iBuyGrillParts.com **888-634-4289**

☐	30	IGNITER KIT	1	50000816
☐	31	SHELF TOP SOLID S/S	2	50001413B
☐	32	HARDWARE BAG	1	50001390
☐	33	SHELF FRONT S/S RIGHT	1	50000984B
☐	34	SHELF FRONT S/S LEFT	1	50000986B
☐	35	SIDE PANEL - BLACK	2	50001506
☐	NS	CABINET PANEL KIT (FRONT + 2 SIDES)	1	50001491
☐	NS	TEMPERATURE GAUGE	1	50001643
☐	NS	LOGO	1	50000007
☐	NS	PUSH ON NUT	2	50000255

iBuyGrillParts.com

iBuyGrillParts.com **888-634-4289**