


DIMAS



IPL, DIMAS CS 2512, 2005-42, 531 12 05-57

DIMAS CS 2512

Reservdelar

Spare parts

Ersatzteile

ConstructionParts.com

Pieces de rechange

Piezas de repuesto

Ricambi

Peças
sobresselente

From machine number: 1001

ConstructionParts.com

888-634-4289

531 12 05-57

DIMAS


No.	Pos.	Description	No.	Pos.	Description
531 11 42-26	N	Hydraulic motor complete	531 11 92-73	E	O-ring 29x2,5
531 11 42-89	AL	Main Frame	531 11 93-21	PQ	Circlip SgH 55
531 11 42-94	M	Drive unit	531 11 93-22	H	Circlip SgH 80
531 11 42-95	M	Clamp	531 11 93-32	V	Washer TBRB 6,4x22
531 11 42-99	D	Cart	531 11 93-34	M	V-ring 60
531 11 43-18	Q	Guide wheel compl. with bearings	531 11 93-40	N	Plug VSTI R1/2"
531 11 43-36	C	Foot beam	531 11 93-42	Y	Plug 1/8"
531 11 43-45	Q	Align device	531 11 94-26	V	Screw K6S 6x16
531 11 43-54	T	Rod	531 11 94-81	FG	Circlip SgA 25
531 11 43-70	E	Handle	531 11 94-95	D	Washer BRB 21x36
531 11 43-73	M	Tommy screw	531 11 94-96	E	Spring pin FRP 10x36
531 11 43-80	V	Frame	531 11 94-97	E	Screw cap MHM M8
531 11 43-83	W	Frame	531 11 95-02	L	Screw M6SF 6x16
531 11 43-88	W	Handle	531 11 95-04	H	O-ring OR 71,12x2,62
531 11 43-89	V	Bar	531 11 95-06	V	Spring
531 11 43-91	E	Handle beam	531 11 95-07	E	Spring
531 11 43-92	B	Foot	531 11 95-08	JK	Spring
531 11 43-93	W	Bracket	531 11 95-10	FG	Screw K6S 6x10
531 11 43-94	EP	Handle	531 11 95-14	H	Bearing NU 208 EC
531 11 43-95	P	Pivot house	531 11 95-15	H	Sealing BA 50x80x8
531 11 43-97	P	Fork	531 11 95-21	FH	Grease nipple M8x1,25
531 11 44-06	A	Anchor beam	531 11 95-23	PQ	Sealing CR 30x50x10
531 11 44-14	J	Angle shaft	531 11 95-24	Q	Screw K6S 10x20
531 11 44-17	K	Angle shaft	531 11 95-28	M	V-ring 85
531 11 44-18	F	Hydraulic cylinder	531 11 95-29	HM	Bearing 6208-2RS1
531 11 44-26	Y	Pressure reducing block complete	531 11 95-42	V	Screw K6S 6x40
531 11 44-28	P	Wheel link compl. with bearings	531 11 95-43	W	Screw K6S 6x35
531 11 44-49	I	Wheel magazine complete	531 11 95-44	W	Screw K6S 6x50
531 11 44-50	R	Wheel link complete	531 11 95-45	P	Sealing CR 65x80x8
531 11 44-51	O	Drive wheel complete	531 11 95-47	E	Eye bolt screw M12
531 11 73-72	S	Rubber grommet	531 11 95-48	E	Handle
531 11 80-03	S	Quick coupling Tema 1800	531 11 95-49	FQ	Circlip SgA 28
531 11 80-18	S	Ball valve 3/8"	531 11 95-50	JK	Washer 15x21x1
531 11 80-34	N	Coupling	531 11 95-51	JK	Washer 16x22x1
531 11 80-41	N	Quick coupling, female	531 11 95-52	JK	Spring lug
531 11 80-42	N	Quick coupling, male	531 11 95-54	X	Clamp
531 11 80-45	XY	Quick coupling 1/8" Female	531 11 95-55	F	Shim 28x40x2
531 11 80-46	Y	Quick coupling 1/8" male	531 11 95-57	DT	Locking pin 3mm
531 11 80-78	Y	Pressure reducing valve	531 11 95-58	F	Hose clamp ABA 58-75
531 11 81-99	Y	Knob	531 11 95-59	T	Angled ball joint DIN 71802
531 11 82-18	S	Quick coupling male 13411	531 11 95-61	C	Rubber buffer
531 11 82-95	N	Banjo	531 12 00-29	IR	Rubber band
531 11 82-96	N	Hydraulic motor	531 12 00-50	O	Rubber band
531 11 82-98	Y	Manometer	531 12 00-51	M	Cap
531 11 82-99	Y	Rubber cover	531 12 00-52	M	Ring
531 11 83-03	Y	Non return valve	531 12 00-56	M	Drive shaft
531 11 83-04	S	Nut 3/8	531 12 00-57	M	Ring
531 11 83-09	X	Banjobolt	531 12 01-24	FG	Shaft
531 11 83-19	S	Connector Loc-Line 41406	531 12 01-35	N	Block 2-speed
531 11 83-20	S	Muff 1/4" x 3/8"	531 12 01-36	N	Return block
531 11 83-21	S	Nipple 3/8"-3/8"	531 12 01-37	N	Adapter
531 11 83-22	S	Angle jet Loc-Line 41473	531 12 01-38	N	Adapter
531 11 83-24	S	Angle knee 1/4"	531 12 01-39	N	Nipple
531 11 83-26	S	Nipple 1/4 - 3/8	531 12 01-57	F	Shaft
531 11 90-07	D	Wheel	531 12 01-89	Q	Shaft
531 11 90-40	H	Washer 40x60x1	531 12 02-85	M	Washer
531 11 90-45	N	Ball	531 12 02-94	P	Shaft
531 11 90-98	N	Spring	531 12 03-07	S	Water valve block
531 11 90-99	N	Ball 6 mm	531 12 03-09	S	Water tube
531 11 91-49	N	Thrust needle bearing	531 12 03-47	L	Index plate
531 11 91-80	PQ	Sealing CR 35x55x9	531 12 03-64	F	Bellows
531 11 91-83	MV	Washer BRB 13x24	531 12 03-83	P	Rod
531 11 91-85	N	Sealing washer GB 1/2"	531 12 04-02	E	Pin, handle
531 11 92-00	F	Screw M6S 10x35	531 12 04-03	BCD	Screw
531 11 92-06	M	Screw M6S 12x40	531 12 04-05	W	Cover sheet
531 11 92-10	V	Screw M6S 6x12	531 12 04-11	V	Cover
531 11 92-11	VW	Screw M6S 6x16	531 12 04-49	V	Stop
531 11 92-62	EN	O-ring 18,3x2,4	531 12 04-50	W	Cover
531 11 92-63	N	O-ring 19,3x2,4	531 12 04-59	BCD	Nut
531 11 92-70	N	O-ring 24,2x3	531 12 04-64	P	Cover

No.	Pos.	Description	No.	Pos.	Description
531 12 04-69	M	Lock plate	735 31 37-00	HM	Circlip SgA 40
531 12 04-72	K	Bracket	735 31 42-00	P	Circlip SgA 50
531 12 04-79	JK	Spring hook	738 21 06-04	PQ	Bearing 6006-2RS1
531 12 04-80	JK	Hook	738 21 10-04	P	Bearing 6010-2RS1
531 12 04-88	F	Pionter	740 38 18-01	XY	Sealing washer GB 1/8"
531 12 04-92	S	Water tube	740 38 27-01	Y	Sealing washer GB 1/4"
531 12 04-93	S	Bracket	740 38 34-01	XY	Sealing washer GB 3/8"
531 12 05-11	JK	Roll	740 43 06-00	P	O-ring 8,3x2,4
531 12 05-24	U	Cover	740 43 07-00	N	O-ring 9,3x2,4
531 12 05-29	A	Cross beam	740 43 12-00	J	O-ring OR 14,3x2,4
531 12 05-32	BCD	Sleeve	740 44 12-00	H	O-ring OR 39,2x3
531 12 05-33	G	Angular scale			
531 12 05-39	V	Sleeve			
531 12 05-40	V	Brass washer			
531 12 05-49	H	Cover			
531 12 05-51	PQ	Cover			
531 12 05-54	X	Cylinderhose			
531 12 05-60	G	Arm			
531 12 05-61	H	Cover			
531 12 05-62	H	Plug			
531 12 05-63	H	Distance			
531 12 05-64	H	Sealing ring			
531 12 05-65	H	Flange			
531 12 05-66	H	Shaft, wheel magazine			
531 12 05-67	H	Spacer ring			
531 12 13-79	M	Triangular knob			
531 12 14-02	N	Valve lever hub			
531 12 20-85	N	Valve plate			
531 12 20-87	N	Valve			
531 12 31-00	XY	Marking washer			
531 12 41-80	S	Nipple 3/8			
531 14 20-25	N	Nipple 1/2			
531 14 21-11	Y	Pressure reducing block			
531 14 21-21	Y	Hose 1/8"-1/4"			
531 14 21-22	Y	Hose 1/8"-3/8"			
720 12 65-50	N	Cylindric pin			
721 42 58-00	N	Spring pin FRP 4x20			
721 44 11-00	M	Spring pin FRP 10x20			
725 24 49-71	U	Screw M6S 8x16			
725 24 59-51	L	Screw M6S 8x40			
725 24 63-71	A	Screw M6S 8x60			
725 24 69-51	F	Screw M6S 8x90			
725 25 09-51	P	Screw M6S 10x90			
725 25 46-51	A	Screw M6S 12x70			
725 53 31-01	W	Screw MC6S 5x20			
725 53 68-01	N	Screw MC6S 6x16			
725 54 53-01	L	Screw MC6S 8x25			
725 54 57-01	X	Screw MC6S 8x35			
725 54 59-01	MN	Screw MC6S 8x40			
725 54 62-01	M	Screw MC6S 8x55			
725 54 67-01	U	Screw MC6S 8x80			
725 54 69-01	J	Screw MC6S 8x90			
725 63 25-51	R	Screw MF6S 5x10			
725 63 27-51	N	Screw MF6S 5x12			
725 63 30-51	I	Screw MF6S 5x16			
725 63 66-51	O	Screw MF6S 6x12			
725 63 68-51	IR	Screw MF6S 6x16			
725 64 59-51	E	Screw MF6S 8x40			
728 73 60-05	FG	Set screw S6SS 6x6			
728 73 64-05	BCD	Set screw S6SS 6x10			
728 84 45-05	JK	Set screw SK6SS 8x10			
731 23 18-01	FJKU	Nut M6M M8			
731 23 22-01	BCDMT	Nut M6M M12			
732 25 16-01	IRVW	Nut Loc-King M6			
732 25 18-01	J	Nut Loc-King M8			
732 25 20-01	P	Nut M10 nylock			
734 11 52-01	IRV	Washer BRB 6,4x12			
734 11 63-01	JLUV	Washer BRB 8,4x16			
735 31 17-00	JK	Circlip SgA 15			
735 31 30-00	PQ	Circlip SgA 30			

A

ConstructionParts.com

888-634-4289




ConstructionParts.com

888-634-4289

B

ConstructionParts.com

888-634-4289




ConstructionParts.com

888-634-4289

C

ConstructionParts.com

888-634-4289




ConstructionParts.com

888-634-4289

D

ConstructionParts.com

888-634-4289




ConstructionParts.com

888-634-4289

E

ConstructionParts.com

888-634-4289



ConstructionParts.com


ConstructionParts.com

888-634-4289

F

ConstructionParts.com

888-634-4289




ConstructionParts.com

888-634-4289

G

ConstructionParts.com


888-634-4289



H

ConstructionParts.com

888-634-4289




ConstructionParts.com

888-634-4289

ConstructionParts.com

888-634-4289




ConstructionParts.com

888-634-4289

J

ConstructionParts.com

888-634-4289




ConstructionParts.com

888-634-4289

K

ConstructionParts.com

888-634-4289




ConstructionParts.com

888-634-4289

L

ConstructionParts.com

888-634-4289




ConstructionParts.com

888-634-4289


M

ConstructionParts.com

888-634-4289




ConstructionParts.com



ConstructionParts.com

888-634-4289


N





ConstructionParts.com

888-634-4289




ConstructionParts.com

888-634-4289

P

ConstructionParts.com

888-634-4289




ConstructionParts.com

888-634-4289

Q

ConstructionParts.com

888-634-4289



ConstructionParts.com


888-634-4289

R

Wheel link complete 531 11 44-50

ConstructionParts.com

888-634-4289




ConstructionParts.com

888-634-4289

S

ConstructionParts.com

888-634-4289




ConstructionParts.com

888-634-4289

T

ConstructionParts.com

888-634-4289



ConstructionParts.com


ConstructionParts.com

888-634-4289

U

ConstructionParts.com

888-634-4289




ConstructionParts.com

888-634-4289

V

ConstructionParts.com

888-634-4289




ConstructionParts.com

888-634-4289

W

ConstructionParts.com


888-634-4289



X

ConstructionParts.com

888-634-4289



ConstructionParts.com

888-634-4289

