

Re.#	Part#	Description	Qty Reqd
1	20003467	GAS LOG ASSEMBLY	1
1a.	20003463	LOG, REAR	1
1b.	20003464	LOG, RIGHT	1
1c.	20003465	LOG, LEFT	1
2	30000393	GRILL, TOP	1
3	30000508	MESH, GRILL - UV30	1
4	1206122	CEMENT, GASKET 3OZ. TUBE	1
5	20003739	MANIFOLD ASSEMBLY	1
6	57897	LAVA ROCKS BURNER	1
5	1203702	GASKET GLASS - MEDIUM KNIT - 7 FEET USED	7
6	1601691	GLASS, DV25	1
7	30000127	WINDOW METAL FRAME ONLY	1
10a.	10001782	VALVE, HONEYWELL VS8420E 2038 NG WHEN CONVERTING TO SIT VALVE, ORDER RP275 FOR NG.	1
10b.	10001759	VALVE, HONEYWELL VS8420E 2020 LP WHEN CONVERTING TO SIT VALVE, ORDER RP269 FOR LP.	1
11a.	20003719	RF VALVE RV8310E 1107 - NG	1
11b.	20003720	RF VALVE RV8310E 2015 - LP	1
12a.	10002264	PILOT ASSEMBLY 3 WAY N/DV RN 0.199.706	1
12a.	10002265	PILOT ASSEMBLY 3 WAY N/DV RP 0.199.703	1
12b.	20001115	PILOT, PSE - NA175	1
12b.	20001116	PILOT, PSE - LP175	1
12c.	20002266	PILOT ASSEMBLY 3WAY DV/RFN	1
12c.	20002268	PILOT ASSEMBLY 3WAY DV/RFP	1
13	24D0808	THERMOCOUPLE 24IN (SAME AS 24D0808)	1
13	24D0808	THERMOCOUPLE 24IN (SAME AS 53373)	1
14	10001297	ELECTRODE IGNITER W/CABLE SIT24	1
15	10002266	PILOT TOP CONVERTIBLE	1
16	26D0566	THERMOPILE 18IN	1
17	57886	NUT ELECTRODE, SIT 0.974.144	1
18	26D0665	TUBING SIT PILOT W/FITTINGS 1/8IN X 24IN	1
19	20002400	THERMOPILE PSE FOR RF PILOTS - NO LONGER AVAILABLE SUB 26D0566	2
20a.	30000694	68 ORIFICE HOOD - FRONT LP (.031IN)	1
20c.	30000336	56 ORIFICE HOOD - REAR LP (.0465IN)	1
20d.	20003054	47 ORIFICE HOOD - REAR NG (.078IN)	1
21	20004066	BURNER HOUSING ASSEMBLY	1
22	20002167	GRATE, BURNER JDV	1
23	10002582	WIRE W/STRAIGHT TERMS END 50IN	1
24	53606	TRIM ON/OFF SWITCH - JDV	0
26	20005259	BRACKET, RIGHT LOG	0
28	20002282	GASKET BASE PAN	0
29	20002566	GASKET INNER BASE PAN	0
30	30001278	TOP CLASSIC STARDANCE RV,UV,PDV	0

30	30003307	TOP BISCUIT STARDANCE RV,UV,PDV	0
30	30001285	TOP BORDEAUX STARDANCE RV,UV,PDV	0
30	30003315	TOP CHESTNUT BROWN STARDANCE RV,UV,PDV	0
30	30001306	TOP EBONY STARDANCE RV,UV,PDV	0
30	30001292	TOP FOREST GREEN STARDANCE RV,UV,PDV	0
30	30001319	TOP MIDNIGHT BLUE STARDANCE RV,UV,PDV	0
30	30001299	TOP SAND STARDANCE RV,UV,PDV	0
30	30002554	TOP SUEDE BROWN STARDANCE RV,UV,PDV	0
30	30003323	TOP VERMONT CLASSIC GREEN RV,UV,PDV	0
30	30003638	TOP BRICK BLUE RV,UV,PDV	0
30	30003646	TOP COUNTRY COOKWARE GRAY RV,UV,PDV	0
30	30003654	TOP GRANITE GRAY RV,UV,PDV	0
30	30003662	TOP SAGE GREEN RV,UV,PDV	0
31	1301129	PDV20 FRONT CLASSIC	0
31	1321129	PDV20 FRONT SAND	0
31	1341129	PDV20 FRONT EBONY	0
31	30003326	PDV20 FRONT BISCUIT	0
32	30001139	LEFT DOOR STARDANCE CLASSIC	0
32	30003304	LEFT DOOR STARDANCE BISCUIT	0
32	30001263	LEFT DOOR STARDANCE BORDEAUX	0
32	30003312	LEFT DOOR STARDANCE CHESTNUT BROWN	0
32	30001272	LEFT DOOR STARDANCE EBONY	0
32	30001266	LEFT DOOR STARDANCE FOREST GREEN	0
32	30001316	LEFT DOOR STARDANCE MIDNIGHT BLUE	0
32	30001269	LEFT DOOR STARDANCE SAND	0
32	30002552	LEFT DOOR STARDANCE SUEDE BROWN	0
32	30003320	LEFT DOOR STARDANCE VERMONT CLASSIC GREEN	0
32	30003635	LEFT DOOR STARDANCE BRICK BLUE	0
32	30003643	LEFT DOOR STARDANCE COUNTRY COOKWARE GRAY	0
32	30003651	LEFT DOOR STARDANCE GRANITE GRAY	0
32	30003659	LEFT DOOR STARDANCE SAGE GREEN	0
33	30001138	RIGHT DOOR STARDANCE CLASSIC	0
33	30003303	RIGHT DOOR STARDANCE BISCUIT	0
33	30001262	RIGHT DOOR STARDANCE BORDEAUX	0
33	30003311	RIGHT DOOR STARDANCE CHESTNUT BROWN	0
33	30001271	RIGHT DOOR STARDANCE EBONY	0
33	30001265	RIGHT DOOR STARDANCE FOREST GREEN	0
33	30001315	RIGHT DOOR STARDANCE MIDNIGHT BLUE	0
33	30001268	RIGHT DOOR STARDANCE SAND	0
33	30002551	RIGHT DOOR STARDANCE SUEDE BROWN	0
33	30003319	RIGHT DOOR STARDANCE VERMONT CLASSIC GREEN	0
33	30003634	RIGHT DOOR STARDANCE BRICK BLUE	0
33	30003642	RIGHT DOOR STARDANCE COUNTRY COOKWARE GRAY	0
33	30003650	RIGHT DOOR STARDANCE GRANITE GRAY	0
33	30003658	RIGHT DOOR STARDANCE SAGE GREEN	0
34	30001496	FRONT (OP) CLASSIC	0
34	30003302	FRONT (OP) BISCUIT	0
34	30001261	FRONT (OP) BORDEAUX	0
34	30003310	FRONT (OP) CHESTNUT BROWN	0
34	30001270	FRONT (OP) EBONY	0

34	30001264	FRONT (OP) FOREST GREEN	0
34	30001314	FRONT (OP) MIDNIGHT BLUE	0
34	30001267	FRONT (OP) SAND	0
34	30002550	FRONT (OP) SUEDE BROWN	0
34	30003318	FRONT (OP) VERMONT CLASSIC GREEN	0
34	30003633	FRONT (OP) BRICK BLUE	0
34	30003641	FRONT (OP) COUNTRY COOKWARE GRAY	0
34	30003649	FRONT (OP) GRANITE GRAY	0
34	30003657	FRONT (OP) SAGE GREEN	0
35	1203290	NUT, HEX JAM TOPLK-Z	0
36	5004025	PAWL ASSEMBLY DOOR	0
37	30002717	FRONT STEEL HANDLE WSHAFT BRUSHED NICKEL	0
38	30004175K	BLACK WOOD FALLAWAY HANDLE ASSEMBLY	0
39	20003801	REAR SHROUD ASSEMBLY, PDV20	0
40	1203687	GASKET, HE DOOR	0
41	30001282	LEFT END PDV20 CLASSIC	0
41	30001303	LEFT END PDV20 SAND	0
41	30001310	LEFT END PDV20 EBONY	0
41	30003325	LEFT END PDV20 BISCUIT	0
42	30001281	RIGHT END PDV20 CLASSIC	0
42	30001302	RIGHT END PDV20 SAND	0
42	30001309	RIGHT END PDV20 EBONY	0
42	30003324	RIGHT END PDV20 BISCUIT	0
43	30001280	LEFT END SDVR CLASSIC	0
43	30003300	LEFT END SDVR BISCUIT	0
43	30001287	LEFT END SDVR BORDEAUX	0
43	30003308	LEFT END SDVR CHESTNUT BROWN	0
43	30001308	LEFT END SDVR EBONY	0
43	30001294	LEFT END SDVR FOREST GREEN	0
43	30001321	LEFT END SDVR MIDNIGHT BLUE	0
43	30001301	LEFT END SDVR SAND	0
43	30002547	LEFT END SDVR SUEDE BROWN	0
43	30003316	LEFT END SDVR VERMONT CLASSIC GREEN	0
43	30003631	LEFT END SDVR BRICK BLUE	0
43	30003639	LEFT END SDVR COUNTRY COOKWARE GRAY	0
43	30003647	LEFT END SDVR GRANITE GRAY	0
43	30003655	LEFT END SDVR SAGE GREEN	0
44	30001279	RIGHT END SDVR CLASSIC	0
44	30003301	RIGHT END SDVR BISCUIT	0
44	30001286	RIGHT END SDVR BORDEAUX	0
44	30003309	RIGHT END SDVR CHESTNUT BROWN	0
44	30001307	RIGHT END SDVR EBONY	0
44	30001293	RIGHT END SDVR FOREST GREEN	0
44	30001320	RIGHT END SDVR MIDNIGHT BLUE	0
44	30001300	RIGHT END SDVR SAND	0
44	30002548	RIGHT END SDVR SUEDE BROWN	0
44	30003317	RIGHT END SDVR VERMONT CLASSIC GREEN	0
44	30003632	RIGHT END SDVR BRICK BLUE	0
44	30003640	RIGHT END SDVR COUNTRY COOKWARE GRAY	0
44	30003648	RIGHT END SDVR GRANITE GRAY	0

44	30003656	RIGHT END SDVR SAGE GREEN	0
45	20002047	TRANSMITTER HONEYWELL RF	0
46	30000887	FK28 FAN SUBASSEMBLY FOR PDVRF	0
47	3186678	SILICONE PADS (NOT SHOWN)	0
48a.	20010563	VALVE SIT 820.662 RN (SERIAL S STARTING WITH 3871)	0
48b.	20010645	VALVE SIT 820.653 RP (SERIAL S STARTING WITH 3871)	0
49	057958	IGNITER PIEZO W/NUT SIT	0
50	20010876	BRACKET PIEZO IGNITER (NOT SHOWN)	0
N/S	0005005	CONVERSION KIT NG TO LP - RN MODELS	0
N/S	0005014	CONVERSION KIT NG TO LP - RP MODELS	0
N/S	0005004	CONVERSION KIT LP TO NG - RFN MODELS	0
N/S	0005013	CONVERSION KIT LP TO NG - RFP MODELS	0
N/S	30000085	FIREBOX CAP	0
N/S	30000084	AIR PASSAGE	0
N/S	30000060	RELIEF DOOR	0
N/S	30000083	4IN COLLAR	0
N/S	30000166	GLASS FRAME SUB ASSEMBLY	0
N/S	30000245	4IN STARTER	0
N/S	30002167	FINISH BAG	0
N/S	30002774	BLACK CERAMIC HANDLE W/INSERT LIFTER	0
N/S	20002166	RIGHT LOG SUPPORT	0
N/S	20002165	LEFT LOG SUPPORT	0

iBuyFireplaceParts.com 888-634-4289

iBuyFireplaceParts.com

iBuyFireplaceParts.com 888-634-4289