


DIMAS

ConstructionParts.com

888-634-4289



IPL, DS50 GYRO, 2004-07, 106 40 25-61

DS50 GYRO

Reservdelar

Spare parts

Ersatzteile

Pieces de rechange

Piezas de repuesto

Ricambi

Peças
sobresselente

ConstructionParts.com

ConstructionParts.com

888-634-4289

106 40 25-61

DIMAS

No.	Pos.	Description	No.	Pos.	Description
506 40 04-01	A	PIPE OUTER	531 14 06-70	D	STOPSCREW
506 40 05-01	A	PIPE INNER	531 14 06-71	F	DC 50 X1
506 40 06-01	C	ADJUSTMENT SCREW	531 14 06-72	FG	GRIP
506 40 07-01	C	DRILL RACK	531 14 06-73	FG	SPRING
506 40 08-01	E	KEYSET CPL.	531 14 06-75	K	SLEEVE
506 40 08-02	E	KEYSET COMPL. WEKA	531 14 06-76	K	WASHER
506 40 08-03	E	BRACKET CPL.	531 14 06-78	F	MOTORHOUSING
506 40 08-04	E	BRACKET	531 14 06-79	K	SCREW
506 40 14-01	A	BOLT COMPL	531 14 06-80	FG	BUSHING COMPL.
506 40 14-02	A	BOLT CPL.	531 14 06-83	EFG	NUT
506 40 15-01	C	SCREW COMPL GYRO UNIT	531 14 06-84	FG	SLEEVE
506 40 15-02	H	SCREW GB50AT	531 14 06-85	FG	SCREW
506 40 16-01	C	KNOB COMPL GYRO UNIT 50	531 14 06-86	FG	SCREW
506 40 17-01	D	SHAFT CPL. GYRO UNIT 50	531 14 06-87	FG	KNOB
506 40 17-02	F	SHAFT CPL. DCX1	531 14 06-88	FG	DECAL
506 40 17-03	G	SHAFT CPL. DCX2	531 14 06-90	FG	HANDLE
506 40 18-01	D	RETAINING RING COMPL.	531 14 06-91	G	DC 50 X2
506 40 19-01	F	BUSHING DCX1	531 14 06-92	G	SCREW
506 40 19-02	G	BUSHING DCX2	531 14 06-93	G	SCREW
506 40 20-01	FG	HANDLE	531 14 06-95	G	SCREW
506 40 20-02	FG	HANDLE	531 14 07-00	G	GEAR HOUSING
506 40 21-01	G	GEAR CPL.	531 14 07-01	G	NUT
506 40 22-01	H	HOLDER GB50AT	531 14 07-02	H	GB50AT NO WHEEL
531 14 06-00	C	NUT	531 14 07-03	J	GB50A NO WHEEL
531 14 06-01	B	GB50T NO WHEEL	531 14 07-05	G	MOTORHOUSING
531 14 06-02	A	WING SCREW	531 14 07-09	L	EXTENSION POLE INNER
531 14 06-04	A	STAMP MECHANISM SCREW	531 14 07-11	E	BOLT
531 14 06-07	AL	STOP TAP	531 14 07-15	H	GB50AT
531 14 06-08	B	GB50T	531 14 07-17	D	ADJUSTABLE LEVER
531 14 06-11	FG	DISTANCEWASHER	531 14 07-18	D	ADJUSTABLE LEVER
531 14 06-12	A	STAMP MECHANISM SCREW	531 14 07-19	D	ADJUSTABLE LEVER COMPL.
531 14 06-13	A	WASHER	531 14 07-20	D	SPRINGTIGHTEN
531 14 06-14	A	NUT	531 14 07-21	H	BOLT
531 14 06-16	A	FORK	531 14 07-22	H	SPACER WASHER
531 14 06-18	GHJ	SCREW LOCK	531 14 07-23	H	SCREW
531 14 06-19	BC	SCREW	531 14 07-23	J	SCREW
531 14 06-20	ABHJ	PLUG	531 14 07-24	H	NUT
531 14 06-21	B	PLATE	531 14 07-25	D	ADJUSTABLE LEVER
531 14 06-22	B	NUT	531 14 07-26	G	GEAR HOUSING
531 14 06-23	BK	R-CLIP	531 14 07-27	HJ	WHEEL STAND
531 14 06-24	BK	WHEEL COMPL.	531 14 07-28	HJ	WHEEL COMPL.
531 14 06-25	B	SHAFT HOLDER	531 14 07-29	A	SLEEVE COMPL.
531 14 06-26	B	KNOB	531 14 07-30	HJ	COVERPLATE
531 14 06-27	BHJK	WASHER	531 14 07-31	H	PLATE
531 14 06-28	CD	GYRO UNIT	531 14 07-32	HJ	SHAFT HOLDER + WHEEL
531 14 06-29	C	SHAFT	531 14 07-33	H	SHAFT
531 14 06-30	CFG	NUT	531 14 07-34	K	STABILIZER
531 14 06-31	J	PLATE	531 14 07-35	K	SCREW
531 14 06-32	C	WASHER	531 14 07-36	K	FORK
531 14 06-33	C	WASHER	531 14 07-37	K	SLEEVE
531 14 06-34	C	WASHER	531 14 07-38	K	PLUG
531 14 06-36	CH	WASHER	531 14 07-39	K	SLEEVE
531 14 06-37	C	NUT	531 14 07-41	A	TOP SUPPORT
531 14 06-38	C	WASHER	531 14 07-43	K	SCREW
531 14 06-39	C	SCREW	531 14 07-44	D	BUSHING COMPL.
531 14 06-40	C	DOWEL LOCK	531 14 07-45	B	SHAFT HOLDER + WHEEL
531 14 06-41	J	GB50A	531 14 07-46	D	HANDLE COMPL.
531 14 06-43	C	KNOB	531 14 07-47	L	EXTENSION POLE OUTER
531 14 06-44	C	NUT	531 14 07-48	L	POLE OUTER
531 14 06-45	C	ADJUSTMENT SCREW	531 14 07-49	L	SCREW
531 14 06-46	M	BRACKET	531 14 07-50	K	ADJUSTABLE LEVER COMPL.
531 14 06-47	C	DRILL RACK CPL.	531 14 07-51	KL	HANDLE COMPL.
531 14 06-57	D	STOPSCREW	531 14 07-52	K	ROD
531 14 06-58	FG	SCREW	531 14 07-55	L	ADJUSTABLE LEVER COMPL.
531 14 06-59	FG	SCREW	531 14 07-57	H	NUT
531 14 06-60	D	SLIDEBUSHING	531 14 07-59	M	TOOL KIT
531 14 06-62	D	WASHER	531 14 07-69	A	EXPANDABLE COLUMN
531 14 06-63	D	HOLDER			
531 14 06-64	L	PLUG			
531 14 06-68	D	SCREW			

A

ConstructionParts.com

888-634-4289

compl 531 14 07-69
EXPANDABLE COLUMN

*compl 531 14 06-12

*506 40 14-01

ConstructionParts.com

506 40 05-01

531 14 06-20

531 14 06-02

531 14 07-41

531 14 07-29

531 14 06-07

506 40 04-01

*531 14 06-04

*531 14 06-13

*531 14 06-16

*531 14 06-14

506 40 14-02*

B

compl 531 14 06-08
GB50T

*compl 531 14 06-01
GB50 T NO WHEEL

*531 14 06-18 (x4)

*531 14 06-19

**531 14 06-22

**compl 531 14 07-45
SHAFT HOLDER WITH WHEEL

**531 14 06-23

**531 14 06-25

**531 14 06-24 (x2)

531 14 06-26*



ConstructionParts.com

888-634-4289

**531 14 06-27 (x6)

*531 14 06-20 (x4)

*531 14 06-21




C

compl 531 14 06-28 GYRO UNIT


**compl 506 40 16-01

ConstructionParts.com 888-634-4289



compl 531 14 06-47 DRILL RACK

ConstructionParts.com



ConstructionParts.com

888-634-4289

D


compl 531 14 06-28 GYRO UNIT

compl 531 14 07-46


ConstructionParts.com

888-634-4289

*compl 531 14 07-44




ConstructionParts.com




ConstructionParts.com

888-634-4289



G compl 531 14 06-91 DCX2



888-634-4289

ConstructionParts.com

ConstructionParts.com

888-634-4289

H

compl 531 14 07-15 GB50AT

ConstructionParts.com 888-634-4289

compl 531 14 07-32
SHAFT HOLDER
WITH WHEEL

531 14 07-23

531 14 07-27

531 14 07-28 (x2)

531 14 06-27 (x6)

531 14 07-30 (x2)

compl 531 14 07-02
GB50AT NO WHEEL

*compl 506 40 22-01

**compl 506 40 15-02

ConstructionParts.com

*/** (x2)

*/**

531 14 07-57*

*/** (x2)

*/**

*531 14 07-21

531 14 07-22*

531 14 07-24

531 14 06-36

531 14 06-18 (x4)

ConstructionParts.com 888-634-4289

531 14 06-20 (x4)

531 14 07-31

*/** (x2)



531 14 07-33

J

compl 531 14 06-41 GB50A


ConstructionParts.com

888-634-4289



K compl 531 14 07-34 STABILIZER

ConstructionParts.com 888-634-4289




L


ConstructionParts.com

888-634-4289

*compl 531 14 07-47
EXTENSION POLE OUTER






*compl 531 14 07-09
EXTENSION POLE INNER



ConstructionParts.com

M Accessories
Zubehöre
Accessoires
Acessorios
Tillbehör

*compl 531 14 07-59



ConstructionParts.com

888-634-4289

