




AC2-PH11-30M / AC2-PH11-30M (sn:20024699-99999999)

TANK ASSEMBLY



Id	Item #	Description	Quantity	Rev	Comments
1	27-0133	BOLT	1		
2	28-0023	FLATWASHER	19		
3	20-0650A01	BELT TENSIONER PLATE	1		
4	5-0198A01	BASEPLATE	1		
5	N/A	DECAL- DATA PLATE	1		
6	27-9524	BOLT	15		
7	N/A Sep.	DECAL- WARNING: RISK OF BURNS (SEE 34-9016)	2		
8	N/A Sep.	DECAL- DANGER/WARNING/CAUTION (SEE 34-9016)	1		
9	29-0007	LOCKWASHER	16		
10	27-0067	BOLT	16		
11	33-0351	COLLAR / SHAFT	2		
12	14-0006	WHEEL	2		
13	28-0008	WASHER	6		
14	62-0176	AXLE SPACER	2		
15	20-0670A01	AXLE STUB BRACKET	2		


Id	Item #	Description	Quantity	Rev	Comments
16	N/A Sep.	DECAL- DRAIN TANK (SEE 34-9016)	2		
17	34-0828	DECAL- MI-T-M COMPRESSOR	2		
18	23-0312	DRAIN VALVE	1		
19	20-0671A01	SUPPORT BRACKET	1		
20	27-0068	BOLT	2		
21	14-0008	ISOLATOR	2		
22	28-0003	WASHER	6		
23	30-0157	LOCKNUT	4		
24	N/A	AIR TANK ASSEMBLY	1		
25	24-0041	ELBOW	1		
26	22-0270	PILOT VALVE	1		
27	15-0188	HOSE	1		
28	24-0160	ADAPTER	1		
29	27-0122	BOLT	8		
30	30-0159	LOCKNUT	8		
31	43-0102	KEY	1		
32	10-0130	FLYWHEEL	1		
33	11-0066	DRIVE BELT	1		
34	28-1032	WASHER	1		
35	27-8033	BOLT	1		
36	854-0067	FRONT BELTGUARD ASSEMBLY (INC. 36-37)	1		
37	33-0020	EDGING *(FIVE FEET REQUIRED)	1		
38	N/A Sep.	FRONT BELTGUARD (SEE 854-0067)	1		
39	N/A Sep.	DECAL- MAINTENANCE INSTRUCTIONS (SEE 34-9016)	1		
40	N/A Sep.	DECAL- OPERATING INSTRUCTIONS (SEE 34-9016)	1		
41	33-0197	FASTENER	2		
42	27-0015	BOLT	2		
43	9-0005	BUSHING	1		
44	10-0128	SHEAVE	1		
45	854-0066	BACK BELTGUARD ASSEMBLY (INC. 45-47)	1		
46	N/A Sep.	BACK BELTGUARD (SEE 854-0024)	1		
47	N/A Sep.	DECAL- WARNING: BELTGUARD IN PLACE (SEE 34-9016)	1		
48	33-0020	EDGING *(THREE FEET REQUIRED)	1		
49	19-0219	AIR FILTER ASSEMBLY (INC. 49-51)	1		
50	N/A Sep.	FRONT AIR FILTER HOUSING (SEE 19-0219)	1		
51	19-0220	AIR FILTER ELEMENT	1		
52	N/A Sep.	REAR AIR FILTER HOUSING (SEE 19-0219)	1		
53	3-0222	COMPRESSOR PUMP	1		
54	27-0066	BOLT	2		

Id	Item #	Description	Quantity	Rev	Comments
55	27-8074	BOLT	2		
56	20-0816A01	SUPPORT BRACKET	1		
57	33-0425	SPACER	4		
58	N/A Sep.	DECAL- CHECK OIL (SEE 34-9016)	2		
59	43-0078	KEY	1		
60	N/A Sep.	DECAL- ENGINE FUEL (SEE 34-9016)	1		
61	1-0086	ENGINE- 13.0 HP HONDA	1		
62	N/A Sep.	DECAL- MUFFLER HOT (SEE 34-9016)	1		
63	70-0358	DRAINZIT DRAIN ASSEMBLY	1		
64	24-0267	ELBOW	1		
65	22-0271	PRESSURE GAUGE	2		
66	24-0009	PLUG	1		
67	24-0266	MANIFOLD	1		
68	22-0267	PRESSURE RELIEF VALVE	1		
69	24-0082	PLUG	1		
70	24-0175	NIPPLE	1		
71	22-0231	ADJUSTABLE REGULATOR	1		
72	23-0316	ELBOW	1		
73	23-0425	TUBE SUPPORT INSERT	2		
74	15-0238	TUBE *(TWO FEET REQUIRED)	1		
75	33-0413	THROTTLE CONTROL	1		
76	23-0315	COMPRESSION NUT	1		
77	45-0084	ENGINE THROTTLE CLIP	1		
78	62-0126	THROTTLE CONTROL ADAPTER	1		
	34-9016	SAFETY DECAL KIT (INC. 7-8, 15, 38-39, 46, 57, 59, 61)			
		*MUST ORDER IN ONE FOOT LENGTHS			



AC2-PH11-30M / AC2-PH11-30M (sn:20024699-99999999)

SINGLE STAGE COMPRESSOR



Id	Item #	Description	Quantity	Rev	Comments
1	27-8807	BOLT	1		
2	46-1156	AFTER COOLER	1		
3	22-0385	SAFETY VALVE	1		
4	27-8032	BOLT	5		
5	25-0439	O-RING	3		
6	28-1021	WASHER	6		
7	27-8934	BOLT	6		
8	N/A	AIR SHROUD	1		
9	27-8002	BOLT	6		
10	22-0386	SAFETY VALVE	1		

Id	Item #	Description	Quantity	Rev	Comments
11	27-9575	BOLT	11		
12	46-1157	INTER COOLER	1		
13	25-0440	O-RING	1		
14	46-0816	INTERCOOLER COVER	1		
15	27-8906	BOLT	4		
16	46-1158	PUMP HEAD	1		
17	N/A Sep.	HEAD GASKET (SEE 70-0345)	1		
18	22-0283	VALVE PLATE ASSEMBLY	1		
19	N/A Sep.	CYLINDER GASKET (SEE 70-0345)	1		
20	46-1176	CYLINDER	1		
21	N/A Sep.	CRANKCASE GASKET (SEE 70-0345)	1		
22	N/A	COMPLETE PISTON	1		
23	70-0344	RING SET KIT	1		
24	N/A	CONNECTING ROD	2		
25	27-8194	BOLT	6		
26	46-0818	CRANKCASE FILL HOLE PLUG W/O-RING	1		
27	46-0819	OIL FILL END CAP	1		
28	N/A Sep.	OIL FILL END CAP GASKET (SEE 70-0345)	1		
29	46-0820	OIL LEVEL SIGHT GLASS W/GASKET	1		
30	39-0106	OIL DRAIN PLUG	1		
31	N/A	OIL PAN	1		
32	N/A Sep.	OIL PAN O-RING (SEE 70-0345)	1		
33	46-0821	ISOLATOR	4		
34	N/A	CRANKCASE	1		
35	48-0060	BALL BEARING	1		
36	N/A	PISTON CRANKSHAFT	1		
37	48-0024	BALL BEARING	1		
38	N/A Sep.	FRONT END CAP GASKET (SEE 70-0345)	1		
39	26-0208	CRANKSAFT SEAL	1		
40	46-0822	FRONT END CAP	1		
41	27-8033	BOLT	5		
42	10-0130	FLYWHEEL	1		
43	28-1032	WASHER	1		
44	43-0102	KEY	1		
45	N/A	COMPLETE PISTON	1		
46	70-0239	RING SET KIT	1		
KIT	70-0345	GASKET KIT (INC. 5, 13, 17, 19, 21, 28, 32, 38)	1		


Id	Item #	Description	Quantity	Rev	Comments
1	N/A	INLET PORT FITTING	1		
2	N/A Sep.	O-RING (SEE 70-0241)	3		
3	N/A	MAIN BODY	1		
4	N/A Sep.	PISTON ASSEMBLY-UNLOADER VALVE (SEE 70-0241)	1		
5	N/A Sep.	SPRING-UNLOADER VALVE (SEE 70-0241)	1		
6	N/A	SPRING SEAT-UNLOADER VALVE	1		
7	N/A	CAP	1		

Id	Item #	Description	Quantity	Rev	Comments
8	N/A	DISCHARGE PORT FITTING	1		
9	N/A	SPRING SEAT ASSEMBLY-CHECK VALVE	1		
10	N/A Sep.	SPRING-CHECK VALVE (SEE 70-0241)	1		
11	N/A Sep.	PISTON-CHECK VALVE (SEE 70-0241)	1		
12	23-0419	MUFFLER	1		
13	N/A Sep.	STEM UNLOADER (SEE 70-0241)	1		
14	N/A Sep.	DIAPHRAM (SEE 70-0241)	1		
15	N/A Sep.	O-RING (SEE 70-0241)	1		
16	N/A Sep.	SCREEN (SEE 70-0241)	1		
17	N/A	SCREW W/WASHER	4		
18	N/A	PILOT BODY	1		
19	N/A Sep.	BALL (SEE 70-0241)	1		
20	N/A Sep.	O-RING (SEE 70-0241)	1		
21	N/A	DIFFERENTIAL ADJUSTING LOCKNUT	1		
22	N/A	DIFFERENTIAL ADJUSTING NUT	1		
23	N/A	PRESSURE ADJUSTING LOCKNUT	1		
24	N/A Sep.	PRESSURE ADJUSTING TOGGLE ASSEMBLY (SEE 70-0241)	1		
25	N/A	RED TOGGLE COVER	1		
KIT	70-0241	REPAIR KIT (INC. 2 EACH 3, 4-5, 10-11, 13-16, 19-20, 24			




AC2-PH11-30M / AC2-PH11-30M (sn:20024699-99999999)

AX-OPTIONS BATTERY



Id	Item #	Description	Quantity	Rev	Comments
1	1-0039	ENGINE- HONDA 11HP	1		

AX-OPTION BREAKS



Id	Item #	Description	Quantity	Rev	Comments
1	5-0198A01	BASE PLATE ASSEMBLY	1		
2	24-0267	ELBOW	1		
3	24-0266	MANIFOLD	1		
4	24-0175	NIPPLE	1		

Id	Item #	Description	Quantity	Rev	Comments
5	24-0082	PLUG	1		
6	24-0009	PLUG	1		
7	20-0671A01	SUPPORT FOOT BRACKET	1		
8	30-0157	LOCKNUT	2		
9	28-0003	WASHER	2		
10	14-0008	ISOLATOR	2		
11	27-0068	SCREW	2		