

Parts Catalogue



DFP11 Forward Plate

Engine : Honda GX160UH2X-QX4-SD



No. DL00827161 | 2024-09-24

© 2018 Dynapac GmbH

***Your Partner
on the Road Ahead***

dynapac.com

General information

Use only authorized parts. Any damage or malfunction caused by the use of unauthorized parts is not covered by Warranty or Product Liability. Any unauthorized use or copying of the contents or any part thereof is prohibited. This applies in particular to trademarks, model denominations, part numbers, and drawings.

Instructions for use

This spare parts list contains no safety regulations and is merely intended to assist in the ordering of spare parts.

For information about operating, servicing, or repairing, the relevant Safety and operating instructions must be consulted at all costs.

Please observe the safety instructions listed in the relevant Safety and operating instructions!

10 Engine

DL92400024_00_010_DFP11-76 Engine / Fitting Parts	1
---	---

Engine / Fitting Parts

DL92410076_00 Engine Carrier	3
DL92411212_00 Engine	5
DLEA002910_00 Centrifugal Clutch	7

50 Frame

DL92500026_00_050_DFP11-76 Frame with Attachment Parts	9
--	---

Frame with Attachment Parts

DL23060047_00 Steering Handle	11
-------------------------------	----

65 Plate

DL92400024_00_065_DFP11-76 Plate / Foot	13
---	----

Plate / Foot

DL23020007_01 Base Plate	15
DL23010002_01 Exciter Unit	17

100 Accessories

dynp_DL92400004_00_100_DFP11-76 Accessories	19
---	----

Accessories

DL92410914_01 Decals	21
----------------------	----



110 Options

dynp_DL92500026_00_110_DFP11-76 Special Equipment	23
---	----

Special Equipment

DL23000216_00 L15-Steering handle, Middle	25
DL92400104_01 W1-Water sprinkler system	27
DL23003471_00 Water tank, assembled	29
DL23000214_00 L19-Comfort handle	31
DL23000218_00 L20-Comfort handle,middle	33
DL23000614_01 T90-Transport wheels,mid bow	35
DL23000616_00 T1-Transport wheels	37
DL92492424_00 Service kit	39

10 Engine DL92400024_00_010_DFP11-76 Engine / Fitting Parts




10.00

Forward Plate DFP11



Item	Part No.	Qty	Name	SN INFO
12.12			Engine Carrier	
12.13	DL92411212_00		Engine	
19.07			Centrifugal Clutch	




12.12

Forward Plate DFP11

Item	Part No.	Qty	Name	SN INFO
1	DL23030223	1	Engine carrier	
2	DL07141020	4	Screw	
3	DL08752106	4	Spring washer	
4	DL23030173	1	Holder	
5	DL07140842	2	Screw	
6	DL08510817	2	Washer	
7	DL23030205	1	Stop	DFP11 - from 101924241001 to 101924241036
7	DL23030229	1	Stop	DFP11 - from 101924241037 ff.
8	DL23030176	2	Carrying handle	
9	DL08590820	2	Washer	
10	DL08130813	2	Safety nut	
65.05	-		Base Plate	

Engine / Fitting Parts DL92411212_00 Engine

- 2) Luftfilter-Dichtung bei Einsatz in sehr staubiger Umgebung durch Pos. 30 ersetzen !
For use in very dusty environment replace air filter sealing by item no. 30 !



12.13

Refer to Parts Online for the most up to date information. The printed information might be outdated.


Fri Sep 18 00:35:56 UTC 2026

Forward Plate DFP11

Item	Part No.	Qty	Name	SN INFO
1	DL05747086	1	Four-stroke engine	
2	DL07140848	4	Screw	
3	DL08510817	8	Washer	
4	DL08130813	4	Safety nut	
5	DL05650122	1	Centrifugal clutch	
6	DL23040112	1	Spacer sleeve	
7	DL23040137	1	Washer	
8	DL07010816	1	Hexagon bolt	
9	DL23040106	1	Seal	
10	DL06142915	1	Stop buffer	
11	DL23040153	1	Supporting plate	
12	DL08510817	2	Washer	
13	DL07210817	2	Screw	
14	DL08621084	4	Washer	
15	DL92410030	1	V-belt guard	
16	DL07140853	3	Screw	
17	DL08510817	3	Washer	
18	DL92410581	1	V-belt	
19	DL08130813	2	Safety nut	
20	DL69020718	2	Stop	
21	DL07230819	2	Screw	
22	DL08510817	2	Washer	
23	DL08130813	2	Safety nut	
24	DL23040185	1	Supporting plate	
25	DL06510213	1	Plug	
26	DL08510817	1	Washer	
27	DL08130813	1	Safety nut	
28	DL08665000	3	Stop disc	
29	DL05749153	1	Exhaust gas effector	
30	DL83403043	1	Gasket	
12.12			Engine Carrier	
19.07			Centrifugal Clutch	
194.08			Service kit	

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 00:35:56 UTC 2026





19.07

Forward Plate DFP11

Item	Part No.	Qty	Name	SN INFO
0	DL05650122	1	Centrifugal clutch	
1	DL05660548	1	Belt pulley	
2	DL05113306	1	Ball bearing,grooved	
3	DL05660215	1	Spring ring	
4	DL05660777	1	Circlip	
5	DL05660459	1	Hub	
6	DL05660214	2	Centrifugal weight	
7	DL05660174	2	Support with lining	
8	DL05660366	4	Tension spring	
9	DL05660134	2	Cover disc	
10	DL05660807	2	Circlip,external	

50 Frame DL92500026_00_050_DFP11-76 Frame with Attachment Parts




50.00

Forward Plate DFP11



Item	Part No.	Qty	Name	SN INFO
52.16	DL23060047_00		Steering Handle	





52.16

Forward Plate DFP11

Item	Part No.	Qty	Name	SN INFO
1	DL23003476	2	Bushing	
2	DL23003475	2	Spring element	
3	DL08130813	4	Safety nut	
4	DL08510817	4	Washer	
5	DL05931600	2	Linch pin	
6	DL23060280	1	Steering handle	
7	DL07140818	2	Screw	
8	DL08590820	2	Washer	
9	DL06142912	2	Stop buffer	
12.12	-		Engine Carrier	

65 Plate DL92400024_00_065_DFP11-76 Plate / Foot



65.00

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 00:35:59 UTC 2026


Forward Plate DFP11



Item	Part No.	Qty	Name	SN INFO
65.05	DL23020007_01		Base Plate	
65.06	DL23010002_01		Exciter Unit	

Plate / Foot DL23020007_01 Base Plate

1) Vorspannung Gummipuffer 0-1mm
rubber buffer preload 0-1mm



65.05


Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 00:35:59 UTC 2026

Forward Plate DFP11

Item	Part No.	Qty	Name	SN INFO
1	DL23010504	1	Base plate	SN - from 101925371082 ff.
1	DL23020146	1	Base plate	SN - from 101925371001 to 101925371081
2	DL06126912	4	Rubber buffer	
3	DL23020117	8	Shim	
4	DL07611616	1	Magnetic plug	
194.08	-		Service kit	

Plate / Foot DL23010002_01 Exciter Unit




65.06

Refer to Parts Online for the most up to date information. The printed information might be outdated.
Fri Sep 18 00:36:00 UTC 2026

Forward Plate DFP11

Item	Part No.	Qty	Name	SN INFO
1	DL05224252	1	Cylinder roller bearing	
2	DL05224260	1	Cylinder roller bearing	
3	DL05428122	1	Inner ring	
4	DL06510380	1	Locking cap	
5	DL07230819	1	Screw	
7	DL09181604	1	Fitting key	
8	DL09224400	1	Circlip,internal	
9	DL09312808	1	Radial seal	
10	DL23010161	1	Exciter shaft	
12	DL23010140	1	V-belt pulley	
13	DL23010132	1	Washer	
14	DL23010156	1	Seal	
65.05	-		Base Plate	




100.00

Forward Plate DFP11



Item	Part No.	Qty	Name	SN INFO
101.03	DL92410914_01		Decals	

Accessories DL92410914_01 Decals



101.03


Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 00:36:01 UTC 2026

Forward Plate DFP11

Item	Part No.	Qty	Name	SN INFO
1	DL00833977	1	Decal,maintenance instr.	
2	DL00834125	1	Decal,operation	
3	DL00833833	1	Decal,indication	
4	DL00833226	1	Decal,indication	
5	DL05050358	1	Decal,indication	
6	DL05050359	1	Decal,indication	
7	DL00832654	1	Decal,indication	
8	DL00833653	1	Decal,indication	
9	DL92410405	1	Type designation	
10	DL92410221	1	Decal	
11	DL00834622	1	Warning sign	

110 Options dynp_DL92500026_00_110_DFP11-76 Special Equipment




110.00

Forward Plate DFP11

Item	Part No.	Qty	Name	SN INFO
152.04	DL23000216_00		L15-Steering handle, Middle	
152.18	DL92400104_01		W1-Water sprinkler system	
152.31	DL23003471_00		Water tank, assembled	
152.72	DL23000214_00		L19-Comfort handle	
152.73	DL23000218_00		L20-Comfort handle,middle	
161.63	DL23000614_01		T90-Transport wheels,mid bow	
162.1	DL23000616_00		T1-Transport wheels	
194.08			Service kit	

Special Equipment DL23000216_00 L15-Steering handle, Middle



152.04


Forward Plate DFP11

Item	Part No.	Qty	Name	SN INFO
1	DL23003484	2	Holder	
2	DL88003146	2	Band, belt	
3	DL07140842	4	Screw	
4	DL08500823	4	Washer	
5	DL08510817	4	Washer	
6	DL08130813	4	Safety nut	
7	DL23060325	4	Buffer	
8	DL23003422	1	Steering handle	
9	DL07141017	4	Screw	
10	DL08501028	4	Washer	
11	DL23003476	2	Bushing	
12	DL23003475	2	Spring element	
13	DL08130813	4	Safety nut	
14	DL08510817	4	Washer	
15	DL05931600	2	Linch pin	
12.12	-		Engine Carrier	

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 00:36:02 UTC 2026

Special Equipment DL92400104_01 W1-Water sprinkler system



152.18

Forward Plate DFP11

Item	Part No.	Qty	Name	SN INFO
1	DL23003471	1	Water tank, assembled	
2	DL23003273	1	Plate	
3	DL23003440	1	Tapped plate	
4	DL07210616	3	Screw	
5	DL08621064	3	Washer	
6	DL00652070	2.00	Expanded rubber	
7	DL06144100	2	Stop buffer	
8	DL08752084	2	Spring washer	
9	DL08130813	2	Safety nut	
10	DL92410189	1	Decal	
52.17	-		Protection Bow	

[illegible]

29

Forward Plate DFP11


Item	Part No.	Qty	Name	SN INFO
KIT	DL23003471		Water tank, assembled	
1	DL23003470	1	Tank, cpl.	
1.1	DL23003289	1	Tank cover	
1.2	DL23003319	1	Filling level indicator	
2	DL23003447	1	Valve	
2.1	DL23003448	1	Adjustment sleeve	
2.2	DL23003449	1	Intake	
3	DL06220148	1	Loop ring	
4	DL23003446	1	Rod	
5	DL09133514	1	Grooved dowel pin	
6	DL09220901	1	Circlip, internal	
7	DL23003347	1	Gasket	
8	DL07230521	2	Screw	
9	DL08621053	2	Washer	
10	DL06550012	1	Gasket	
11	DL08110813	1	Hexagon nut	
12	DL06420840	1	Wing nut	
13	DL06420841	1	Cap, cover	
14	DL23003452	1	Tube holder	
15	DL06220147	1	Loop ring	
16	DL06220223	2	Loop ring	
17	DL23003450	1	Tube	
18	DL23003451	2	Plug	
19	DL05551959	2	Tube clamp	
20	DL07210609	2	Screw	
21	DL23003180	1	Bolt	
22	DL05994004	1	Spring cotter	
23	DL00833835	1	Decal, indication	

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 00:36:03 UTC 2026

Special Equipment DL23000214_00 L19-Comfort handle

1) Anziehdrehmoment 25 Nm
Tightening torque 25 Nm

**152.72**

Refer to Parts Online for the most up to date information. The printed information might be outdated.


Fri Sep 18 00:36:04 UTC 2026

Forward Plate DFP11

Item	Part No.	Qty	Name	SN INFO
1	DL23003476	2	Bushing	
2	DL23003475	2	Spring element	
3	DL08130813	4	Safety nut	
4	DL08510817	4	Washer	
5	DL05931600	2	Linch pin	
6	DL23060278	1	Steering handle	
7	DL23060333	1	Shaft	
8	DL23060282	2	Expanded rubber	
9	DL23060283	2	Stop	
10	DL05756120	2	Wall duct	
11	DL07320829	2	Screw	
12.12	-		Engine Carrier	

Special Equipment DL23000218_00 L20-Comfort handle,middle

¹⁾ Anziehdrehmoment 25 Nm
Tightening torque 25 Nm



152.73

Refer to Parts Online for the most up to date information. The printed information might be outdated.


Fri Sep 18 00:36:04 UTC 2026

Forward Plate DFP11

Item	Part No.	Qty	Name	SN INFO
1	DL23003484	2	Holder	
2	DL88003146	2	Band, belt	
3	DL07140842	4	Screw	
4	DL08500823	4	Washer	
5	DL08510817	4	Washer	
6	DL08130813	4	Safety nut	
7	DL23060325	4	Buffer	
8	DL23003425	1	Steering handle	
9	DL07141017	4	Screw	
10	DL08501028	4	Washer	
11	DL23003476	2	Bushing	
12	DL23003475	2	Spring element	
13	DL08110813	4	Hexagon nut	
14	DL08510817	4	Washer	
15	DL05931600	2	Linch pin	
16	DL23003428	1	Shaft	
17	DL23060282	2	Expanded rubber	
18	DL23060283	2	Stop	
19	DL05756120	2	Wall duct	
20	DL07320829	2	Screw	
12.12	-		Engine Carrier	

Special Equipment DL23000614_01 T90-Transport wheels,mid bow

1) Anziehdrehmoment 100 Nm
Tightening torque 100 Nm



161.63

Refer to Parts Online for the most up to date information. The printed information might be outdated.


Fri Sep 18 00:36:05 UTC 2026

Forward Plate DFP11

Item	Part No.	Qty	Name	SN INFO
1	DL23003314	1	Frame	
2	DL07141242	2	Screw	
3	DL08511324	6	Washer	
4	DL08131218	2	Safety nut	
5	DL06422046	1	Control pin	
6	DL06704107	2	Wheel	
7	DL05520315	2	Supporting disc	
8	DL09170407	2	Cotter pin	
9	DL23003248	1	Holder	
10	DL07140834	2	Screw	
11	DL08510817	4	Washer	
12	DL08130813	2	Safety nut	
13	DL23003354	1	Detent	
14	DL07140626	1	Screw	
15	DL08590617	1	Washer	
16	DL23003460	1	Holder	
17	DL07140834	2	Screw	
18	DL08510817	4	Washer	
19	DL08130813	2	Safety nut	
20	DL23003455	1	Hook	
21	DL68050213	1	Washer	
22	DL07140834	1	Screw	
23	DL09290169	2	Belleville spring	
24	DL08130813	1	Safety nut	
25	DL08141615	1	Hexagon nut	
12.12	-		Engine Carrier	

Special Equipment DL23000616_00 T1-Transport wheels

1) Anziehdrehmoment 100 Nm
Tightening torque 100 Nm



162.10


Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 00:36:05 UTC 2026

Forward Plate DFP11

Item	Part No.	Qty	Name	SN INFO
1	DL23003314	1	Frame	
2	DL07141242	2	Screw	
3	DL08511324	6	Washer	
4	DL08131218	2	Safety nut	
5	DL06422046	1	Control pin	
6	DL08141615	1	Hexagon nut	
7	DL06704107	2	Wheel	
8	DL05520315	2	Supporting disc	
9	DL09170407	2	Cotter pin	
10	DL23003248	1	Holder	
11	DL07140834	2	Screw	
12	DL08510817	4	Washer	
13	DL08130813	2	Safety nut	
14	DL23003354	1	Detent	
15	DL07140626	1	Screw	
16	DL08590617	1	Washer	
17	DL23003479	2	Plate	
18	DL23003480	2	Plate	
19	DL06422046	2	Control pin	
20	DL08141615	4	Hexagon nut	
21	DL07210820	4	Screw	
22	DL08510817	4	Washer	
23	DL08130813	4	Safety nut	
12.12	-		Engine Carrier	

Special Equipment DL92492424_00 Service kit



194.08

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 00:36:06 UTC 2026

Forward Plate DFP11

Item	Part No.	Qty	Name	SN INFO
0	DL92492424	1	Service kit	
1	DL92410581	1	V-belt	
2	DL05747161	1	Filter,fuel	
3	DL05747188	1	Loop ring	
4	DL05747215	1	Element	
5	DL05747296	1	Starter rope	
6	DL05747282	1	Spark plug	
7	DL05747125	1	Valve cover gasket	
8	DL05747129	1	Gasket, oil drain	
9	DL07611616	1	Magnetic plug	
10	DL83403043	1	Gasket	

