



IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.



**Stocked
in Depot**

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	
1	Starter Collar		30399	
2	Damper Assembly		34454	
3	Top Stand Off	Qty 4 Req	4044-111	
4	Upper Front Face	Not replaceable must order overlay CUST4004-107	30395	
5	Side Column Left		30375	
6	Top Door Track		30400	
7	Door Clips	Qty 2 Req	30407	
Traditional Refractory				
8	Right Side Refractory		28393	
9	Back Refractory		28394	
10	Left Side Refractory		28393	
	Hearth Refractory		28391	
Herringbone refractory available post week 3/04				
8	Right Side Refractory		4010-013	
9	Back Refractory		4010-015	
10	Left Side Refractory		4010-014	
	Hearth Refractory		4010-020	
11	Grate		GR21	Y
12	Hearth Pan	Pre AK560843	30405	
	Hearth Stone Retainer	Post Ak560843	30403	
13	Firescreen Rod	Qty 2 Req	31375	Y
14	Screen Assembly	Qty 2 Req	30371	
15	Door Pivot Clip	Qty 2 Req	31527	
16	Bottom Front Face	Not replaceable must order overlay CUST4004-107	30393	
17	Side Column Right		30376	
	Gas Tube		30412	
	Smoke Shield		30402	