





Cylinder Head Subassembly



Id	Item #	Description	Quantity
1	45-0190	CYLINDER HEAD COVER SUBASSY	1
2	45-0191	GASKET- CYLINDER HEAD COVER	1
3	45-0598	CYLINDER HEAD SUBASSY	1
4	45-0599	GASKET- CYLINDER HEAD	1
5	80-0060	BOLT-STOPPER BRACKET	4
6	45-0192	SPARK PLUG	1
7	45-0600	BOLT-CYLINDER HEAD	4
8	45-0193	BRACKET- MUFFLER SHIELD	1
9	80-0060	BOLT-STOPPER BRACKET	1
10	45-0601	STUD- CARBURETOR	2
11	45-0602	PIN- CYLINDER HEAD	2



Crankcase/governor gear Assembly




Id	Item #	Description	Quantity
12	45-0603	CRANKCASE SUBASSY	1
13	45-0604	CRANKCASE SHIELD	1
14	45-0194	OIL DIPSTICK SUBASSY	1
15	80-0060	BOLT-STOPPER BRACKET	2
16	80-0060	BOLT-STOPPER BRACKET	1
17	45-0675	BRACKET- FUEL TANK	1
18	45-0195	SEAL-OIL	1
19	80-0060	BOLT-STOPPER BRACKET	1
20	80-0060	BOLT-STOPPER BRACKET	2
21	45-0606	PLATE-BREATHER GROOVE COVER	1
22	45-0607	GASKET- BREATHER GROOVE	1
23	45-0608	BREATHER RING	1
24	45-0609	STRAINER	1
25	45-0610	SHIELD- CRANKCASE REAR	1

Id	Item #	Description	Quantity
26	45-0611	BALL BEARING	1
27	45-0612	BRACKET- CRANKCASE FRONT	1
28	80-0060	BOLT-STOPPER BRACKET	1
29	45-0613	GOVERNOR ARM	1
30	45-0480	WASHER- GOVERNOR ARM	1
31	45-0614	OIL- SEAL	1
32	45-0328	PIN	1




Crankcase Cover Subassembly



Id	Item #	Description	Quantity
33	45-0196	GASKET- CRANKCASE	1
34	45-0570	PIN	2
35	45-0616	WASHER- CRANKCASE COVER	1
36	45-0617	BLOCK- RETURNING OIL	1
37	80-0060	BOLT- STOPPER BRACKET	1
38	45-0618	GOVERNOR PLATE SPINDLE	1
39	45-0197	SEAL- OIL	1
40	45-0619	BOLT- CRANKCASE	6
41	45-0620	GOVERNOR GEAR ASSY	1
42	45-0621	CRANKCASE COVER	1




Piston Subassembly



Id	Item #	Description	Quantity
43	45-0622	RING- THE FIRST	1
44	45-0623	RING- THE SECOND	1
45	45-0624	RING SET- OIL	1
46	45-0625	PISTON	1
47	45-0350	PISTON- RING	2
48	45-0486	PIN- PISTON	1
49	45-0626	ROD- CONNECTING	1
50	45-0627	CRANKSHAFT ASSY	1




Valve Train//Camshaft Subassembly



Id	Item #	Description	Quantity
51	45-0269	NUT- VALVE LOCK	2
52	45-0271	NUT- VALVE ADJUSTING	2
53	45-0628	RETAINER- VALVE SPRING	2
54	45-0500	VALVE- ROCKER	2
55	45-0501	VALVE- SPRING	2
56	45-0629	GUIDE- SEAL	1
57	45-0270	BOLT- VALVE ADJUSTING	2
58	45-0630	VALVE- INTAKE	1
59	45-0631	LIFTER STOPPER PLATE SUBASSY	1
60	45-0632	VALVE- LIFTER	2
61	45-0633	VALVE- TAPPET	2
62	45-0634	CAMSHAFT ASSY	1
63	45-0635	VALVE- EXHAUST	1




Recoil Starter



Id	Item #	Description	Quantity
64	45-0198	RECOIL STARTER ASSY	1




Shrouds



Id	Item #	Description	Quantity
65	45-0199	ENGINE HOUSING 170CC	1
66	45-0636	SHROUD- INNER	1
67	45-0324	NUT- GOVERNOR SUPPORT	3
68	45-0637	STUD- SHROUD MOUNTING	2
69	45-0638	STUD- LONG- SHROUD MOUNTING	1




Carburetor Assembly



Id	Item #	Description	Quantity
70	45-0200	GASKET- INSULATOR PLATE	1
71	45-0639	PLATE- CARBURETOR INSULATOR	1
72	45-0201	GASKET- CARBURETOR	2
73	45-0640	GASKET- CARBURETOR INSULATOR	1
74	45-0202	CARBURETOR ASSY	1
75	45-0203	GASKET- AIR CLEANER	1




Air Cleaner



Id	Item #	Description	Quantity
76	45-0203	GASKET-AIR CLEANER	1
77	45-0204	BREATHER- TUBE	1
78	45-0324	NUT- AIR CLEANER	2
79	45-0205	AIR CLEANER CASE- 170CC	1
80	45-0206	AIR FILTER ELEMENT- 170CC	1
81	45-0207	AIR CLEANER- CASE COVER	1
82	45-0641	CLIP- AIR CLEANER	1




Muffler Assembly



Id	Item #	Description	Quantity
83	45-0208	OUTTER MUFFLER- COVER 170CC	1
84	45-0209	OUTTER MUFFLER COVER ASSY	1
85	45-0210	EXHAUST PORT GASKET	1
86	80-0060	BOLT- STOPPER BRACKET	3
87	45-0642	BOLT- MUFFLER	2



Fuel Tank Assembly




Id	Item #	Description	Quantity
1	45-0683	FUEL TANK - 170CC	1
2	45-0656	TUBE - FUEL	1
3	45-0643	BOLT	2
4	45-0689	FUEL TANK CHAIN	1
5	45-0690	FUEL TANK CAP - 170CC	1
6	45-0644	STRAINER - FUEL	1
7	45-0645	CLIP - HOSE	1

Id	Item #	Description	Quantity
8	45-0338	CLAMP	1



Flywheel//Impeller/Starter Pulley/Ignition Coil




Id	Item #	Description	Quantity
94	45-0520	NUT- FLYWHEEL	1
95	45-0654	PULLE-STARTER	1
96	45-0655	IMPELLER	1
97	45-0656	FLYWHEEL SUBASSY	1
98	45-0657	BOLT- IGNITION COIL	1
99	80-0060	BOLT- STOPPER BRACKET	1
100	45-0658	SHIELD- FUEL TANK LEFT	1
101	45-0659	WIRE- GROUND	1
102	45-0716	ENGINE SWITCH- 170CC	1

Id	Item #	Description	Quantity
103	45-0213	IGNITION COIL- 170CC	1



Throttle Control Assembly



Id	Item #	Description	Quantity
104	45-0660	ROD- GOVERNOR	1
105	45-0661	SPRING- THROTTLE VALVE RETURN	1
106	45-0662	ROD- CHOKE	1
107	45-0663	THROTTLE CONTROL ASSY	1
108	45-0664	GOVERNOR SUPPORT ASSY	1
109	45-0282	BOLT- GOVERNOR SUPPORT	1
110	45-0324	NUT	1
111	45-0665	SPRING- GOVERNOR	1
112	45-0666	BOLT- GOVERNOR PLATE	1
113	45-0335	CLIP	1