


VCS3500BI/ 5000BI ASSEMBLY DRAWING

50002467
1643



VCS3500 BI/ 5000 BI PARTS LIST

ITEM	DESCRIPTION	No. Req'd.	VCS3500 BI	VCS5000 BI
1	Base Assembly	1	50002039	50002193
2	Ignitor Assembly Kit	1	50000816	50001619
3	Console Assembly	1	50002098	50002120
4	Bottom Cover	1	50001953	50001946
5	Bracket, Right - BI	1	50001947	50001947
6	Fascia Assembly - VCSBI	1	50002106	50002106
7	Cover, Rear	1	50001954	50001949
8	Grease Tray	1	50001955	50001950
9	Front Grease Tray	1	50001956	50001951
10	Lid Assembly, Rear	1	50001279	50001538
11	Front Lip	1	50001482	50001819
12.a	Valve Assembly - LP	1	50002020	50000803
12.b	Valve Assembly - Natural Gas	1	50002006	50000852
13.a	Regulator - LP	1	50000804	50000804
13.b	12' Hose Assembly - Natural Gas	1	50000198	50000198
13.c	Connector Hose - Natural Gas	1	50000915	50000915
14	Bezel	4/6	50001327	50001327
15	Burner Main Assembly - HBQ	3/5	50000835	50000835
16	Electrode Main - Long	2/3	50000523	50000523
17	Electrode Main - Short	1/2	50000431	50000431
18	Gasket Burner - HBQ	3/5	50000892	50000892
19	Flash Tube	1	50001300	50000880
20.a	Tube and Orifice Assembly - LP	1	50001992	50000819
20.b	Tube and Orifice Assembly - Natural Gas	1	50002018	50000818
21	Rotisserie Housing/Screen Assembly	1	50001416	50000961
22	Burner Rotisserie Assembly	1	50000047	50000875
23	Electrode - Rotisserie	1	50000981	50000981
24	Hardware - Lid Set	1	50000355	50000355
25	Lid Assembly, Front	1	50001999	50002116
26	Lid Bumpers	4/6	50000177	50000177
27	Warming Rack, Enamel	1	50001311	50000889
28	Cook Grate - Set	1	50001314	50001227
29	Rotisserie Kit	1	50002102	50002102
30	Spit Rod	1	50001326	50000962
31	Flexible Connector - 28"	1	50000672	50000672
32	Handle, Grip Set - Charcoal	1	50000642	50000642
33	Handle, Door	1	50000313	50000313
34	Knob - H Style	4/6	50001328	50001328
35	Smoke Box Body	1	50001038	50001763
36	Smoke Box Lid	1	50001039	50001039
37	Plate, Heat - H S/S	3/5	50000777	50000777
38	Hardware Bag	1	50002105	50002105

Magnet 50002033
 Logo 50002027