


BJM Pumps RX750SS, RX1500SS



Pos No	Part #	Description	Pos No	Part #	Description
01-2	202006	Bottom Plate	26-1	202633	O-Ring (Kit Only)
05	202061	Impeller	27	201692	Power Cable w/ Gland-115V, 1PH
07	202159	Pump Housing/Suction Cover	27	201691	Power Cable w/ Gland- 230V, 1PH, No Plug
07-1	202633	O-Ring (Kit Only)	27-1	202633	O-Ring (Kit Only)
08	202215	Oil Chamber Cover	27-2	202633	O-Ring (Kit Only)
08-1	202633	O-Ring (Kit Only)	31E	203145	Ground Wire w/Ring Term.
09	202233	Lip Seal FKM	32	203161	Power Cord Line Clip
09	202231	Lip Seal Buna-N (Optional)	34	203169	Handle
09	203053	Lip Seal EPDM (Optional)	35	202666	Rod Bolts
13	204240	Mechanical Seal FKM**	38	202532	Disch. Nipple NPT 2"
13	200501	Mechanical Seal Buna-N (Optional)	38F	202566	Discharge Flange Kit 1-1/2"
14	200958	Lower Ball Bearing	38F	202568	Discharge Flange Kit 2"
15	200481	Impeller Shim Kit (Required)	50-01-2	203220	Screw for Bottom Plate
16	202292	Pump Casing Outer	50-07	203250	Screw for Suction Cover
17	203090	Rotor w/ Shaft 115, 1PH	50-08	203219	Screw for Oil Chamber Cover
17	203090	Rotor w/ Shaft 230, 1PH	50-11	203218	Screw for Oil Fill
18	200513	Stator Coil w/ Casing 115, 1PH	50-11-1	202633	O-Ring (Kit Only)
18	200571	Stator Coil w/ Casing 230, 1PH	50-12	203218	Screw - Pressure Test
19	202360	Governor Switch w/Switch Plate	50-12-1	202633	O-Ring (Kit Only)
20	200967	Upper Ball Bearing	50-16	203220	Screw for Outer Casing
21A	202161	Oil Chamber	50-19	202693	Screw for Gov. Switch Plate
21A-1	202633	O-Ring (Kit Only)	50-23	202700	Screw for Overload
21B	202366	Motor Cover (Upper)	50-27	203216	Screw for Power Cord
23	202383	Overload 115V, 1PH	50-31E	202692	Screw for Ground Wire
23	202395	Overload 230V, 1PH	50-32	203220	Screw for Line Clip
24	202417	Capacitor 115	50-34	203220	Screw for Handle
24	202418	Capacitor 230	50-38N	203182	Acorn Nut for Flange
26	202430	Pump Top Cover	50-38W	202902	Washer for Flange