



Log Set Assembly



IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.

ITEM	DESCRIPTION	COMMENTS	PART NUMBER
	Log Set Assembly		LOGS-550TRSAUD
1	Log #1	No longer available, must order complete assembly	SRV540-704
2	Log #2		SRV347-703
3	Log #3		SRV349-704
4	Log #4		SRV484-703
5	Log #5		SRV550-718
6	Log #6		SRV278-705
7	Log #7		SRV347-701
8	Log #8		SRV550-715
9	Inner Baffle		2021-103
10	Grate		2021-007
11	Base Refractory		SRV550-117
12	Burner Assembly - NG		2021-005
	Burner Assembly - LP		2021-003
13	Glass Door Assembly		GLA-550TRS
14	Dress Guard w/Lower Door		347-180A
15	Hood		SRV550-175
16	Top Louver		550-251A
17	Lower Door		347-181
18	Rheostat		491-510A
19	Temperature Sensor		046-530
20	Junction Box		546-250A
21	Blower Assembly 240v.		GFK-240V
22	Power Cord		546-251A
	Glass Latch Assembly	Pkg of 2	386-122A /2
	Mesh Assembly		561-330A
	Mineral Wool		050-721
	Rheostat Knob		SRV100-512
	Touch-up Paint		TUP-GBK-12
	Vertical Flue Resistor		347-299

#23 Valve Assembly



IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.

ITEM	DESCRIPTION	COMMENTS	PART NUMBER
23.1	Pilot Assembly - NG		2103-010
	Pilot Assembly - LP		2103-011
	Thermocouple		446-511
	Thermopile		2103-512
23.2	Pilot Bracket		530-164
23.3	Valve Bracket		2025-101
23.4	Flex Ball Valve		SRV302-320
23.5	Wire Assembly		049-552A
23.6	Piezo Ignitor		291-513
23.7	ON/OFF Rocker Switch		SRV060-511
23.8	Valve - NG		060-522
	Valve - LP		060-523
23.9	Burner Tube Assembly		530-302A
	Orifice - NG		582-839
	Orifice - LP		582-057
	Conversion Kit-LP		LPK-550TRSAUD
	Pilot Orifice - NG		SRV446-505
	Pilot Orifice - LP		SRV446-517