




REPLACEMENT PARTS/ORDER FORM

Doc # VC200

VC200E

iBuyGrillParts.com
888-634-4289

✓	REF	DESCRIPTION	QTY	PART #
☐	1	BASE ASSY - OBSOLETE	N/A	50000425
☐	2	BRACE LEG END	2	50000236
☐	3	BRACE LEG REAR	1	50000237
☐	4	SHELF FRONT	2	50000738
☐	5	CONSOLE 200	1	50000429
☐	6	BURNER ASSY - Also send a Burner Repair Kit	2	50000038
☐	7A	VALVE ASSY NG - NEEDS TECH APPROVAL	1	50000919
☐	7B	VALVE ASSY LP - NEEDS TECH APPROVAL	1	50000470
☐	8	HEAT PLATES; SET OF 2, NO SINGLE PIECES	1	50000356
☐	9	SHELF SIDE RIGHT	1	50000099
☐	10	END CAP SHELF RIGHT	1	50000441
☐	11	END CAP SHELF LEFT	1	50000442
☐	12	ELECTRODE MAIN SHORT	1	50000431
☐	13	ELECTRODE MAIN LONG	1	50000523
☐	14	BURNER (ROTISSERIE) ASSY	1	50000047
☐	15	ELECTRODE (ROTISSERIE)	1	50000466
☐	16	AXLE	1	50000093
☐	17	SMOKER BOX ASSY	1	50000357
☐	18	FLASH TUBE	1	50000043B
☐	19	DEFLECTOR (OVEN)	1	50000430
☐	20	COOKING GRIDS (SET OF 3 ONLY)	1	VCCG1A
☐	21A	PANEL BASE R CHARCOAL	1	50000130
☐	22	OVEN ELECTRODE	1	50000439
☐	23	IGNITOR KIT (Push button NOT included)	1	50000438
☐	24	CONTROL KNOB	4	50000076
☐	25A	TUBE & ORIFICE ASSY (ROTISSERIE) NG	1	50000456
☐	25B	TUBE & ORIFICE ASSY (ROTISSERIE) LP	1	50000455
☐	26	SHELF SIDE LEFT	1	50000097
☐	27	REAR LID ASSY - Also send p/n 50000355.	1	50000414
☐	28	FRONT LID ASSY - Also send p/n 50000355.	1	50001267
☐	29	PANEL BOTTOM - LP MODEL ONLY	1	50000096
☐	30	PANEL BOTTOM PLAIN - LP MODEL	1	50000095
✓	REF	DESCRIPTION	QTY	PART #
☐		PANEL BOTTOM PLAIN - NG MODEL	2	50000095
☐	31	WHEEL (SET OF 2)	1	50000360

REPLACEMENT PARTS/ORDER FORM

Doc # VC200

VC200E				
☐	32	GREASE CUP HOLDER/CUPS (2)	1	50000361
☐	33	GRIP HANDLE SET	1	50000642
☐	34	TEMPERATURE GAUGE	1	50001643
☐	35	PANEL BASE L CHARCOAL	1	50000129
☐	36	PANEL REAR LOWER - BLACK - SET	2	50000369
☐	37	DOOR FRONT CHARCOAL SET	1	50000363
☐	38	LID BUMPERS (SET OF 6)	1	50000365
☐	39	REGULATOR/O.D. ASSY	1	50000248
☐	40	PIVOT PIN & BOLT SET - Send with lid assy.	1	50000355
☐	41	ROTISSERIE HOUSING/SCREEN ASSY	1	50000746
☐	42	WARMING RACK	1	50000261
☐	44A	TUBE & ORIFICE ASSY (OVEN) - NG	1	50000454
☐	44B	TUBE & ORIFICE ASSY (OVEN) - LP	1	50000453
☐	45	OVEN BURNER ASSY	1	50000433
☐	NS	IGNITOR - PUSH BUTTON	1	50001011
☐	NS	SHELF SUPPORT ASSEMBLY	2	50000230
☐	NS	SUPPORT - ROTISSERIE SPIT ROD	1	50000399
☐	NS	ROTISSERIE SPIT ROD	1	50000286
☐	NS	ROTISSERIE WORK KIT	1	50000287
☐	NS	ROTISSERIE MOTOR BRACKET	1	50000541
☐	NS	ROTISSERIE BRACKET GUIDE	1	50000151
☐	NS	TOOL HOLDER	1	50000504
☐	NS	GREASE PAN	1	50000027
☐	NS	CONSOLE DECAL	1	50000443
☐	NS	ROTISSERIE KIT	1	VCRK1A
☐	NS	BBQ COVER - SALE ITEM	1	VC303-3666
☐	NS	VC BURNER REPAIR KIT	1	50004102

iBuyGrillParts.com

888-634-4289