




GEN-13000-0MSE / GEN-13000-0MSE (sn:40020052-99999999)

FRAME ASSEMBLY



Id	Item #	Description	Quantity
1	27-0121	BOLT	4
2	28-0022	WASHER	8
3	5-0247A01	ISOLATION PLATE	1
4	30-0157	LOCKNUT	25
5	30-0159	LOCKNUT	4
6	850-0355	ENGINE ASSEMBLY - 20 HP HONDA (GEN-12000-0MHE)	1
6	850-0357	ENGINE- 22 HP SUBARU (GEN-13000-0MSE)	1
7	33-0423	EDGING *(THREE FEET REQUIRED)	1
8	20-0851A01	HEAT SHIELD	1
9	28-0003	WASHER	37
10	29-0007	LOCKWASHER	6
11	27-0067	BOLT	14
12	27-9527	BOLT	16
13	27-0117	BOLT	4
14	32-0886	GENERATOR	1

Id	Item #	Description	Quantity
15	29-0112	LOCKWASHER	1
16	28-0005	WASHER	2
17	30-0161	LOCKNUT	1
18	33-0028	VIBRATION PAD	6
19	5-0246A01	ISOLATION PLATE	1
20	29-0110	LOCKWASHER	1
21	27-0168	BOLT	1
22	33-0433	EDGING *(ONE FOOT REQUIRED)	1
23	32-0907	CONDUIT ELBOW	1
24	N/A Sep.	CONTROL BOX ASSEMBLY (SEE EXPLODED DRAWING)	1
25	33-0114	SPIRAL WRAP *(ONE FOOT REQUIRED)	1
26	27-8881	BOLT	13
27	29-1013	LOCKWASHER	13
28	20-0848A01	SIDE PANEL	2
29	N/A	DECAL- DATA PLATE	1
30	34-1817	DECAL- CARB. EMISSIONS	1
31	5-0245A01	FRAME	1
32	28-0002	WASHER	11
33	30-0155	LOCKNUT	4
34	33-0400	PUSH/PULL TOGGLE CLAMP	1
35	30-0004	NUT	1
36	27-9592	BOLT	1
37	30-0152	LOCKNUT	1
38	14-0006	WHEEL	4
39	30-0117	NUT	4
40	34-1720	DECAL- SIDE LOGO	2
41	39-0016	PLUG DRAIN	1
42	12-0179A01	FUEL TANK	1
43	20-0850A01	GAS TANK BRACKET	2
44	20-0849A01	BRAKE BRACKET	1
45	27-0015	BOLT	7
46	27-8807	BOLT	1
47	28-1009	LOCKWASHER	4
48	15-0008	FUEL HOSE *(THREE FEET REQUIRED) (GEN-12000-0MHE)	1
48	15-0008	FUEL HOSE *(ONE FOOT REQUIRED) (GEN-13000-0MSE)	1
49	12-0183	FUEL CAP	1
50	N/A Sep.	DECAL- CAUTION: RISK OF FIRE (SEE 34-9039)	1
51	12-0184	FUEL GAUGE	1
52	24-0009	PLUG	1


Id	Item #	Description	Quantity
53	33-0271	FUEL PICK-UP	1
54	17-0038	QUICK CONNECT PLUG	1
55	17-0018	QUICK CONNECT SOCKET	1
56	42-0004	CLAMP WORM	2
57	20-0264A01	BATTERY RETAINER	1
58	27-0066	SCREW	5
59	33-0092	BATTERY BOX	1
60	33-0004	BATTERY CABLE COVER	1
61	32-0097	TERMINAL RING	3
62	32-0065	CABLE *(TWO FEET REQUIRED)	2
63	32-0744	TERMINAL RING	1
64	32-0058	BATTERY	1
65	20-0847A01	CONTROL PANEL	1
66	N/A Sep.	DECAL- WARNINGS (SEE 34-9039)	1
67	34-1708	DECAL- GEN-12000-0MHE	1
67	34-1707	DECAL- GEN-13000-0MSE	1
68	30-6001	HEX NUT	3
69	20-0845A01	SIDE PANEL BRACKET	6
70	29-0006	LOCKWASHER	3
71	20-0846A01	FRAME BRACKET	3
72	28-0057	WASHER	12
	34-9039	DECAL SET (INC. 50, 66)	

*MUST ORDER IN ONE FOOT LENGTHS



GEN-13000-0MSE / GEN-13000-0MSE (sn:40020052-99999999)

ENGINE ASSEMBLY




Id	Item #	Description	Quantity
1	32-0917	KEY SWITCH	1
2	27-8881	BOLT	3
3	29-1013	LOCKWASHER	3
4	N/A Sep.	DECAL- ON/OFF/START (SEE 34-9039)	1
5	20-0865	SWITCH PANEL	1
6	20-0866	SWITCH BOX	1
7	1-0158	ENGINE- 22HP SUBARU	1
8	45-0118	MUFFLER ASSEMBLY	1
	850-0357	ENGINE ASSEMBLY (INCLUDES 1-8)	
	34-9039	DECAL SET (INC. 4)	



GEN-13000-0MSE / GEN-13000-0MSE (sn:40020052-99999999)

CONTROL BOX ASSEMBLY



Id	Item #	Description	Quantity
1	N/A SEP.	DECAL-OPERATIONS (SEE 34-9039)	1
2	27-8942	BOLT	4
3	32-0912	POWER BLOCK ADDER	1
4	32-0905	POWER BLOCK 3-POLE	1
5	32-0587	LOCKNUT	1
6	20-0836A01	ELECTRIC BOX COVER	1
7	32-0586	STRAIN RELIEF	1
8	20-0835A01	ELECTRIC BOX ASSEMBLY	1
9	32-0907	CONDUIT ELBOW	1
10	32-0908	CONDUIT ELBOW *(TWO FEET REQUIRED)	1
11	30-0155	LOCKNUT	1
12	28-0002	WASHER	2
13	27-8881	BOLT	28
14	29-1013	LOCKWASHER	42

Id	Item #	Description	Quantity
15	20-0797A01	CAPACITOR CLAMP BRACKET	2
16	32-0846	CAPACITOR	2
17	27-0022	BOLT	1
18	32-0896	IDLE DOWN BOARD	1
19	27-0740	BOLT	2
20	32-0834	TOGGLE BREAKER - SP 20A	3
21	20-0837A01	CONTROL PANEL	1
22	30-0152	LOCKNUT	14
23	32-0836	TOGGLE BREAKER - SP 20A	1
24	32-0837	TOGGLE BREAKER - DP 30A	1
25	32-0902	CIRCUIT BREAKER TOGGLE - DP 50A	1
26	27-9574	BOLT	16
27	32-0830	RECEPTACLE - GFCI DUPLEX 20A	3
28	32-0904	RECEPTACLE - L14-50	1
29	32-0831	RECEPTACLE - L14-30	1
30	32-0832	RECEPTACLE - L5-30	1
31	32-0838	VOLT METER	1
32	32-0668	HOUR METER	1
33	32-0626	ROCKER SWITCH	1
34	N/A SEP.	DECAL-CONTROL PANEL (SEE 34-9039)	1
	34-9039	DECAL SET (INC. 34)	