

Part Listings > Radiance RNVD (3233 - 3236 / 3340 - 3349 / 3355 / 3356)

Ref#	Part#	Description	Qty Reqd
1	20004184	GAS LOG SET	1
1a	20004185	LOG - RIGHT REAR	1
1b	20004186	LOG - LEFT REAR	1
1c	20004187	LOG - RIGHT	1
2	20003739	MANIFOLD ASSEMBLY	1
3	57897	LAVA ROCKS - BURNER	1
4	1409112	FRAME ONLY, GLASS - RDV40	1
5	1203702	GASKET, GLASS MEDIUM KNIT - RDV40	7
6	1601290	GLASS, GFP FIREBOX	1
N/S	5003075	GLASS ASSEMBLY W/FRAME & GASKET	1
7a	10001782	VALVE RN HONEYWELL VS8420E 2038 (SERIALS UP TO 2512)	1
7b	10001759	VALVE RP HONEYWELL VS8420E 2020 (SERIALS UP TO 2512)	1
8a	10002389	PILOT ASSEMBLY 3WAY B-VENT RN 0.199.705 (SERIALS UP TO 1456)	1
8b	10002390	PILOT ASSEMBLY 3WAY B-VENT RP 0.199.704 (SERIALS UP TO 1943)	1
8c	10002264	PILOT ASSEMBLY 3WAY N/DV RN 0.199.706 (SERIALS STARTING AT 1457)	1
8d	10002265	PILOT ASSEMBLY 3WAY N/DV RP 0.199.703 (SERIALS STARTING AT 1944)	1
9a	54912	THERMOCOUPLE (SERIALS UP TO N1456,P1943)	1
9b	24D0808	THERMOCOUPLE 24IN (SERIALS STARTING AT N1457,P1944)	1
9b	7531157	THERMOCOUPLE 24IN (SERIALS STARTING AT N1457,P1944)	1
10	10001297	ELECTRODE IGNITER W/CABLE SIT 24IN	1
11	10002385	PILOT HOOD TOP CONVERTIBLE SIT	1
12a	26D0566	THERMOPILE 18IN	1
12a	26D0566	THERMOPILE 18IN	1
13	57886	NUT ELECTRODE SIT 0.974.144	1
14	26D0665	PILOT TUBING W/FITTINGS 1/8IN X 24IN	1
15a	37D0022	ORIFICE PILOT 62 NG - TOP CONVERTIBLE	1
15b	37D0023	ORIFICE PILOT 35 LP - TOP CONVERTIBLE	1
16	20003526	BURNER HOUSING ASSEMBLY	1
17	20003536	BURNER DECORATIVE GRATE	1
18	51866	VENT SAFETY SWITCH [SERIALS UP TO 1456 (RN), 1943 (RP)]	1
19	20005039	VENT SAFETY SWITCH (SERIALS STARTING AT 1457 [RN], 1944 [RP])	1
20	10002582	WIRING HARNESS - FSDV32RN/JDV	1
21	30000874	SWITCH ON/OFF JDV	1
25	30004175K	BLACK WOOD FALLAWAY HANDLE ASSEMBLY	1
26a	20004587	ORIFICE HOOD (.043IN) - FRONT - LP	1
26b	30000449	ORIFICE HOOD (.067IN) - FRONT - NG	1
26c	20000130	ORIFICE HOOD (.055IN) - REAR - LP	1
26d	20004263	ORIFICE HOOD (.098IN) - REAR - NG	1
27	20005259	BRACKET, RIGHT LOG	1
28	20005258	BRACKET, LEFT LOG	1
29	20004286	BASE PAN INNER GASKET	1

30	20003577	BRACKET, BACK LOG -	1
31	1301192	GRILLE, RVF	1
32	1601933	SCREEN, RVF	1
33	30000108	VENT SWITCH WIRE ASSEMBLY - RNV	1
34	30002720	DAMPER STEEL HANDLE/SCREW	1
35	30001249	LATCH, FRONT DOOR - RDV	1
36	30002730	CONTROL DOOR HANDLE ASSEMBLY	1
37	30000069	INTERRUPTER BLOCK FOR VENT SWITCH (SERIALS STARTING AT 1457 [RN], 1944 [RP])	1
38	20005118	DRAFT HOOD FINAL ASSEMBLY (SERIALS STARTING AT 1457 [RN], 1944 [RP])	1
43	20005860	INNER SHROUD GROMMET	1
44a	20010563	VALVE NOVA SIT 820.662 RN (SERIALS STARTING AT 2513)	1
44b	20010645	VALVE NOVA SIT 820.653 RP (SERIALS STARTING AT 2513)	1
45	057958	IGNITER PIEZO W/NUT SIT (SERIALS STARTING AT 2513)	1
46	20010876	BRACKET PIEZO IGNITER SIT (SERIALS STARTING AT 2513)	1
47	20000062	IGNITER PIEZO HONEYWELL (SERIALS UP TO 2512)	1
N/S	0005010	CONVERSION KIT, NG TO LP	1
N/S	0005009	CONVERSION KIT, LP TO NG	1
42	1301235	TOP - CLASSIC BLACK	1
42	30003274	TOP - BISCUIT	1
42	2321235	TOP - BORDEAUX	1
42	30003275	TOP - CHESTNUT BROWN	1
42	30003276	TOP - EBONY	1
42	2311235	TOP - FOREST GREEN	1
42	2371235	TOP - MIDNIGHT BLUE	1
42	1321235	TOP - SAND	1
42	30002513	TOP - SUEDE BROWN	1
42	30003277	TOP - VERMONT CLASSIC GREEN	1
42	30003593	TOP - BRICK BLUE	1
42	30003604	TOP - COOKWARE GRAY	1
42	30003615	TOP - GRANITE GRAY	1
42	30003626	TOP - SAGE GREEN	1
39	30001751	LEFT END - CLASSIC BLACK	1
39	30003239	LEFT END - BISCUIT	1
39	30001771	LEFT END - BORDEAUX	1
39	30003248	LEFT END - CHESTNUT BROWN	1
39	30003257	LEFT END - EBONY	1
39	30001780	LEFT END - FOREST GREEN	1
39	30001777	LEFT END - MIDNIGHT BLUE	1
39	30001774	LEFT END - SAND	1
39	30002512	LEFT END - SUEDE BROWN	1
39	30003271	LEFT END - VERMONT CLASSIC GREEN	1
39	30003587	LEFT END - BRICK BLUE	1
39	30003598	LEFT END - COOKWARE GRAY	1
39	30003609	LEFT END - GRANITE GRAY	1
39	30003620	LEFT END - SAGE GREEN	1
47	30001752	RIGHT END - CLASSIC BLACK	1
47	30003238	RIGHT END - BISCUIT	1
47	30001770	RIGHT END - BORDEAUX	1
47	30003247	RIGHT END - CHESTNUT BROWN	1
47	30003236	RIGHT END - EBONY	1

47	30001779	RIGHT END - FOREST GREEN	1
47	30001776	RIGHT END - MIDNIGHT BLUE	1
47	30001773	RIGHT END - SAND	1
47	30002511	RIGHT END - SUEDE BROWN	1
47	30003266	RIGHT END - VERMONT CLASSIC GREEN	1
47	30003586	RIGHT END - BRICK BLUE	1
47	30003597	RIGHT END - COOKWARE GRAY	1
47	30003608	RIGHT END - GRANITE GRAY	1
47	30003619	RIGHT END - SAGE GREEN	1
23	30001376	FRONT - CLASSIC BLACK	1
23	30003240	FRONT - BISCUIT	1
23	30001416	FRONT - BORDEAUX	1
23	30003249	FRONT - CHESTNUT BROWN	1
23	30003258	FRONT - EBONY	1
23	30001428	FRONT - FOREST GREEN	1
23	30001424	FRONT - MIDNIGHT BLUE	1
23	30001420	FRONT - SAND	1
23	30002514	FRONT - SUEDE BROWN	1
23	30003267	FRONT - VERMONT CLASSIC GREEN	1
23	30003588	FRONT - BRICK BLUE	1
23	30003599	FRONT - COOKWARE GRAY	1
23	30003610	FRONT - GRANITE GRAY	1
23	30003621	FRONT - SAGE GREEN	1
24	30001378	LEFT DOOR - CLASSIC BLACK	1
24	30003242	LEFT DOOR - BISCUIT	1
24	30001418	LEFT DOOR - BORDEAUX	1
24	30003251	LEFT DOOR - CHESTNUT BROWN	1
24	30003260	LEFT DOOR - EBONY	1
24	30001430	LEFT DOOR - FOREST GREEN	1
24	30001426	LEFT DOOR - MIDNIGHT BLUE	1
24	30001422	LEFT DOOR - SAND	1
24	30002516	LEFT DOOR - SUEDE BROWN	1
24	30003269	LEFT DOOR - VERMONT CLASSIC GREEN	1
24	30003590	LEFT DOOR - BRICK BLUE	1
24	30003601	LEFT DOOR - COOKWARE GRAY	1
24	30003612	LEFT DOOR - GRANITE GRAY	1
24	30003623	LEFT DOOR - SAGE GREEN	1
25	30001377	RIGHT DOOR - CLASSIC BLACK	1
25	30003241	RIGHT DOOR - BISCUIT	1
25	30001417	RIGHT DOOR - BORDEAUX	1
25	30003250	RIGHT DOOR - CHESTNUT BROWN	1
25	30003259	RIGHT DOOR - EBONY	1
25	30001429	RIGHT DOOR - FOREST GREEN	1
25	30001425	RIGHT DOOR - MIDNIGHT BLUE	1
25	30001421	RIGHT DOOR - SAND	1
25	30002515	RIGHT DOOR - SUEDE BROWN	1
25	30006268	RIGHT DOOR - VERMONT CLASSIC GREEN	1
25	30003589	RIGHT DOOR - BRICK BLUE	1
25	30003600	RIGHT DOOR - COOKWARE GRAY	1
25	30003611	RIGHT DOOR - GRANITE GRAY	1

25	30003622	RIGHT DOOR - SAGE GREEN	1
26	30001413	CONTROL DOOR - CLASSIC BLACK	1
26	30003243	CONTROL DOOR - BISCUIT	1
26	30001419	CONTROL DOOR - BORDEAUX	1
26	30003252	CONTROL DOOR - CHESTNUT BROWN	1
26	30003261	CONTROL DOOR - EBONY	1
26	30001431	CONTROL DOOR - FOREST GREEN	1
26	30001427	CONTROL DOOR - MIDNIGHT BLUE	1
26	30001423	CONTROL DOOR - SAND	1
26	30002517	CONTROL DOOR - SUEDE BROWN	1
26	30003270	CONTROL DOOR - VERMONT CLASSIC GREEN	1
26	30003591	CONTROL DOOR - BRICK BLUE	1
26	30003602	CONTROL DOOR - COOKWARE GRAY	1
26	30003613	CONTROL DOOR - GRANITE GRAY	1
26	30003624	CONTROL DOOR - SAGE GREEN	1
48	30001753	LEG - CLASSIC BLACK	4
48	30003245	LEG - BISCUIT	4
48	30001772	LEG - BORDEAUX	4
48	30003254	LEG - CHESTNUT BROWN	4
48	30003263	LEG - EBONY	4
48	30001781	LEG - FOREST GREEN	4
48	30001778	LEG - MIDNIGHT BLUE	4
48	30001775	LEG - SAND	4
48	30002518	LEG - SUEDE BROWN	4
48	30003272	LEG - VERMONT CLASSIC GREEN	4
48	30003595	LEG - BRICK BLUE	4
48	30003606	LEG - COOKWARE GRAY	4
48	30003617	LEG - GRANITE GRAY	4
48	30003628	LEG - SAGE GREEN	4
N/S	30003596	FRONT W/DOORS - BRICK BLUE	1
N/S	30003607	FRONT W/DOORS - COOKWARE GRAY	1
N/S	30003618	FRONT W/DOORS - GRANITE GRAY	1
N/S	30003629	FRONT W/DOORS - SAGE GREEN	1
N/S	30001476	FRONT W/DOORS - CLASSIC BLACK	1
N/S	30001477	FRONT W/DOORS - BORDEAUX	1
N/S	30001478	FRONT W/DOORS - SAND	1
N/S	30001479	FRONT W/DOORS - MIDNIGHT BLUE	1
N/S	30001480	FRONT W/DOORS - FOREST GREEN	1
N/S	30002519	FRONT W/DOORS - SUEDE BROWN	1
N/S	30003273	FRONT W/DOORS - VERMONT CLASSIC GREEN	1
N/S	30003264	FRONT W/DOORS - EBONY	1
N/S	30003246	FRONT W/DOORS - BISCUIT	1
N/S	30003255	FRONT W/DOORS - CHESTNUT BROWN	1
N/S	1601924	CABLE, CONTROL DOOR - RDV/RNV/RVF	1
N/S	1201842	SPRING LID/DOOR - BBQ/RDV/RNV/RVF	1
N/S	30001007	BASE II BURNER - RDV/RUV	1
N/S	1601972	LATCH, GLASS FRAME	2
N/S	20004194	SHROUD, REAR - RDV40	1
N/S	20000849	FAN BRACKET - RUV40	1
N/S	30002168	FINISH BAG, DNV UV/SNV UV/PUV	1

N/S	1201985	JUMP RING - WASHER USED ON HINGE PINS FOR ENAMEL STOVES ONLY	2
N/S	1201745	LEG LEVELLER BOLT	4

iBuyFireplaceParts.com 888-634-4289

iBuyFireplaceParts.com

iBuyFireplaceParts.com 888-634-4289