
117
116
122
A
118
RK2T 4 × 10
123
121
RKSW3 × 5 – 4
120
110
128
119
SK3 × 6 – 4
C
A
109
BD4 × 6 – 2
124
103
104
BD4 × 6
BD4 × 6
BD4 × 6
BD4 × 6
B
102
115
C
126
112
111
C
RKSW4 × 5 – 6
117
116
106
A
129
118
RK2T 4 × 10
107
140
RKSW3 × 5-8
114
113
110
105
101
B
SK3 × 6-6
A
109
BD4 × 6

1. Exterior Section/Electrical Equipment Section I

Fig. No.	Parts No.	Parts name	407A	307A	207M	Remarks	Fig. No.	Parts No.	Parts name	407A	307A	207M	Remarks
101	260509	Right side cover	1			260507 2pieces	125	1262-7207	Nylon clamp NK-7N	2	2	2	
	260503	Right side cover		1		260507 2pieces	126	321855	Board stut	4	4		
102	0264-0001	Right side plate	1	1									
	0264-0021	Right side plate			1		128	260902	PF22･23 chip			1	
103	260510	Left side cover	1	1	1	260507 2pieces							
104	0264-0002	Left side plate	1	1			129	260838	Film	1	1	1	
	0264-0022	Left side plate			1								
105	260520	Operation identification plate	1										
	260524	Operation identification plate		1									
106A	260623	Operation panel A'ssy	1			106,107,116-118							
	260624	Operation panel A'ssy		1		106,107,116-118							
106	260539	Operation board mounitng plate	1			260512 8pieces							
	260541	Operation board mounitng plate		1		260512 8pieces	406	260128	Lift return SP	2	2	2	
107	260701	Operation board	1	1									
							140	260614	407A/307A Operation Manual	1	1		
109	260530	UCHIDA identification plate	1	1	1			260615	207M Operation Manual			1	
110	260511	Start identification plate	1	1	1								
111	260518-2	Main board cover	1	1									
112	0260-7180	Control board Ver.204				only for 306A							
	3260-7180	Control board Ver.205	1	1									
113	260750	Harness (large) between	1	1									
114	260751	the operationand control boards	1	1									
116	260513-1	Start key top (orange)	1	1	1								
117	260513-2	Start key top (green)	1	1	1								
118	260514	Setting key top	19	16	5								
119	260518	Right side cover			1	260507 2pieces							
120	260813	Operation identification plate			1								
121A	260625	Operation panel A'ssy			1	116-118, 121, 122, 128							
121	260901	PF22･23KEY board			1								
122	260809	Board support			1	260512 4pieces							
124	260543	Left side cover identification plate	1	1	1								


HS4×6
RKSW6×10
210
229
228
RKWS 4×10
230
RKWS4×6-2
RK4×6W付
125
229
BD3×5
206
RKWS4×6
233
菊座金4
231
204
RKSW3×6
SK3×6
232
207
215
209
HS4×4
211
RKWS4×10
220
RKWS4×18
RKSW4×5
214
221
216
RKWS 3×10
RKSW4×6
RKSW4×10
208
RKWS4×6-2
BD3×5-2
206
RK4×6W付
235
E5
HS4×6
217
RKSW 4×8
223
RKSW4×8
RKWS3×25
222
337
RKSW3×6
A
B
225
218
RKWS4×15
233
RKWS4×6
菊座金4
205
RKSW 3×6
SK3×6
N6
SK 4×8
226
227
RKWS4×8
SK4×8
212
203
213
219
202
201
236
207
234
菊座金4
RKWS4×6
RKSW4×10
224
RKSW4×8
RKWS3×6
RKWS3×15
RKSW4×8

2. Electric Equipment Section II

Fig. No.	Parts No.	Parts name	407A	307A	207M	Remarks	Fig. No.	Parts No.	Parts name	407A	307A	207M	Remarks
201	260120	Rubber leg table	1	1	1		229	260934	115V main motor A'ssy			1	
202	51137	Rubber leg	4	4	4								
203	260915	Powe switch	1	1			230						
204	72806	Power cord for U.S.A.	1	1	1			260931	PF22 transformer120 A'ssy			1	
							231	3260-9360	Inlet A'ssy			1	
							232	260919	Power switch			1	
205	260757	Inlet with harness	1	1			233	20289	Earth mark	1	1	1	
206	8020-0007	Noise filter	1	1	1		234	260763	Paper ejection roller motor harness	1			
207							235	143032	Up and down lever A'ssy	1			143033,143102
	260709	Breaker 2A	1	1	1		236	67034	Canoe clip	2	2	2	
208	260768	Transformer with harness 120V	1	1									
209	260755	Paper feed motor with harness	1	1									
210	260123	Motor plate	1	1	1								
211	260121	Shutter plate A'ssy	1	1		146066,260129							
212	260758	Table 1 control board harness	1	1			125	1262-7207	Nylon clamp NK-7N			4	
213	260759	Table 2 control board harness	1	1			337	250155	Microswitch insulating plate	2	2		
214	260505	Cover switch mounting plate	1	1	1								
215	3264-0044	Main motor A A'ssy	1	1									
216	260113	Photo sensor mounting plate	1	1									
217	260222	Liftting arm	1			260223,260224							
218	260774	Rectifier	1	1									
219	260762	Paper feed table motor harness	1										
220	260917	Safety switch	1	1	1								
221	260778	Built-in photo sensor	1	1									
222	100351	Micro switch	3										
	100346	Micro switch		1	1								
223	260916	One touch bush	3	3	2								
224	260776	One touch bush	1	1									
225	20116	Reinforcing stay	2	2	2								
226	20012	Frame rubber	1	1	1								
227	260775	Cable clamp	3	3									
228	3264-0058	Main motor B A'ssy			1								


RKSW4x12
Assy N4

3. Paper Feed Table Section/Paper Guide Section

Fig. No	Parts No.	Parts name	407A	307A	207M	Remarks
301	0264-0003	Safety cover			1	
302	3264-0084	Lower paper guide A'ssy	1	1		
	3264-0071	Lower paper guide A'ssy			1	※1F-407A/3264-0071
303	3264-0515	Upper paper A'ssy	1	1		※1F-407A/3264-0515
304	3264-0538	Safety cover A'ssy	1	1		0264-0538,0260-9235
305	260301	Photo sensor mounting tray	1	1	1	
306	20222	Guide mounting angle A	6	6	6	
307	0260-0160	Static eliminator bar	1	1	1	
308	0264-0139	Upper paper ejection guide A	1			
309	3264-0074	Separator shaft	1	1	1	※1F-407A/3264-0074
310	0264-0077	Separator holder	1	1	1	※1F-407A/0264-0077
311	0264-0079	Separator center	1	1	1	
312	3264-0082	Separator A'ssy	1	1	1	※1F-407A/3264-0082 0070-6040,0264-0078/0081
313						
314A						
	260629	Auxiliary table A'ssy for U.S.A.	1	1		314,315,322,374,375
314	1280-0214	Auxiliary table A'ssy for U.S.A.	1	1		
	3264-0106	Auxiliary table A'ssy for U.S.A.			1	
315	260261	Slant adjustment plate	1	1	1	
316	20105	Rubber magnet	2	2	2	
317A	20843	Auxiliary paper guide A'ssy	1	1	1	316,317,319,321
317	20103	Auxiliary paper guide (R)	1	1	1	
318A	20844	Auxiliary paper guide (L) A'ssy	1	1	1	316,318,320,321
318	20104	Auxiliary paper guide (L)	1	1	1	
319	20203	Paper holder lever (R) A'ssy	1	1	1	
320	20204	Paper holder lever (L) A'ssy	1	1	1	
321	20034	F roller holder	2	2	2	
322						
	53018	Gauge for paper guide	1	1	1	for U.S.A.
323	260220	Paper feed table shaft	1			
	20069	Paper feed table shaft		1	1	
324	260221	Table lever	1			
325	260255	Table lever angle	1			

Fig. No.	Parts No.	Parts name	407A	307A	207M	Remarks
326	20075	Spring hook	1	2	2	
327	20076	Table SP	1	1	1	
328	260544	Cover switch lever A'ssy			1	
	3264-0527	Cover switch lever A'ssy	1	1		
329	20040	ϕ 6 metal	1	1	1	
330	260215	Paper guide (right)	1	1	1	260217
331	260216	Paper guide (left)	1	1	1	260218
332	260258	Paper guide knob	2	2	2	
333	20099	Brake rubber	1	1	1	
334A						
	260662	Paper feed table A'ssy for U.S.A.	1	1		330-337,341,342, 344-347,380
	260631	Paper feed table A'ssy			1	330～337,365,
334	260208	Paper feed table	1	1		260211
	260837	Paper feed table			1	260211
335	20444	Microswitch	1	1	1	
336	20426	Actuator	1	1	1	
337	250155	Microswitch insulating plate	2	2	2	
338	260213	Paper feed table tray	1	1	1	
339	20071	Paper feed slant adjuster	1	1	1	
340	20100	Slant adjustmen knob	1	1	1	
341	260250	Rack holder	2	2		
342	260251	Rack	2	2		
343	0264-0140	Upper paper ejection guide B		1	1	
344	260212	Paper guide slide guide gear	1	1		
345	260249	Photograph sensor lever	1	1		
346	260214	Paper detection board cover	1	1		
347						
	260706	Paper detection board A'ssy(inch)	1	1		for U.S.A.
348	20041	Separatr SP	1	1	1	
349	220114	Stopper rubber	4	4	4	
350						
	260766	Paper detection board (inch) with harness	1	1		for U.S.A.

Fig. No.	Parts No.	Parts name	407A	307A	207M	Remarks	Fig. No.	Parts No.	図番	Parts name	407A	307A	仕切価格	Remarks
351	20434	Wire sticker	2	2	2				00-0					
352	260912	Paper feed luminous sensor	1	1	1				00-0					
353	260913	Paper feed light-intercepting sensor	1	1	1				00-0					
354	0260-7521	Paper feed photo harness	1	1					00-0					
355	260753	Paper feed photo harness	1	1					00-0					
356	260254	Table lever A'ssy		1	1				00-0					
357A	3280-7023	Paper feed table lever B A'ssy		1	1	357-360,362			00-0					
357	2281-0118	Paper feed table lever B		1	1	20078,1281-0118			00-0					
358	0020-8000	Paper feed table lever holder		1	1				00-0					
359	0264-0112	Table lever guide collar		1	1				00-0					
360	0020-08100	Paper feed table lever SP		1	1				00-0					
									00-0					
362	0020-0800	Paper feed table lever holder		1	1				00-0					
363									00-0					
364	260810	Wire stopper B			1				00-0					
365	260820	Guide			2				00-0					
366	260245	Upper paper guide A			1				00-0					
367									00-0					
	260548	Roller position indication		1	1	for U.S.A.			00-0					
368	260926	Paper feed clutch harness A'ssy			1				00-0					
369	260927	Paper ejection photo sensor harness A'ssy			1				00-0					
370	260925	Paper micro harness A'ssy			1				00-0					
371	1262-7204	Nylon clamp NK-4N	2	2					00-0					
372	100346	Micro switch		1					00-0					
373	20014	ϕ 10 metal	2	2	2				00-0					
374	20189	Sensor cover	1	1	1	for U.S.A.			00-0					
375	20442	Micro photo senser KR1207	1	1	1	for U.S.A.			00-0					
378	7330-5008	Micro photo senser KR866	1	1					00-0					
379	0260-7521	Paper feed photo harness	1	1					00-0					
380	260252	Slide guide collar	4	4					00-0					
									00-0					
									00-0					
									00-0					
									00-0					



4. Drive Unit

Fig. No.	Parts No.	Parts name	407A	307A	207M	Remarks	Fig. No	Parts No.	Parts name	407A	307A	207M	Remarks
401	0264-0039	Bearing holder	4	4	4		436	145414	Sintered metal B-F6-45	2	2	2	
402	260110	Bearing strap	2	2	2		437	0264-0031	Paper ejection pullet center	1	1	1	※1F-407A/0264-0031
403	260108	Lift cam	2	2	2		438	20017	Paper ejection gear	1	1	1	
404	260114	Lift cam spring lever	2	2	2		439	3264-0046	Paper feed gear A'ssy	1	1	1	20054 (2 pieces),0264-0042,0264-0047
405	20029	Holder roller SP	2	2	2								
406	260128	Lift return SP	2	2	2		440	3264-0134	Paper ejection table A'ssy	1	1	1	※1F-407A/3264-0134
407	8260-1310	F roller holder (R)	1	1	1	260118, 260710	441	0264-0141	Paper ejection lower guide	1	1	1	※1F-407A/0264-0141
408	8260-1320	F rolelr holder (L)	1	1	1	260118, 260710	442	260517	Rear cover	1	1	1	
409	260111	Lift cam lever right	1	1	1		443	260518-1	Wire stopper	1	1		
410	260112	Lift cam lever left	1	1	1		444	260309	Paper ejection roller lever	1			
411	260130	cam lever sheet	2	2	2		445	260318	Paper ejection table insulating pla	2	2	2	
412	260311	Paper ejection arm A'ssy	1			260224, 260311,260312	446	20018	Speed reduction gear	2	2	2	
413	3264-0048	Holder roller	2	2	2	51009 2 pieces/※2F-407A/0264-0048	447	20033	Intercepter plate	1	1	1	
414	0264-0049	F roller	1	1	1	※1F-407A/0264-0049	448	0264-0032	Center roller pulley	1	1	1	
415	0264-0043	Center roller	1	1	1	※1F-407A/0264-0043	449	20035	F roller SP	2	2	2	
416	260119	Intercepter	1	1	1		450	260205	Paper feed gear	1	1	1	
417	260126	Intercepter spring	2	2	2		451	145403	Paper feed clutch	1	1	1	
418	70608	Paper feed roller	3	3	3		452	0264-0037	Paper feed puller center	1	1	1	
419	260207	Auxiliary paper feed roller	2	2	2								
420	70601	Paper feed rubber roller	1	1	1		454	260711	Bearing with snap 6900ZNR	2	2	2	
421	145234	Paper feed shaft SP collar	2	2	2		455						
422	145233	Paper feed shaft SP	1	1	1		456						
423	145232	Paper feed bearing	1	1	1		457	146067	Shutter plate boss	1	1	1	
424	260239	Paper feed shaft	1	1	1		458	145417	Sintered metal B-F10-9	2	2	2	
425	0264-0036	Paper ejection shaft	1	1	1		459	3264-0034	Idler pulley for papper feed	1	1	1	0264-0035,0264-0041,20054 (2 pieces)
426	260320	Paper feed conveying belt	2	2	2		460	20014	ϕ 10 metal	2			
427	260302	Lower paper ejection roller	4	4	4		461	3264-0133	Paper Ejection Table	1	1	1	
428	20020	Lower paper ejection roller	1	1	1								
429	260307	Roller moving shaft	1										
430	260308	Paper ejection roller holder	1										
431A	260633	Paper ejection U roller shaft	1	1	1	431,432							
431	260303	Paper ejection U roller shaft	1	1	1								
432	20117	Paper ejection roller	2	2	2		125	1262-7207	Nylon clamp NK-7N	1	1	1	
433	5264-0402	V belt	1	1	1	※1F-407A/5264-0402	236	67034	Canoe clip	2	2	2	
434	0264-0038	1 feed axis angle	1	1	1		306	20222	Guide fitting angle A	2	2	2	
435	260240	Clutch shaft	1	1	1		371	1262-7204	Nylon clamp NK-4N	2	2		

TABLE 1 (407A/307A)



TABLE 2 (407A/307A)



TABLE 2 （207M）



TABLE 1 （207M）



5. Table 1 and 2 Section

Fig. No.	Parts No.	Parts name	407A	307A	207M	Remarks
501A						
	3260-0011	Table 1 A'ssy (for U.S.A.)	1	1		501-505,507-530, 539,540,549,236,371
	3260-0013	Table 1 A'ssy (for U.S.A.)			1	503-505,507-512, 514-516,529,540, 542-544,546-548,236
501	260429	Table 1 cover (upper)	1	1		
502	260430	Table 1 cover (bottom)	1	1		
503	1281-0257	Table 1 (upper)	1	1	1	
504	260402	Lower table 1	1	1		
	260816	Lower table 1			1	
505						
	260449	Inch size 1 folding gauge	1	1	1	for U.S.A.
507A	260641	Table 1 stopper A'ssy	1	1		507-509,549
	260642	Table 2 stopper A'ssy	1	1		507,509,549
	260643	1table stopper A'ssy			1	507-509,548,549
	260644	2table stopper A'ssy			1	507,509,548,549
507	260424	Stopper plate	2	2		260426
	260424	Stopper plate			2	
508	260425	Push plate	1	1	1	
509	260436	Stopper cushion rubber	6	6	6	
510	20431	Glomet bush	2	2	2	
511	20079	Guide push	2	2	2	
512A	260645	Stopper slider A'ssy	2	2		512-515
	260646	Stopper slider A'ssy			2	512,514,515,542,547

Fig. No.	Parts No.	Parts name	407A	307A	207M	Remarks
512	1281-0275	Stopper slider	2	2	2	20136(2pieces)
513	20148	Stopper doc	2	2		
514	20139	Half nut	2	2	2	
515	20149	Halfnut SP	2	2		
	260848	Halfnut SP			2	
516	260406	Table 1 screw	1	1	1	
517A	**0260-6481**	Table 1 photo board harnessA'ssy	1	1		517-519,528,1281-7000
517						
518						
519						
520	260423	Stopper original position LS tray	2	2		
521	20425	Lead micro switch	2	2		
522	260418	Timing belt	4	4		
523	260412	Stopper shatter	2	2		
524	260411	Stopper screw gear	2	2		260454
525	260415	Idler pulley	2	2		
526	260414	Idelr center	2	2		
527	260416	Idler puller washer	2	2		
528	260420					
529	260408	Screw bearing	2	2	2	
530	260428	Table fine adjustment knob (large)	2	2		
531A						
	3260-0012	Table2 A'ssy(for U.S.A.)	1	1		507,509-515,518-535, 537,538,540,550,236,371
	3260-0014	Table 2 A'ssy(for U.S.A.)			1	507,509-512,514,515, 529,533-535,537,540, 542,544-548,555,236

Fig. No.	Parts No.	Parts name	407A	307A	207M	Remarks	Fig. No.	Parts No.	Parts name	407A	307A	207M	仕切価格	Remarks
531A														
531	260431	Table 2 cover up	1	1										
532	260432	Lower table 2 cover	1	1										
533	260403	Upper table 2 cover	1	1	1									
534	260404	Lower table 2	1	1										
	260818	Lower table 2			1									
535														
	260450	Inch size single folding gauge	1	1	1	for U.S.A.								
537	260407	Table 2 screw	1	1	1									
538A	**0260-6591**	Table 2 photo board harness A'ssy	1	1		518,519,528,538,1281-7000								
538														
539	1281-0271	Roller cover	1	1										
540	260447	Fine adjustment knob indication for export	2	2	2									
541														
542	260804	Halfnut lever			2									
543	260806	Table 1 stop plate			1									
544	100710	Hand caution label			2									
545	100707	Roller caution label			3									
546	260835	Fine adjustment knob			2									
547	260808	Halfnut lever collor			2									
548	20155	Fold position indication identification plate			2									
549	260452	Table 1 sheet	2	2										
550	260453	Table 2 sheet	2	2										
236	67034	Canoe cllip	4	4	4									
371	1262-7203	Nylon clump NK-4N	4	4										


704
702
701
703
N3-2
706
SK-3x6-2
N3-2
SK-3x6L-2
705
BD4x6-2

6. Manual Feed Section（Option）

Fig. No	Parts No.	Parts name	407A	307A	207M	Remarks	Fig. No	Parts No.	Parts name	407A	307A	207M	仕切価格	Remarks
701	0264-0537	Cover for MBM, safety cover for manual feed	1											
702	0264-0518	Paper guide for manual feed mounting plate	1											
703	0264-0533	Safety cover lid	1											
704	0264-0519	Paper guide for manual feed (R)	1			0264-0521 mounted								
705	0264-0520	Paper guide for manual feed (L)	1			0264-0521mounted								
706	0260-8200	guide	1											