


PARTS LIST 1 B1728R

GENERAL ASSEMBLY



PARTS LIST 1

B1728R

GENERAL ASSEMBLY

ITEM NO.	PART NO.	DESCRIPTION	QTY.	REMARK
1	31101	WHEEL COVER	2	
2	31102	RETAINING RING, 16MM	2	
3	31103	WHEEL	2	
4	31104	AXLE	1	
5	31105	SHCS, M8x60	3	
6	31106	SHCS, M8x20	1	
7	31107	CLUTCH WHEEL SLEEVE	1	
8	31108	CLUTCH WHEEL SPRING	2	
9	31109	CENTRIFUGAL BLOCK	3	
10	31110	CENTRIFUGAL WHEEL HUB	1	
11	31111	CENTIFUGAL WHEEL	1	
12	31112	BEARING, 6006	1	
13	31113	RETAINING RING, 30MM	1	
14	31114	RETAINING RING, 55MM	1	
15	31115	SPACER	1	
16	31116	HHCS, M8x20	15	
17	31117	WASHER, LOCK, 8MM	21	
18	31118	ENGINE BELT COVER PLATE	1	
19	31119	KEY, 5x5x35	1	
20		ENGINE	1	
21	31121	HHCS, M8x35	4	
22	31122	WASHER, FLAT, 8MM	16	
23	31123	BELT	1	
44	31144	ENGINE BELT COVER	1	
60	31160	SCREW, M6x12	2	
61	31161	SHIELD COVER	1	
62	31162	COVER PLATE	1	
63	31163	GUARD SUPPORT	1	
64	31164	LOCKNUT, M8	4	
65	31165	PRESSING PLATE	1	
66	31166	COVER PLATE	1	
67	31167	HHCS, M8x25	2	
68	31168	HHCS, M12x25	8	
69	31169	WASHER, LOCK, 12MM	8	
70	31170	SHCS, M12x40	2	
71	31171	SHCS, M12x120	6	
72	31172	WASHER, LOCK, 12MM	16	

PARTS LIST 1

B2027R

GENERAL ASSEMBLY - cont.


ITEM NO.	PART NO.	DESCRIPTION	QTY.	REMARK
73	31173	WASHER, FLAT, 12MM	8	
74	31174	HEX NUT, M12	4	
75	31175	BUFFER	4	
76	31176	HHCS,M10x20	1	
77	31177	WASHER, FLAT,10MM	2	
78	31178	BASE PLATE	1	
79	31179	WASHER, 12MM	4	
80	31180	HHCS,MT2x30	4	
130	31230	CLUTCH ASSY	1	INCL ITEMS 7-14
132	31224	HANDLE ASSEMBLY	1	
133	31245	EXCITER ASSEMBLY	1	

BartellParts.com
800-889-0661

PARTS LIST 2

B1728R

HANDLE ASSEMBLY



PARTS LIST 2

B1728R

HANDLE ASSEMBLY - 31224

ITEM NO.	PART NO.	DESCRIPTION	QTY.	REMARK
16	31116	HHCS,M8x20	1	
17	31117	WASHER, LOCK, 8MM	3	
22	31122	WASHER, FLAT, 8MM	2	
64	31164	LOCK NUT, M8	2	
68	31168	HHCS, M12x25	2	
69	31169	WASHER, LOCK, 12MM	2	
81	31181	DECOMPRESSION VALVE	1	
82	31182	ORING, 2.65x18	1	
83	31183	ORING, 2.65x70	1	
84	31184	PIN, 6MMx26	1	
85	31185	ROCKER SHAFT	1	
86	31186	ROCKER	1	
87	31187	PIN, 8MMx30	1	
88	31188	ORING, 1.8x8	2	
89	31189	BEARING, 619/8	2	
90	31190	REOCKER RESTRICTING SLEEVE	1	
91	31191	WAVE WASHER	2	
92	31192	ORING, 2.65x15	2	
93	31193	SUPPORT SLEEVE	2	
94	31194	ORING, 2.65x19	2	
95	31195	SHCS,M12x1.5x8	1	
96	31196	PIN, 10MMx60	1	
97	31197	HYDRAULIC CONTROL BOX	1	
98	31198	ORING, 1.8x6.9	1	
99	31199	RESTRICTING SCREW	1	
100	31200	FORWARD/REVERSE GRIP	1	
101	31201	SHCS, M8x12	1	
102	31202	HANDLE	1	
103	31203	HANDLE SLEEVE	2	
104	31205	HANDRAIL TUBE	1	
105	31206	RUBBER RING	1	
106	31207	SPRING	1	
107	31208	ORING, 2.65x21.2	1	
108	31209	TUBE CONNECTOR	1	
109	31210	NUT, M16	2	
110	31211	WASHER, FLAT, 16MM	2	
111	31212	HANDRAIL SUPPORT PLATE	1	

PARTS LIST 2

B1728R


HANDLE ASSEMBLY - 31224 - cont.

ITEM NO.	PART NO.	DESCRIPTION	QTY.	REMARK
112	31213	WASHER, BELLEVILLE, 16.3	1	
113	31214	HANDRAIL BUMPER RUBBER STICK	2	
114	31215	WASHER, LOCK, 10MM	1	
115	31216	NUT, M10	1	
116	31217	POSITIONING PIN	1	
117	31218	POSITIONING SPRING	1	
118	31219	HANDRAIL LOCKING PLATE	1	
119	31220	PIN, 3MMx18	1	
120	31231	LOCKING GRIP	1	
121	31232	BOLT, M16x145	1	
122	31233	HYDRAULIC HOSE ASSY	1	
123	31234	CYLINDER COVER	1	
124	31235	ORING, 2.65X25	1	
125	31236	SINGLE DIRECTION VALVE	1	
126	31237	HYDRAULIC BOX COVER	1	
127	31238	SHCS, M6x35	4	
128	31239	THROTTLE CABLE	1	
129	31240	THROTTLE LEVER	1	

BartellParts.com
800-889-0661

PARTS LIST 3 B1728R

EXCITER ASSEMBLY - 31245



PARTS LIST 3

B1728R

EXCITER ASSEMBLY - 31245

ITEM NO.	PART NO.	DESCRIPTION	QTY.	REMARK
16	31116	HHCS, M8x20	8	
17	31117	WASHER, LOCK, 8MM	8	
22	31122	WASHER, FLAT, 8MM	8	
24	31124	BEARING, NJ307E	4	
25	31125	RETAINING RING, 35MM	8	
26	31126	BEARING 6807	2	
27	31127	SHCS, M6x30	4	
28	31128	BEARING COVER	1	
29	31129	COMMUTATING GEAR	1	
30	31130	SHCS, M10x1.25x30	4	
31	31131	ECCENTRIC WEIGHT	4	
32	31132	COMMUTATING SHAFT	1	
33	31133	PIN	1	
34	31134	COMMUTATING SLEEVE	1	
35	31135	SHCS, M6x16	4	
36	31136	COMMUTATING POST	1	
37	31137	RETAINING RING, 26MM	1	
38	31138	BEARING, 6000	2	
39	31139	RETAINING RING, 10MM	1	
40	31140	COMMUTATING PISTON	1	
41	31141	OIL SEAL, USH-22.4	1	
42	31142	SHCS, M6x45	5	
43	31143	EXCITER BELT COVER	1	
45	31145	HHCS, M8x30	1	
46	31146	SHIELD SLEEVE	1	
47	31147	DRIVEN PULLEY	1	
48	31148	OIL SEAL 45x28x7	1	
49	31149	COVER, SC45x8x10	1	
50	31150	EXCITER HOUSING	1	
51	31151	ACTUATOR HOUSING	1	
52	31152	END COVER	1	
53	31153	CONNECTOR	1	
54	31154	HHCS, M8x12	1	
55	31155	WASHER, SEALING, 8MM	1	
56	31156	KEY 8MM x 25	1	
57	31157	GEAR SHAFT	1	
58	31158	KEY, 10MMx18	1	
59	31159	DRIVE GEAR	1	

PARTS LIST 4 B1728R

LABELS



BartellParts.com

800-889-0661

ITEM NO.	PART NO.	DESCRIPTION	QTY.	REMARK
A	PC230	WARNING LABEL - HOT BESIDE	1	
B	PC231	WARNING LABEL - HOT BELOW	1	
C	PC140	DANGER LABEL - GENERAL	1	
D	PC110	WARNING LABEL - PPE	1	
E	PC400	WARNING LABEL - FINGER HAZARD	1	
F	109dB	NOTICE LABEL - NOISE	1	
G	PC220	INSTRUCTION LABEL - THROTTLE	1	
H	PC200	INSTRUCTION LABEL - LIFT POINT	1	
J	PC221	INSTRUCTION LABEL - THROTTLE	1	
K	PC211	CAUTION LABEL - READ INSTRUCTIONS	1	