




Ref#	Part#	Description	Qty Reqd
1	0002640	VF25 FIREBOX MANUAL OPERATION NG	1
1	0002641	VF25 FIREBOX MANUAL OPERATION LP	1
1	0002093	VF25T FIREBOX REMOTE OPERATION NG	1
1	0002094	VF25T FIREBOX REMOTE OPERATION LP	1
2	1408857	SIDES/BACK	1
3	1408858	BOTTOM	1
4	1408856	SHEETROCK STOP, LEFT	1
5	1408861	SHEETROCK STOP, RIGHT	1
6	1408860	STANDOFF, TOP (2)	2
7	1408859	FIREPLACE SUPPORT SHELF (2)	2

8	1301091	BRICK EXTENSION, RIGHT	1
9	1301092	BRICK EXTENSION, LEFT	1
10	1301120	LINTEL/LOUVER	1
11	1301119	CONTROL DOOR	1
12	1202470	WASHER (2)	2
13	1200900	1/4-20 X 3/4IN PHILLIPS SCREW (2)	2
14	1601488	DAMPER TAB (6)	6
15	1200993	1/4-20 X 3/8IN PHILLIPS SCREW (6)	6
16	1201846	COMPRESSION SPRING (2)	2
17	1408886	BACK BRACKET	1
N/S	1202058	10 X 1/2IN SMS (45)	45
N/S	1202527	1/4 FENDER WASHER	6
N/S	1408862	BACK COVER PLATE	1
N/S	1301082	BASE	1
N/S	1301081	FIREBOX	1
N/S	0005899	COMPLETE BURNER & LOG ASSEMBLY MANUAL NG	1
N/S	0005900	COMPLETE BURNER & LOG ASSEMBLY MANUAL LP	1
N/S	0005923	COMPLETE BURNER & LOG ASSEMBLY REMOTE NG	1
N/S	0005924	COMPLETE BURNER & LOG ASSEMBLY REMOTE LP	1
N/S	1408851	SCREEN	1
N/S	2003027	MANUAL	1
N/S	1601801	INJECTOR TUBE ASSEMBLY MANUAL ASSEMBLY	1
N/S	1601794	ODS PILOT ASSEMBLY NG OP 8202 MN	1
N/S	1601795	ODS PILOT ASSEMBLY LP OP 8402 MP	1
N/S	1601663	ODS PILOT ASSEMBLY NG ROBERTSHAW MN	1
N/S	1601667	ODS PILOT ASSEMBLY LP ROBERTSHAW MP	1
N/S	1601898	PILOT TUBING NG	1
N/S	1601899	PILOT TUBING LP	1
N/S	1601789	MAXITROL VALVE LP	1
N/S	1601788	MAXITROL VALVE NG	1
N/S	1601657	ROBERTSHAW VALVE NG	1
N/S	1601658	ROBERTSHAW VALVE LP	1
N/S	1409081	FRONT LOG	1
N/S	1409082	BACK LOG	1
N/S	1409076	BURNER ASSEMBLY	1
N/S	1601665	INJECTOR TUBE ASSEMBLY	1
N/S	1601792	ODS PILOT ASSEMBLY RN OP 8209 RN	1
N/S	1601793	ODS PILOT ASSEMBLY RP OP 8409 RP	1
N/S	1601800	PILOT TUBING	1
N/S	1601304	PIEZO IGNITER	1
N/S	1601661	IGNITER CABLE	1
N/S	1601790	VALVE UV ROBERTSHAW 70000MVRB4LC NG	1
N/S	1601791	VALVE UV ROBERTSHAW 70000MVRB4LPLC LP	1