




IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.



**Stocked
at Depot**

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	
1	Face, Top Front (overlay only)	No longer available	24009	
2	Face, Upper Front (overlay only)	No longer available	12125E	
3	Smokeshield	No longer available	16759D	
4	Firescreen Assembly - Qty. 2 req.	Pre 25/92	11855A	Y
		Post 25/92	12267	Y
5	Refractory, Side - Qty. 2 req.	Pre 26/91	11821A	
		26/91 thru 25/92	16757	
		Post 25/92	17180A	
6	Refractory, Back	Pre 26/91	11819A	
		26/91 thru 25/92	16755A	
		Post 25/92	17177B	
7	Grate		GR41	Y
8	Face, Bottom Front (overlay only)	No longer available	23922A	
9	Face, Lower Front (overlay only)		4012-109	
10	Refractory, Hearth	Pre 25/92	11822A	
		Post 25/92	17174B	
	Ashlip Ceramic	No longer available	11820A	
	Ashlip Metal	No longer available	16762A	
	Damper Repair Kit		SRV32828	Y
	Firescreen Hairpin Clip	Pkg of 24	101025/24	Y
	Firescreen Rod	Qty. 2 req.	SRV11866	Y
	Smoke Baffle	No longer available	14078B	
	Smokeshield Extended	No longer available	12830A	
	Installation Instructions & Owner's Manual		12955	