




Ref#	Part#	Description	Qty Reqd
1	50001578	LOWER CABINET ASSEMBLY	1
2	50001524	CABINET END PANEL LEFT	1

iBuyGrillParts.com
888-634-4289

3	50001525B	CABINET END PANEL RIGHT	1
4	50000789	CABINET UPPER PANEL	1
5	50001372	CABINET REAR PANEL RIGHT	1
6	50001376	DOOR ASSEMBLY LEFT	1
7	50001389	DOOR ASSEMBLY RIGHT	1
8	50000797	DRAWER SUPPORT RIGHT	1
9	50000798	DRAWER SUPPORT LEFT	1
10	50001041	CABINET SLIDE, RIGHT	1
11	50001043	CABINET SLIDE, LEFT	1
12	50001174	BASE ASSEMBLY	1
13	50000857B	HEAT SHIELD	1
14	50001393	REAR LID ASSEMBLY (REQUIRES PART 50000355)	1
15	50001585	ROTISSERIE HOUSING/SCREEN ASSEMBLY	1
16	50001388	FRONT LID ASSEMBLY (REQUIRES PART 50000355)	1
17	50001541	TANK TRAY ASSEMBLY	1
18	50001548	UPPER REAR PANEL - S/S	1
19	50001540	CONSOLE ASSEMBLY	1
20	50000779B	FRONT LIP	1
21	50000892	BURNER GASKET	5
22	50003133K	BURNER ASSEMBLY - INCLUDES ELECTRODE AND WIRE	5
23	50001549	DRAWER ASSEMBLY	1
24	50001418	SHELF SUPPORT BLACK	1
25	50001419	SHELF SUPPORT BLACK	1
26	50000984	FRONT SHELF RIGHT	1
27	50001558B	SIDE SHELF RIGHT	1
28	50000120	COVER - SIDE BURNER	1
29	50001551B	TOWEL MOUNT PLATE	1
30	50001412B	TOP SHELF	1
31	50001550B	TOWEL COVER	1
32	50001552	TOWEL BAR	1
33	50001532	SIDE TRAY	1
35	50001594	WARMING RACK (ENAMEL)	1
36	50000355	PIVOT PIN & BOLT SET - SEND WITH LID ASSEMBLY	1
37	50000880B	FLASH TUBE	1
38	50001619	IGNITOR MODULE- PUSHBUTTON NOT INCL. (ON OLDER VC GRILLS SOME MODIFICATION MAY BE REQUIRED TO MOUNT)	1
39	50001014	IGNITOR WIRE 10 POSITIVE	1
40	50001015	IGNITOR WIRE 10 NEGATIVE	1
41	50000431	ELECTRODE MAIN SHORT	2
42	91D0108	ELECTRODE WIRE MAIN LONG, NEED 91D0107 FOR ELECTRODE	3
42a	91D0107	ELECTRODE ONLY - MAIN	2
43	50002788	IGNITOR PUSH BUTTON	1
44	50000823	GREASE PAN ASSEMBLY	1
45A	50000803	VALVE ASSEMBLY (LP)	1
45B	50000852	VALVE ASSEMBLY (NG)	1
46A	50000804	REGULATOR ASSEMBLY (LP)	1
46B	50000198	HOSE NG - 12 FT	1
47	50000365	LID BUMPERS (SET OF 6)	1
48	50000875	ROTISSERIE BURNER ASSEMBLY	1
49	50000981	ROTISSERIE ELECTRODE	1
50A	50000819	TUBE & ORIFICE ASSEMBLY (LP)	1
50B	50000818	TUBE & ORIFICE ASSEMBLY (NG)	1
51	50000962	ROTISSERIE SPIT ROD 38	1
52	50001327	KNOB BEZEL	6
53	50000156	COOK GRATE - SINGLE APPROX 16 X 9	4
54	50000842	GRIP HANDLE SET	1
55	50001570	ROTISSERIE PART KIT	1
56	50003003	CONTROL KNOB	6
57	50001038B	SMOKER BOX (LID NOT INCLUDED)	1
58	50001039B	SMOKER BOX LID	1
59	50000777	HEAT PLATE - SS	5
60A	50001443	SIDE BURNER SUB-ASSEMBLY(LP)	1
60B	50001296	SIDE BURNER SUB-ASSEMBLY (NG)	1
61	50000809	CASTER (THREADED)	4
62	50000882	HARDWARE BAG	1
63	50000126	GREASE CUP	1
64	50000313	DOOR HANDLE	1

iBuyGrillParts.com
888-634-4289