

1128759

MEWP CING IM R15 DA RC 110V/60HZ

CRIMR15DA_1128759_R02W - R02W (1/3/2024)



Access Platform Division

Via San Francesco d'Assisi, 8 - 46020 Pegognaga (Mantova) - ITALY Tel. +39 0376
554011 - Fax +39 0376 559855

www.imergroup.com


Building Equipment Division

Via della Meccanica, 39 (Zona Industriale Sentino) - 53040 Rapolano Terme
(Siena) - ITALY - Tel. +39 0577 97341 - Fax +39 0577 704077

www.imergroup.com

www.imerglobalcustomercare.com


BASE CARRIAGE





N.	CODE	DESCRIPTION	UM	QTY
1	86402030	TURRET	PZ	1.0
2	010390	SCREW	PZ	4.0
3	012379	WASHER	PZ	4.0
4	019125	SCREW	PZ	11.0
5	85411166	DISTANCE BEARING	PZ	26.0
6	86402033	COLLAR	PZ	1.0
7	86402034	COLLAR	PZ	1.0
8	040382	SCREW	PZ	1.0
9	86402036	SUPPORT	PZ	3.0
10	040447	MICRO SWITCH	PZ	3.0
11	018933	SCREW	PZ	15.0
12	86401030	CHASSIS	PZ	1.0
13	86401052	COVER	PZ	2.0
14	85501111		PZ	2.0
15	026183	HANDLE	PZ	4.0
16	040412	THUMB SCREW	PZ	4.0


UNDER CARRIAGE





N.	CODE	DESCRIPTION	UM	QTY
1	854012577021		PZ	1.0
2	854012607021		PZ	1.0
3	854010697021		PZ	1.0
4	854012497021		PZ	1.0
5	854012517021		PZ	1.0
6	854012477021		PZ	1.0
7	854012537021		PZ	1.0
8	85401106		PZ	4.0
9	85412017		PZ	1.0
10	85501080	PIVOT	PZ	2.0
11	0402687021	CYLINDER + IDLER WHEEL RAL7021	PZ	2.0
12	0402697021		PZ	6.0
13	85501242		PZ	2.0
14	0404617021	GEARMOTOR PAINTED	PZ	2.0
15	854011417021		PZ	2.0
16	040383	TRACK	PZ	2.0
17	040537	TRACK RUBBER	PZ	2.0
18	854012627021		PZ	1.0
19	854012637021		PZ	1.0
20	0414007021	GEARMOTOR PAINTED RAL7021	PZ	2.0

STABILISER






N.	CODE	DESCRIPTION	UM	QTY
1	86401040		PZ	1.0
2	85401001	FOOT D.200	PZ	1.0
3	85501200	DISTANCE BEARING	PZ	1.0
4	85501097	SEMI-FIXING PLATE	PZ	2.0
5	86401051	PIN	PZ	1.0
6	019106	LOCKNUT	PZ	1.0
7	86401045	PROTECTION	PZ	1.0
8	85501223	SLIDING BLOCK	PZ	1.0
9	040400	MAGNET	PZ	2.0
10	86412001	CYLINDER	PZ	1.0
11	025203	BUSHING	PZ	6.0
12	86405038	STABILIZER BLOCK	PZ	1.0
13	864010877021	COVER FOR STAB. BLOCK, PAINTED	PZ	1.0
14	040480	PUFFER	PZ	1.0
15	041342	BUMPER	PZ	1.0
16	86401044	PIN	PZ	1.0
17	018489	WASHER	PZ	4.0
18	025906	LOCK NUT	PZ	4.0
19	86401042	PIN	PZ	2.0
20	86411085	BLOCK	PZ	2.0
21	040361	MICROSWITCH	PZ	1.0



N.	CODE	DESCRIPTION	UM	QTY
22	86101098		PZ	1.0
23	85501219		PZ	1.0
24	86401128	OUTRIGGER PLATE		1.0

RIGHT SIDE - PETROL






N.	CODE	DESCRIPTION	UM	QTY
1	040284	MOTOR	PZ	1.0
2	041475	CAMPANA GX390 + GR2 >		1.0
3	041450	PUMP		1.0
4	027740	SWITCH	PZ	1.0
5	026549	ACCELERATOR ELECTROMAGNET	PZ	1.0
6	85501164	MOTOR SUPPORT	PZ	1.0
7	855010857021		PZ	1.0
8	040263	DAMPING PAD	PZ	4.0
9	85501214		PZ	1.0
10	040448	CAP	PZ	2.0
11	85501281	COVER FOR MOTOR	PZ	1.0
12	027065	HANDLE	PZ	2.0
13	040302	HINGE	PZ	2.0
14	040382	SCREW	PZ	1.0
15	040245	MOTOR	PZ	1.0
16	86401056	SUPPORT	PZ	1.0
17	041579	HYDRAULIC BLOCK	PZ	1.0
18	041598	PRESSURE SENSOR	PZ	2.0
19	040377	WIRE	PZ	1.0
20	85501232	COMPASS FOR MAGNET	PZ	1.0
21	82801137	COMPASS FOR MAGNET	PZ	1.0



N.	CODE	DESCRIPTION	UM	QTY
22	040378	WIRE	PZ	1.0
23	026568	SPRING	PZ	1.0
24	026391	LOCK	PZ	1.0
25	010983	SCREW	PZ	1.0
26	040444	WASHER	PZ	1.0
27	040443	SPACER	PZ	1.0
28	85501233		PZ	1.0


PETROL ENGINE





N.	CODE	DESCRIPTION	UM	QTY
1	040284	MOTOR	PZ	1.0
2	041028	FILTER	PZ	1.0
3	040621	REGULATOR	PZ	1.0
4	041343	PETROL FILTER + O-RING	PZ	1.0
5	041344	ENGINE SPARK PLUG	PZ	1.0
6	85506034		PZ	1.0
7	040319	ELECTROMAGNET	PZ	1.0
8	040937	DEFLECTOR	PZ	1.0

LEFT SIDE - TANK






N.	CODE	DESCRIPTION	UM	QTY
1	862011077021		PZ	1.0
2	86201274	TANK COVER	PZ	1.0
3	026084	LOBE HANDWHEEL	PZ	1.0
4	862012737021	SUPERIOR COVER FOR OIL TANK, RAL7021	PZ	1.0
5	040412	THUMB SCREW	PZ	2.0
6	86401082	COVER FOR ELEC. MOTOR	PZ	1.0
7	040742	MOTOR	PZ	1.0
8	040789	MOTOR	PZ	1.0
9	040793	PUMP	PZ	1.0
10	040419	POFFER	PZ	1.0
11	041036	RECEIVER	PZ	1.0
12	041014	PUMP	PZ	1.0
13	040264	MAGNETIC CAP	PZ	1.0
14	040265	FUEL LEVEL GAUGE	PZ	1.0
15	862012727021	OIL FILTER COVER,RAL 7021	PZ	1.0
16	79502016	LEVER CLIP	PZ	2.0
17	79502017	LEVER	PZ	1.0
18	86401054	SUPPORT	PZ	1.0
19	041226	MAIN HYDRAULIC BLOCK	PZ	1.0
20	86101081	SEAL FOR OIL TANK COVER	PZ	1.0
21	86101168		PZ	1.0



N.	CODE	DESCRIPTION	UM	QTY
22	024737	OIL LEVEL	PZ	1.0
23	041090	HYDR. OIL FILTER COMPLETE	PZ	1.0
24	041535	HYDR. OIL CARTRIDGE	PZ	1.0
25	040728	CAPTEUR	PZ	1.0
26	027380	PRESSURE-GAUGE	PZ	1.0
27	040337	SWITCH BOX	PZ	1.0
28	040736	COVER	PZ	1.0
29	041058	CONNECTOR	PZ	1.0
30	040738	MAGNET	PZ	2.0
31	041063	RELAY	PZ	1.0
32	86401091		PZ	1.0


HYDRAULIC BLOCKS





N.	CODE	DESCRIPTION	UM	QTY
1	041579	HYDRAULIC BLOCK	PZ	1.0
2	041226	MAIN HYDRAULIC BLOCK	PZ	1.0
3	041225	DISTRIBUTOR	PZ	2.0
4	041569	VALVE	PZ	4.0
5	041570	VALVE	PZ	5.0
6	041560	COIL	PZ	16.0
7	041567	VALVE	PZ	2.0
8	041566	VALVE	PZ	1.0
9	041568	COIL	PZ	3.0
10	041605	MAX. VALVE	PZ	2.0
11	041606	COIL FOR 041605	PZ	2.0
12	041789	PROPORTIONAL VALVE	PZ	2.0
13	041606	COIL FOR 041605	PZ	2.0
14	041607	MAX. VALVE	PZ	2.0
15	041608	COIL FOR 041607	PZ	2.0
16	041908	NUT M16X1 ES. CH24		16.0

RIGHT SIDE - ELEC. COMP.








N.	CODE	DESCRIPTION	UM	QTY
1	86401082	COVER FOR ELEC. MOTOR	PZ	1.0
2	85503134		PZ	1.0
3	040829	HINGE	PZ	1.0
4	85503135		PZ	1.0
5	025887	LOCK	PZ	1.0
6	040429	BATTERY CHARGER	PZ	1.0
7	040428	BATTERY	PZ	1.0
8	862011077021		PZ	1.0
9	040703	GEL BATTERY NON DANG.	PZ	1.0
10	040578	CASE	PZ	1.0
11	040576	CONTACTOR	PZ	1.0
12	041109		PZ	1.0
13	040472	RECTIFIER	PZ	1.0
14	040569	SWITCH	PZ	1.0
15	025325	FUSE CARRIER	PZ	2.0
16	040359	FUSE	PZ	2.0
17	040340	ELECTRIC CONTROL UNIT	PZ	1.0
18	026413	FUSE CARRIER BOX	PZ	1.0
19	040423	FUSE	PZ	1.0
20	026212	FUSE	PZ	1.0
21	041072	CONTROL UNIT HY-TTC510	PZ	1.0



N.	CODE	DESCRIPTION	UM	QTY
22	026084	LOBE HANDWHEEL	PZ	1.0
23	86201319	PIVOT	PZ	1.0
24	86401059	SUPPORT	PZ	1.0
25	86406010	LOWER CONTROL PANEL	PZ	1.0
26	040346	GLASS FUSE	PZ	1.0
27	040345	FUSE CARRIER	PZ	1.0
28	041943	SEAL	M	1.0
29	862013227021	CARTER RAL7021	PZ	1.0
30	041671	INCLINOMETER	PZ	1.0
31	85801061	INCLINOMETER PLATE	PZ	1.0
32	040384	INCLINOMETER	PZ	1.0
33	85506039	EMERGENCY PUMP BOX	PZ	1.0
34	040301	ELECTROPUMP	PZ	1.0


GROUND CONTROL PANEL





N.	CODE	DESCRIPTION	UM	QTY
1	85506001	LABEL	PZ	1.0
2	85506004		PZ	1.0
3	025178	JUNCTION BOX	PZ	4.0
4	040938	KEY SELECTOR	PZ	1.0
5	026121	CONTACT	PZ	1.0
6	027240	CONTACT	PZ	4.0
7	026735	PUSH-BUTTON	PZ	1.0
8	024695	SWITCH	PZ	7.0
9	026741	BUTTON	PZ	3.0
10	040320	GREEN BUTTON	PZ	1.0
11	041283	GREEN SPY 12V	PZ	2.0
12	041284	RED SPY 12V	PZ	2.0
13	040323	AUDIBLE WARNING DEVICE	PZ	1.0
14	040324	RELAY	PZ	3.0
15	040325	RELAY	PZ	2.0
16	040326		PZ	1.0
17	040327	CLAMPING STRIP	PZ	68.0
18	040328		PZ	4.0
19	040329		PZ	4.0
20	040698	CLAMPING STRIP	PZ	4.0
21	041245	KEY	PZ	1.0

TURRET AND FIRST PANTOGRAPH






N.	CODE	DESCRIPTION	UM	QTY
1	86411042	PANTOGRAPH	PZ	1.0
2	025830	BUSHING	PZ	8.0
3	86402027	PIN	PZ	2.0
4	86411085	BLOCK	PZ	5.0
5	012385	WASHER	PZ	5.0
6	019077	LOCKNUT	PZ	5.0
7	86412002	CYLINDER	PZ	1.0
8	041233	VALVE	PZ	1.0
9	86411046	PIN	PZ	1.0
10	86402035	HYDRAULIC BLOCK COVER	PZ	2.0
11	86411004	TIE ROD	PZ	2.0
12	025206	WASHER	PZ	8.0
13	86402025	PIN	PZ	2.0
14	86402030	TURRET	PZ	1.0
15	86402040	TURRET PAD	PZ	2.0
16	040449	MICRO SWITCH	PZ	2.0
17	82801097	SLIDING BLOCK	PZ	2.0
18	86402023	SLIDING BLOCK	PZ	4.0
19	041225	DISTRIBUTOR	PZ	2.0
20	86402033	COLLAR	PZ	1.0
21	86402034	COLLAR	PZ	1.0



N.	CODE	DESCRIPTION	UM	QTY
22	041796	DOCUMENT BOX		1.0
23	041274	HYDRAULIC EMERGENCY KIT	PZ	2.0
24	041679	FORK WRENCH	PZ	1.0
25	040525	FORK WRENCH	PZ	2.0

FIRST KNEE (REAR VIEW)






N.	CODE	DESCRIPTION	UM	QTY
1	864110217021	UPRIGHT	PZ	1.0
2	864112277021		PZ	1.0
3	041267	PHOTOCELL	PZ	1.0
4	864112187021		PZ	1.0
5	041269	SENSOR	PZ	1.0
6	864112047021	COVER RAL7021	PZ	1.0
7	864110517021	SAFETY SUPPORT	PZ	1.0
8	024513	BUSHING	PZ	2.0
9	025203	BUSHING	PZ	2.0
10	86411044	PIN	PZ	1.0
11	012385	WASHER	PZ	5.0
12	012146	SNAP RING	PZ	2.0
13	86411042	PANTOGRAPH	PZ	1.0
14	025830	BUSHING	PZ	2.0
15	86411029	PIN	PZ	1.0
16	019077	LOCKNUT	PZ	3.0
17	86411085	BLOCK	PZ	3.0
18	86411004	TIE ROD	PZ	2.0
19	025206	WASHER	PZ	4.0
20	86411027	PIN	PZ	2.0
21	86411248	PROTEZIONE SENSORE PRESENZA R15		1.0



N.	CODE	DESCRIPTION	UM	QTY
22	041832	FEMALE CONNECTOR 4P HTP M8	PZ	1.0


FIRST KNEE (INTERNAL VIEW)





N.	CODE	DESCRIPTION	UM	QTY
1	864110217021	UPRIGHT	PZ	1.0
2	864112247021	BOOM SUPPORT RAL7021	PZ	1.0
3	854111146		PZ	1.0
4	86411025	PIN	PZ	4.0
5	86411085	BLOCK	PZ	4.0
6	012385	WASHER	PZ	4.0
7	019077	LOCKNUT	PZ	4.0


SECOND PANTOGRAPH





N.	CODE	DESCRIPTION	UM	QTY
1	86411060	PANTOGRAPH	PZ	1.0
2	86402022	SLIDING BLOCK	PZ	2.0
3	86411203	CABLE GUIDE	PZ	1.0
4	025206	WASHER	PZ	12.0
5	025203	BUSHING	PZ	6.0
6	025350	BUSHING	PZ	4.0
7	864110517021	SAFETY SUPPORT	PZ	1.0
8	024513	BUSHING	PZ	2.0
9	86411023	PIN	PZ	1.0
10	018489	WASHER	PZ	1.0
11	025906	LOCK NUT	PZ	1.0
12	86411085	BLOCK	PZ	1.0
13	86411031	TIE ROD	PZ	2.0


SECOND KNEE





N.	CODE	DESCRIPTION	UM	QTY
1	864110907021	UPRIGHT	PZ	1.0
2	85401152	DISTANCE BEARING	PZ	2.0
3	041234	VALVE	PZ	1.0
4	864111987021	COVER RAL7021	PZ	1.0
5	86411107	BUSHING	PZ	1.0
6	86411087	PIN	PZ	1.0
7	86411085	BLOCK	PZ	5.0
8	019077	LOCKNUT	PZ	4.0
9	012385	WASHER	PZ	4.0
10	86412004	CYLINDER	PZ	1.0
11	024327	WASHER	PZ	4.0
12	86411083	PIN	PZ	1.0
13	012381	WASHER	PZ	1.0
14	040510	NUT	PZ	1.0
15	86412003	CYLINDER	PZ	1.0
16	86411079	PIN	PZ	1.0
17	86411031	TIE ROD	PZ	2.0
18	025206	WASHER	PZ	4.0
19	86411089	PIN	PZ	2.0


ARM





N.	CODE	DESCRIPTION	UM	QTY
1	86411207	BOOM	PZ	1.0
2	86411108	SLIDING BLOCK	PZ	1.0
3	86411109	SLIDING BLOCK	PZ	6.0
4	86411221		PZ	2.0
5	86411220	PIN	PZ	2.0
6	86412007	CYLINDER	PZ	1.0
7	041233	VALVE	PZ	2.0
8	018936	BAR	PZ	1.0
9	025830	BUSHING	PZ	2.0
10	86411111	PIN	PZ	1.0
11	012381	WASHER	PZ	1.0
12	040510	NUT	PZ	1.0
13	86411085	BLOCK	PZ	2.0
14	86412004	CYLINDER	PZ	1.0
15	024327	WASHER	PZ	4.0
16	86412003	CYLINDER	PZ	1.0
17	025350	BUSHING	PZ	2.0
18	025830	BUSHING	PZ	2.0
19	86411113	PIN	PZ	1.0
20	012385	WASHER	PZ	1.0
21	019077	LOCKNUT	PZ	1.0

TELESCOPIC EXTENSION






N.	CODE	DESCRIPTION	UM	QTY
1	86411211	EXTRACTION	PZ	1.0
2	024512	BUSHING	PZ	2.0
3	024513	BUSHING	PZ	2.0
4	86411132	SLIDING BLOCK	PZ	2.0
5	86411133	SLIDING BLOCK	PZ	2.0
6	027542	BUSHING	PZ	1.0
7	86412007	CYLINDER	PZ	1.0
8	041233	VALVE	PZ	1.0
9	86411130	PIN	PZ	1.0
10	012141	SNAP RING	PZ	2.0
11	86412005	CYLINDER	PZ	1.0
12	86411156	PIN	PZ	1.0
13	86411085	BLOCK	PZ	2.0
14	018489	WASHER	PZ	2.0
15	025906	LOCK NUT	PZ	2.0
16	86411149	PIN	PZ	1.0
17	86411210		PZ	1.0
18	018936	BAR	PZ	1.0
19	040484	BUSHING	PZ	2.0
20	86411230		PZ	1.0
21	86411231	PAD	PZ	1.0



N.	CODE	DESCRIPTION	UM	QTY
22	041121	CABLE CHAIN	PZ	1.0
23	86411232	PAD	PZ	1.0
24	86411216		PZ	1.0

JIB






N.	CODE	DESCRIPTION	UM	QTY
1	86411152	FRAME	PZ	1.0
2	024327	WASHER	PZ	4.0
3	86412006	CYLINDER	PZ	1.0
4	041339	BALANCE VALVE	PZ	1.0
5	86411149	PIN	PZ	1.0
6	86411085	BLOCK	PZ	5.0
7	018489	WASHER	PZ	2.0
8	025906	LOCK NUT	PZ	2.0
9	86412005	CYLINDER	PZ	1.0
10	025203	BUSHING	PZ	2.0
11	024327	WASHER	PZ	2.0
12	041233	VALVE	PZ	1.0
13	86411151	PIN	PZ	1.0
14	040510	NUT	PZ	3.0
15	012381	WASHER	PZ	3.0
16	86411157	FRAME	PZ	2.0
17	86411156	PIN	PZ	1.0
18	864112447021	SUPPORT RAL7021		1.0
19	041392	REFLECTOR	PZ	1.0
20	024511	BUSHING	PZ	2.0
21	86411200	JIB SPACER	PZ	1.0



N.	CODE	DESCRIPTION	UM	QTY
22	864111657021	JIB ATTACHMENT	PZ	1.0
23	86411164	PIN	PZ	2.0
24	041614	O-RING		2.0

LOAD CELL






N.	CODE	DESCRIPTION	UM	QTY
1	040237	ACTUATOR	PZ	1.0
2	85503133	SHIM	PZ	1.0
3	010066	NUT	PZ	4.0
4	012379	WASHER	PZ	8.0
5	019109	SCREW	PZ	4.0
6	864111827021		PZ	1.0
7	86411189	PROTECTION	PZ	1.0
8	86411195	PIN	PZ	2.0
9	86411188	ROD	PZ	2.0
10	86411193	PIN	PZ	2.0
11	041075	LOAD CELL	PZ	1.0
12	86411184	PIN	PZ	1.0
13	010040	NUT	PZ	2.0
14	86411183	SLIDING BLOCK	PZ	1.0
15	864111757021		PZ	1.0
16	024511	BUSHING	PZ	2.0
17	86412006	CYLINDER	PZ	1.0
18	024327	WASHER	PZ	4.0
19	86411085	BLOCK	PZ	3.0
20	86411191	PIN	PZ	1.0
21	041339	BALANCE VALVE	PZ	1.0



N.	CODE	DESCRIPTION	UM	QTY
22	864111657021	JIB ATTACHMENT	PZ	1.0
23	86411164	PIN	PZ	1.0
24	040510	NUT	PZ	1.0
25	012381	WASHER	PZ	1.0
26	041073	BUSHING	PZ	8.0
27	041660	SEAL KIT	PZ	1.0
28	041614	O-RING		2.0

CAGE






N.	CODE	DESCRIPTION	UM	QTY
1	85403133	CAGE 1400X700	PZ	1.0
2	040401	WHEEL	PZ	4.0
3	855030557021	BASKET SUPPORT RAL7021	PZ	1.0
4	85503131		PZ	2.0
5	855030467021		PZ	1.0
6	85503140		PZ	1.0
7	041078	SENSOR	PZ	1.0
8	85503141		PZ	1.0
9	85503100	PIN WITH HANDLE	PZ	1.0
10	041093	MAGNET	PZ	1.0
11	012000	SNAP RING	PZ	2.0
12	82513080	ANTILOSS CABLE	PZ	1.0
13	85503119		PZ	1.0
14	040237	ACTUATOR	PZ	1.0
15	85503133	SHIM	PZ	1.0
16	864030047021	RADIOCONTROL SUPPORT RAL7021	PZ	1.0
17	041076	CELL AMPLIFIER	PZ	1.0
18	040393	PISTON	PZ	1.0
19	041264	SENSOR	PZ	1.0
20	85503116	MICRO SUPPORT	PZ	1.0
21	85503115	CONTROL BOX BRACKET	PZ	1.0



N.	CODE	DESCRIPTION	UM	QTY
22	040740	BUTTON PANEL	PZ	1.0
23	040428	BATTERY	PZ	1.0
24	85403092	LADDER	PZ	1.0
25	026548	DOCUMENT HOLDER BOX	PZ	1.0
26	040427	CONNECTION CABLE	PZ	1.0
27	018809			1.0
28	010013	NUT	PZ	1.0
29	82613039	DOCUMENT HOLDER BOX SUPPORT	PZ	1.0
30	040745	CASE	PZ	1.0
31	040746	CAP	PZ	1.0
32	040747	SOCKET	PZ	1.0
33	041020	BUTTON	PZ	1.0
34	85403122	SINGLE MAN BASKET 900X750	PZ	1.0
35	041672	PEDAL	PZ	1.0
36	85506130	PEDAL CABLE		1.0
37	040921		PZ	1.0
38	85503136		PZ	1.0
39	040922		PZ	1.0
40	040003	CABLE	PZ	1.0


PUSH-BUTTON PANEL





N.	CODE	DESCRIPTION	UM	QTY
1	040561		PZ	1.0
2	040554	DIPLAY FOR RADIO CONTROLLER	PZ	1.0
3	040566		PZ	1.0
4	041264	SENSOR	PZ	1.0
5	86606031	STICKER	PZ	1.0
6	040558		PZ	1.0
7	040555		PZ	4.0
8	040557		PZ	1.0
9	040559	BUTTON	PZ	1.0
10	040553	PROPORTIONAL JOYSTICK	PZ	6.0
11	040556	BUTTON	PZ	5.0

OPTIONAL





N.	CODE	DESCRIPTION	UM	QTY
1	86611290	ASS SALDATO ANTI CRUSHING R15-R19-R23		2.0
2	026426	FLYWHEEL	PZ	2.0
3	82513080	ANTILOSS CABLE	PZ	2.0
4	026580	ANTI-LOSS RING	PZ	2.0
5	86611296	ANTICRUSHING COVER		2.0
6	041078	SENSOR	PZ	1.0
7	86611293	PIASTRA ANTICRUSHING R15-R19-R23 ZINCATO		2.0
8	041898	MAGNET		3.0
9	86611291	1 ESTREMO ANTI CRUSHING R15-R19-R23		1.0
10	019150	SCREW	PZ	8.0
11	041899	ROPE		1.0
12	041902	TUBO POLIURETANO GIALLO DE8-DI5.5 >		1.0
13	86611294	2 ESTREMO ANTI CRUSHING R15-R19-R23		1.0
14	041302	WINCH		1.0
15	866112187021	SUPPORTO ARGANO		1.0
16	040679	MICRO SWITCH	PZ	1.0
17	866112727021	WINCH COVER PAINTED		1.0
18	866112767021	LEFT WINCH COVER PAINTED		1.0
19	866112737021	LEFT WINCH COVER PAINTED		1.0
20	866113077021	WINCH BRAKET		1.0
21	86611283	DISTANZIALE FINE CORSA ARGANO		1.0



N.	CODE	DESCRIPTION	UM	QTY
22	86611309	PIN WITH CAM		1.0
23	86611311	SCREW		1.0
24	86611286	PERNO FIX RULLI		1.0
25	86611285	DISTANZIALE MICRO ARGANO		1.0
26	026183	HANDLE	PZ	4.0
27	86606066	EMPTY WINCH BOX		1.0
28	041847	KEY SELECTOR		1.0
29	026288	CORE-HITCH	PZ	1.0
30	040535			1.0
31	86606064	WINCH BOX		1.0
32	86201510	STAFFA AGGANCIO SCATOLA ARGANO		1.0



Access Platform Division

Via San Francesco d'Assisi, 8 - 46020 Pegognaga (Mantova) - ITALY Tel. +39 0376
554011 - Fax +39 0376 559855

www.imergroup.com

Building Equipment Division

Via della Meccanica, 39 (Zona Industriale Sentino) - 53040 Rapolano Terme
(Siena) - ITALY - Tel. +39 0577 97341 - Fax +39 0577 704077

www.imergroup.com