



Parts List

Key	DESCRIPTION
1	Guard (Left) (BNT-001)
2	Guard Clip (BNT-002)
3	Washer (BNT-003)
4	Screw (BNT-004)
5	Guard (Right) (BNT-005)
6	Wrest Spring (BNT-006)
7	Axis (BNT-007)
8	Guide Rail Bolt (BNT-008)
9	Sensor Board (BNT-009)
10	Screw (BNT-010)
11	Locking Arm (BNT-011)
12	Spacer (BNT-012)
13	Belt Fastener (BNT-013)
14	Torsion Adjuster (BNT--14)
15	Display Circuit Board (BNT-015)
16	Shade (BNT-016)
17	Power Switch (BNT-017)
18	Aluminum Screw (BNT-018)
19	Press Spring (BNT-019)
19-1	Washer (not shown) (BNT-019-1)
20	Bobbin Holder (Left) (BNT-020)
21	Screw (BNT-021)
22	Handle 1 (BNT-022)
23	Sensor Board (BNT-023)
24	Screw (BNT-004)
25	Handle Cover I (BNT-025)
26	Trigger (BNT-026)
27	Press Spring (BNT-027)
28	Battery Connector (BNT-028)
29	Handle 2 (BNT-029)
30	Main Circuit Board (BNT-030)
31	Tier Cover (Left) (BNT-031)
32	Stopper Pin (BNT-032)
33	Sensor Board (BNT-033)
34	Cam (BNT-034)
35	Hook Arm (BNT-035)
36	Bracket (BNT-036)
37	Hook Pin (BNT-037)

38	Hook Pin (BNT-037)
39	Feed Gear (BNT-039)
40	Screw (BNT-024)
41	Motor Cover (BNT-041)
42	Motor Gear (BNT-042)
43	Motor Bracket (BNT-043)
44	Motor Spacer (BNT-044)
45	O Ring (BNT-045)
46	Feed Motor (BNT-046)
47	C-Clip (BNT-47)
48	Lock Lever (BNT-048)
49	Screw (BNT-021)
50	Guide (A) (BNT-050)
51	O Ring (BNT-051)
52	Gear Block Assembly (BNT-052)
53	Spring (BNT-053)
54	Guide Pipe (BNT-054)
55	O Ring (BNT-051)
56	Cutter-Twist assem. (BNT-056)
57	Transmission Shaft (BNT-057)
58	Motor Plate (BNT-058)
59	Motor (BNT-059)
60	Radiator (BNT-060)
61	Bolt (BNT-004)
62	Nut (BNT-062)
63	S. Strap Fastener (BNT-063)
64	Press Spring (BNT-019)
65	Screw (BNT-021)
66	Bobbin Holder (R) (BNT-066)
67	Case (R) (BNT-067)
68	Nylon Nut (BNT-068)
69	Handle cover II (BNT-069)
70	Bolt (BNT-024)
71	Aluminum Screw (BNT-018)
72	Shoulder Strap (BNT-072)
73	Handle Cover 3 (BNT-073)
74	Screw (BNT-024)
75	Inlay (BNT-075)
	Battery Pack (BN-12Vcad)
	Battery Charger (BN-12VCHGR)



• BN-TIER #BNT-64 VERTICAL WORK PARTS BREAKDOWN



• BN-TIER #BNT-64 HORIZONTAL WORK PARTS BREAKDOWN