

1128936 MEWP IM 3219 AC

CRIM3219AC_1128936_R00W - R00W (1/6/2023)



Access Platform Division

Via San Francesco d'Assisi, 8 - 46020 Pegognaga (Mantova) - ITALY Tel. +39 0376
554011 - Fax +39 0376 559855

www.imergroup.com


Building Equipment Division

Via della Meccanica, 39 (Zona Industriale Sentino) - 53040 Rapolano Terme
(Siena) - ITALY - Tel. +39 0577 97341 - Fax +39 0577 704077

www.imergroup.com

www.imerglobalcustomercare.com


BASE CARRIAGE





N.	CODE	DESCRIPTION	UM	QTY
1	85801145		PZ	1.0
2	85801109	BONNET	PZ	1.0
3	026183	HANDLE	PZ	2.0
4	040528	PUFFER	PZ	2.0
5	027513	WIRE	PZ	1.0
6	026518	TIE ROD	PZ	4.0
7	85801054	BONNET	PZ	1.0
8	85801099		PZ	1.0
9	85801097		PZ	1.0
10	027066	ROTATING BEACON	PZ	1.0
11	85801084	LIFTING CYLINDER CASE	PZ	1.0
12	85801038	LADDER	PZ	1.0
13	027066	ROTATING BEACON	PZ	1.0
14	85806051		PZ	1.0

FRONT AXLE






N.	CODE	DESCRIPTION	UM	QTY
1	858090547021	FRONT WHEEL PAINTED	PZ	2.0
2	041398	GEARMOTOR	PZ	2.0
3	041814	ENCODER >	PZ	1.0
4	041820	TERMINAL BLOCK	PZ	1.0
5	041155	RECTIFIER	PZ	1.0
6	041846	TERMINAL BLOCK COVER	PZ	2.0
7	858090697021	LEFT WHEEL SUPPORT PAINTED	PZ	1.0
8	858090387021	RIGHT SPINDLE RAL7021	PZ	1.0
9	858090137021	SHIELD	PZ	1.0
10	858090147021	SHIELD	PZ	1.0
11	85809034		PZ	2.0
12	85801167	WHEEL SUPPORT WASHER	PZ	2.0
13	024515	BUSHING	PZ	4.0
14	019148	GREASE NIPPLE	PZ	2.0
15	85811024	SENSOR JOINT	PZ	1.0
16	019150	SCREW	PZ	1.0
17	041446	ANGULAR SENSOR	PZ	1.0
18	041806	DISTANZIALE M4X25 F/F	PZ	2.0
19	85801164	TAPPO PER ENCODER STERZO	PZ	1.0
20	041853	ENCODER CAP	PZ	1.0
21	85812004	CYLINDER	PZ	1.0



N.	CODE	DESCRIPTION	UM	QTY
22	041102	GASKET KIT	PZ	1.0
23	85809006	PIVOT	PZ	2.0
24	85809050	STEERING ARM	PZ	2.0
25	85809051		PZ	2.0
26	019206	NUT	PZ	2.0
27	010080	NUT	PZ	2.0
28	85909038		PZ	2.0
29	027017	BUSHING	PZ	4.0
30	025138	BUSHING	PZ	2.0
31	85801111	BATTERY CHARGER COVER	PZ	1.0
32	042085	REDUCTION GEAR		1.0
33	042076	SEALS KIT		1.0
34	042074	BRAKE COMPONENTS KIT		1.0


LEFT BOX





N.	CODE	DESCRIPTION	UM	QTY
1	041675	BATTERY AGM ZENITH 6V ZL060100 170AH C5		2.0
2	85801081	LOCKING DEVICE	PZ	2.0
3	025922	ANDERSON HANDLE	PZ	1.0
4	025920	PLUG	PZ	2.0
5	025325	FUSE CARRIER	PZ	1.0
6	028100	FUSE	PZ	1.0
7	041395	CONTROLLER ZAPI DualACEX&HP 24V >%	PZ	1.0
8	85801138	LEFT BOX COVER	PZ	1.0
9	85801139		PZ	1.0
10	025674	REMOTE SWITCH	PZ	1.0
11	85811067	CABLE	PZ	1.0
12	040227	HANDLE	PZ	1.0
13	027267	CHARGER INDICATOR	PZ	1.0


REAR AXLE





N.	CODE	DESCRIPTION	UM	QTY
1	858090577021	REAR WHEEL PAINTED RAL7021	PZ	2.0
2	83709015	DISC	PZ	2.0
3	025313	BEARING	PZ	4.0
4	83709016	DISTANCE BEARING	PZ	2.0
5	018804	SNAP RING	PZ	2.0
6	026645	PUFFER	PZ	2.0
7	040536	HYDRAULIC UNIT	PZ	1.0
8	85801041	REAR BOX	PZ	1.0
9	85801079	PIVOT	PZ	1.0
10	025421	SPRING	PZ	1.0
11	85801080	BOX HANDLE	PZ	1.0
12	027025	WASHER	PZ	1.0
13	012381	WASHER	PZ	1.0
14	010897	SCREW	PZ	1.0
15	011021	SCREW	PZ	1.0
16	85801078	PIVOT	PZ	1.0
17	027017	BUSHING	PZ	1.0
18	026426	FLYWHEEL	PZ	2.0
19	85801038	LADDER	PZ	1.0
20	041037	INCLINOMETER	PZ	1.0
21	85801061	INCLINOMETER PLATE	PZ	1.0

HYDRAULIC CONTROL BOX






N.	CODE	DESCRIPTION	UM	QTY
1	040645	MOTOR	PZ	1.0
2	040309	SPACER FOR MOTOR	PZ	1.0
3	040308	PEN JOINT	PZ	1.0
4	040150	BUSHING	PZ	1.0
5	040137	MANIFOLD	PZ	1.0
6	027627	PRESSURE GAUGE	PZ	1.0
7	040138	VALVE	PZ	1.0
8	040642	VALVES BLOCK	PZ	1.0
9	040643	VALVE	PZ	1.0
10	040644	SOLENOID VALVE	PZ	1.0
11	040648	PRESSURE-LIMITING VALVE	PZ	1.0
12	040647	PUMP	PZ	1.0
13	040306	INTAKE KIT	PZ	1.0
14	040646	OIL TANK	PZ	1.0
15	040650	DRAINING PLUG	PZ	1.0
16	040649	OL TANK PLUG	PZ	2.0
17	040653	SEAL KIT FOR HYDR. UNIT 040536		1.0
18	025278	PLUG	PZ	1.0
19	040825	FILTER	PZ	1.0
20	040734	BLOCK	PZ	1.0
21	040906	FILTER	PZ	1.0



N.	CODE	DESCRIPTION	UM	QTY
22	041035	MOTOR TRANSMISSION KIT	PZ	1.0
23	027136	COIL	PZ	2.0
24	040856	GREY CONNECTOR	PZ	2.0


POTHOLE





N.	CODE	DESCRIPTION	UM	QTY
1	858010717021	LEFT POTHOLE SLIDE RAL7021	PZ	1.0
2	858010707021	RIGHT POTHOLE SLIDE RAL7021	PZ	1.0
3	83701032	PIVOT	PZ	4.0
4	018797	TIE ROD	PZ	4.0
5	027025	WASHER	PZ	4.0
6	83701026	MALE TIE ROD	PZ	2.0
7	83701027	FEMALE TIE ROD	PZ	2.0
8	83701090	PLATE	PZ	4.0
9	026187	CENTRE BEARING	PZ	2.0
10	027017	BUSHING	PZ	4.0
11	83701088	SPRING	PZ	2.0
12	85801086	LEFT LEVEL POTHOLE	PZ	1.0
13	85801085	RIGHT LEVEL POTHOLE	PZ	1.0
14	027056	SPRING	PZ	2.0
15	85801140	WASHER	PZ	2.0
16	026188	BUSHING	PZ	2.0
17	040034	MICRO SWITCH	PZ	2.0
18	021900	HORN	PZ	1.0


RIGHT BOX





N.	CODE	DESCRIPTION	UM	QTY
1	041675	BATTERY AGM ZENITH 6V ZL060100 170AH C5		2.0
2	85806107	LOWER CONTROL BOX	PZ	1.0
3	85801082	CONTROL PANEL SUPPORT	PZ	1.0
4	026426	FLYWHEEL	PZ	1.0
5	82513080	ANTILOSS CABLE	PZ	1.0
6	026580	ANTI-LOSS RING	PZ	1.0
7	85801083	SUPPORT FOR CONTROL BOX	PZ	2.0
8	040637	ELECTRONIC CONTROL UNIT TTC94	PZ	1.0
9	026413	FUSE CARRIER BOX	PZ	1.0
10	026455	FUSE	PZ	1.0
11	026212	FUSE	PZ	1.0
12	026213	FUSE	PZ	1.0
13	85801081	LOCKING DEVICE	PZ	2.0
14	024762	SWITCH	PZ	1.0
15	025669	WATER-PROOF BOX	PZ	1.0
16	024212	PLUG	PZ	1.0
17	041109		PZ	1.0

GROUND PANEL






N.	CODE	DESCRIPTION	UM	QTY
1	85806037	EMPTY LOWER CONTROL PANEL	PZ	1.0
2	027537	KEY %	PZ	1.0
3	025178	JUNCTION BOX	PZ	2.0
4	027062	KEY SELECTOR	PZ	1.0
5	040625	CONTACT	PZ	2.0
6	026735	PUSH-BUTTON	PZ	1.0
7	024695	SWITCH	PZ	1.0
8	040191	CONTROL LAMP	PZ	1.0
9	040192	CONTROL LAMP	PZ	1.0
10	026121	CONTACT	PZ	1.0
11	040626	BUZZER	PZ	1.0
12	027204	RELAY	PZ	2.0
13	040326		PZ	1.0
14	040327	CLAMPING STRIP	PZ	34.0
15	040328		PZ	2.0
16	040329		PZ	1.0
17	85806034	LABEL	PZ	1.0
18	040333	CLAMPING STRIP	PZ	2.0
19	040839	SCREW	PZ	1.0
20	040668	PIN HARTING DA 1,5 (CPF) 09150006201	PZ	9.0
21	040669	PIN HARTING DA 0,5 (CPF) 09150006203	PZ	6.0



N.	CODE	DESCRIPTION	UM	QTY
22	040667	SOCKET	PZ	1.0
23	040666	CASE	PZ	1.0
24	040661	CABLE CLAMP	PZ	1.0

COMPLETE SCISSOR






N.	CODE	DESCRIPTION	UM	QTY
1	85811003	THIRD CHASSIS	PZ	1.0
2	85811002	SECOND CHASSIS	PZ	1.0
3	85811004	THIRD CHASSIS	PZ	1.0
4	85811005	FOURTH CHASSIS	PZ	1.0
5	85811007	BOOM (SP.3 WITHOUT HOLES)	PZ	6.0
6	85811008	BOOM (SP.4)	PZ	2.0
7	85812003	LIFTING CYLINDER	PZ	1.0
8	84505006	CYLINDER BLOCK	PZ	1.0
9	040481	COIL	PZ	1.0
10	040518	VALVE	PZ	1.0
11	026852	PRESSURE SENSOR	PZ	1.0
12	027132	CYLINDER GASKET KIT	PZ	1.0
13	85806044		PZ	1.0
14	040668	PIN HARTING DA 1,5 (CPF) 09150006201	PZ	9.0
15	040669	PIN HARTING DA 0,5 (CPF) 09150006203	PZ	6.0
16	040667	SOCKET	PZ	1.0
17	040666	CASE	PZ	1.0
18	040661	CABLE CLAMP	PZ	2.0
19	040662	CASE	PZ	1.0
20	040663	SOCKET	PZ	1.0
21	040664	PIN HARTING DA 1,5 (CPM) 09150006101	PZ	9.0



N.	CODE	DESCRIPTION	UM	QTY
22	040665	PIN HARTING DA 0,5 (CPM) 09150006103	PZ	6.0


SCISSOR (1-2)





N.	CODE	DESCRIPTION	UM	QTY
1	85811020	CHASSIS SHELL D25	PZ	2.0
2	018878	SCREW	PZ	4.0
3	024511	BUSHING	PZ	24.0
4	85811048	PIVOT	PZ	1.0
5	83711045	PUFFER	PZ	12.0
6	85811058	POTHOLE PUSHER	PZ	1.0
7	85811042	SLIDING BLOCK FOR POTHOLE PUSHER	PZ	1.0
8	85811049	PIVOT	PZ	2.0
9	85811028	SLIDING BLOCK	PZ	2.0
10	83711047	PIVOT	PZ	1.0
11	018482	PIN	PZ	1.0
12	040640	BUSHING	PZ	2.0
13	85811050	PIVOT	PZ	2.0
14	85811052	PIVOT	PZ	6.0
15	019182	WASHER	PZ	10.0
16	019194	SEEGER D.24 EST. UNI 7435	PZ	12.0
17	027013	PRESS BUTTON	PZ	10.0
18	85811051	PIVOT	PZ	2.0

SCISSOR (3-4)






N.	CODE	DESCRIPTION	UM	QTY
1	85811052	PIVOT	PZ	6.0
2	024511	BUSHING	PZ	26.0
3	85811051	PIVOT	PZ	2.0
4	85811050	PIVOT	PZ	2.0
5	85811043	SAFETY ROD	PZ	2.0
6	027065	HANDLE	PZ	2.0
7	019182	WASHER	PZ	12.0
8	019194	SEEGER D.24 EST. UNI 7435	PZ	12.0
9	027013	PRESS BUTTON	PZ	10.0
10	83711019	PIVOT	PZ	1.0
11	018482	PIN	PZ	1.0
12	040640	BUSHING	PZ	2.0
13	83711045	PUFFER	PZ	4.0
14	011078	PIN	PZ	2.0
15	85811024	SENSOR JOINT	PZ	1.0
16	019150	SCREW	PZ	1.0
17	85811069	SENSOR SUPPORT	PZ	1.0
18	040636	SENSOR	PZ	1.0
19	85811022	PLATFORM SHELL	PZ	2.0
20	85811053	PIVOT	PZ	2.0
21	018878	SCREW	PZ	4.0



N.	CODE	DESCRIPTION	UM	QTY
22	85811028	SLIDING BLOCK	PZ	2.0
23	84511020	NUT	PZ	4.0
24	85811054	PIVOT	PZ	1.0

FIXED PLATFORM






N.	CODE	DESCRIPTION	UM	QTY
1	85851001		PZ	1.0
2	85813008	RIGHT SIDE RAILING	PZ	1.0
3	85813009	LEFT SIDE RAILING	PZ	1.0
4	85813039	GATE	PZ	1.0
5	83713005	DISTANCE BAR	PZ	1.0
6	85851046		PZ	1.0
7	83751014	SLIDING ROLLER	PZ	2.0
8	026488	BEARING	PZ	2.0
9	83751015	PIVOT	PZ	2.0
10	026692	NUT	PZ	2.0
11	026758	CAP	PZ	1.0
12	018882	SCREW	PZ	2.0
13	027121	SPRING	PZ	2.0
14	019105	NUT	PZ	2.0
15	026158	PIN	PZ	5.0
16	82513080	ANTILOSS CABLE	PZ	5.0
17	026580	ANTI-LOSS RING	PZ	5.0
18	84513018	COUPLING	PZ	1.0
19	026645	PUFFER	PZ	1.0
20	85806061	SPRING PLATFORM CONTROL CABLE	PZ	1.0
21	85851016	220V PLUG SUPPORT	PZ	1.0



N.	CODE	DESCRIPTION	UM	QTY
22	040747	SOCKET	PZ	1.0
23	040745	CASE	PZ	1.0
24	040746	CAP	PZ	1.0

MOBILE PLATFORM






N.	CODE	DESCRIPTION	UM	QTY
1	85851005		PZ	1.0
2	85813045	FRONT RAILING	PZ	1.0
3	85813028	RIGHT EXTENSION LEAD	PZ	1.0
4	85813029	LEFT EXTENSION LEAD	PZ	1.0
5	83751077	SLIDING ROLLER	PZ	2.0
6	83751079	PIVOT	PZ	2.0
7	026692	NUT	PZ	2.0
8	83751021	PEDEAL ROLL	PZ	1.0
9	83751016	PEDAL	PZ	1.0
10	83751020	RELEASE PEDAL ROLL	PZ	1.0
11	025489	TRACTION SPRING	PZ	1.0
12	85813044	TELESCOPIC GUARDRAIL	PZ	2.0
13	025811	CAP	PZ	2.0
14	026548	DOCUMENT HOLDER BOX	PZ	1.0
15	041678	MALE T KEY	PZ	4.0
16	041803	MALE T KEY	PZ	1.0
17	85813042	HANDLE CONNECTION	PZ	2.0
18	040586	HANDGRIP	PZ	2.0
19	026158	PIN	PZ	4.0
20	82513080	ANTILOSS CABLE	PZ	4.0
21	026580	ANTI-LOSS RING	PZ	4.0



N.	CODE	DESCRIPTION	UM	QTY
22	85813007	CONTROL BOX SUPPORT	PZ	1.0
23	83706046	CAP FOR CONTROL PANEL	PZ	1.0
24	85806123	UPPER CONTROL BOX	PZ	1.0

CONTROL BOX





N.	CODE	DESCRIPTION	UM	QTY
1	85806124	EMPTY UPPER CONTROL BOX		1.0
2	027124	EMERGENCY BUTTON	PZ	1.0
3	041178	JOYSTICK	PZ	1.0
4	040633	CASE	PZ	1.0
5	040634	SOCKET	PZ	1.0
6	85906020	SPRING CONTROL CABLE FOR IM	PZ	1.0
7	040862	CASE	PZ	1.0
8	026457	CABLE CLAMP	PZ	1.0
9	040661	CABLE CLAMP	PZ	1.0
10	040662	CASE	PZ	1.0
11	040663	SOCKET	PZ	1.0
12	040664	PIN HARTING DA 1,5 (CPM) 09150006101	PZ	9.0
13	040665	PIN HARTING DA 0,5 (CPM) 09150006103	PZ	6.0
14	041016	SOCKET	PZ	1.0
15	040096	JOYSTICK RUBBER CUP	PZ	1.0
16	041453	BOARD FOR UPPER CONTROL BOX 9 HOLES	PZ	1.0
17	040497	KIT WITH 4 SCREWS	PZ	1.0
18	85806122	DECAL FOR UPPER CONTROL BOX		1.0
19	026846	BUZZER	PZ	1.0
20	027253	STEERING BUTTON	PZ	2.0
21	027252	JOYSTICK HANDGRIP	PZ	1.0



N.	CODE	DESCRIPTION	UM	QTY
22	041372	JOYSTICK BASE	PZ	1.0



Access Platform Division

Via San Francesco d'Assisi, 8 - 46020 Pegognaga (Mantova) - ITALY Tel. +39 0376
554011 - Fax +39 0376 559855

www.imergroup.com

Building Equipment Division

Via della Meccanica, 39 (Zona Industriale Sentino) - 53040 Rapolano Terme
(Siena) - ITALY - Tel. +39 0577 97341 - Fax +39 0577 704077

www.imergroup.com