




TRADESMAN

Kerosene Heaters

Kerosene Heaters

MODEL K150





Kerosene Heaters

PARTS IDENTIFICATION

<u>Item</u>	<u>Description</u>	<u>Model K150</u>
1	Upper Shell	130-20770
2	Screw, #10-16 x 1/2"	130-20805
3	Combustion Chamber	130-20775
4	Photocell Bracket	130-20825
5	Screw, #6-32 x 3/8"	130-20808
6	Photocell Assembly	130-20827
7	Burner Head Assembly	400-20832*
7-1	Nozzle with Sleeve	130-20766
7-2	Nozzle Seal Washer	130-20763
7-3	Nozzle Seal Spring	130-20764
7-4	Nozzle Sleeve	130-20765
7-5	Burner Head Body	130-20837
7-6	Barb Fitting	130-20834
7-7	Spark Plug	130-20830
8	Screw, #10-16 x 1/2"	130-20805
9	Fan	130-20844
10	Motor and Pump Assembly	400-20861*
10-1	Motor	120-20862
10-2	Pump Body	130-20857
10-3	Screw, #10-32 x 5/8"	130-20814
10-4	Rotor Insert	130-20858
10-5	Pump Rotor	130-20859
10-6	Pump End Cover	130-20877
10-7	Intake Filter	130-20879
10-8	Filter End Cover	130-20882
10-9	Steel Ball, 1/4" Dia.	130-20915
10-10	Relief Spring	130-20916
10-11	Adjusting Screw	130-20917
10-12	Plug	130-20918
10-13	Screw, #10-32 x 1"	130-20813
10-14	Output Filter	130-20920
10-15	Lint Filter	130-20880
10-16	Barb Fitting	130-20832
10-17	Blade	130-20860
11	Rubber Bumper	130-20924
12	Motor Mounting Bracket	130-20863
13	Solid State Relay	120-20889
14	Screw, #8-18 x 1/2"	130-20812
15	Hex Lock Nut, 1/4-20	130-20818
16	Fan Guard	130-20930
17	Ignitor Kit	120-20888
18	Screw, #10-16 x 3/4"	130-20807
19	Fuel Line	130-20952
20	Fuel Filter	130-20953
21	Fuel Line Tube	130-20954
22	Rubber Bushing	130-20933
23	Airline	130-20955
24	Lower Shell	130-20771
25	Bushing	130-20934
26	Bushing	130-20935
27	Screw, #10-16 x 1/2"	130-20805
28	Clip Nut	130-20936
29	Screw, #8-32 x 3/8"	130-20810
30	Fuel Tank	130-20778
31	Fuel Cap (includes Gasket)	130-20944


Kerosene Heaters

MODEL K150 (Continued)



AIR GAUGE KIT - 500-20907

Special tool to check pump pressure. For all models.



FLAME-OUT CONTROL/ PHOTOCELL TESTER - 500-20913

Special tool used to test the flame-out control and photocell.

Kerosene Heaters

PARTS IDENTIFICATION (Continued)

32	Flame-Out Control	120-20875
33	Strain Relief Bushing	130-20947
34	Power Cord	120-20893
35	Side Cover	130-20956
36	Screw, #10-16 x 1/2"	130-20805
37	Terminal Board	120-20886
38	Rivet	130-20927
39	Wire Assembly (Red, 18")	120-20885
40	Wire Assembly (Red, 6")	120-20883
41	Drain Plug (Includes "O" Ring)	130-20945
42	Hex Nut, 3/8 - 27	130-20822
43	Button Plug	130-20957
44	Thermostat	120-20899
45	Screw, #6-32 x 1/4"	130-20809
46	Thermostat Knob	130-20928

* Not available as an assembly.

Parts Available - Not Shown

General Info. Decal	150-20801
Combustion Chamber Ground Wire	130-20922
Wire Clip (Secures thermostat and power cord wires)	130-20923

Optional Accessories

Rotor Kit	500-20900
Filter Kit	500-20901
Pump Kit	500-20902

Wheels and Handle Parts List

1	Handles	130-21940
2	Screw, #10-24 x 1 3/4"	130-20853
3	Wheel Support Frame - Hex Nut, #10-24	130-21942
4	Wheel	130-20851
5	Cap Nut	130-20854
6	Axle	130-21941