




IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.



Stocked
at Depot

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	
1	Top Side Logs C	No longer available	4004-128	
2	Top Center Right Log C	No longer available	4004-129	
3	Top Center Left Log C	No longer available	4004-130	
4	Bottom Front Left Log 18" C	No longer available	4004-131	
5	Bottom Front Right Log 18" C	No longer available	4004-132	
6	Back Log 18" C	No longer available	4004-133	
	18" Charwood Setup Instructions Sheet		4004-140	