

ConstructionParts.com

K 3600

Reservdelar

Spare parts

Ersatzteile

Pieces de rechange

Piezas de repuesto

Ricambi

***Peças
sobresselente***

ConstructionParts.com


888-634-4289

106 25 76-63

A

ConstructionParts.com


888-634-4289



ConstructionParts.com


888-634-4289

B compl. 506 28 51-02



ConstructionParts.com

C * compl. 506 30 06-01




ConstructionParts.com

888-634-4289

D Hydr. motor compl. 506 19 87-01


ConstructionParts.com

888-634-4289



E Hydr. motor compl. 506 19 87-01

ConstructionParts.com




ConstructionParts.com

888-634-4289

F


ConstructionParts.com 888-634-4289



ConstructionParts.com

G

Tool kit 506 29 96-01




ConstructionParts.com

888-634-4289

H

ConstructionParts.com

888-634-4289



No.	Pos.	Denomination	No.	Pos.	Denomination	No.	Pos.	Denomination			
503 20 00-03	A	Screw M6SF 5x12	506 30 10-01	A	Trigger, kit	888-634-4289					
503 20 00-04	A	Screw M6SF 5x16	506 30 11-01	E	Seal, cpl						
503 20 00-05	A	Screw M6SF 5x25	506 30 12-01	D	Cover motor, cpl						
503 20 00-07	A	Screw M6SF 5x40	506 30 13-01	B	Support roller cover						
503 20 02-20	D, E	Screw	506 30 14-01	B	Adjusting screw						
503 20 02-30	D	Screw	506 30 15-01	B	Plug with O-ring						
503 21 46-01	A, H	Screw	506 30 34-01	B,C	Hex washer						
503 23 00-64	H	Washer	506 31 22-01	F	Flange washer						
503 24 07-01	D	Pin	506 31 45-01	H	Pipe						
503 26 30-21	A	O-ring	506 31 67-01	C	Engagement roller, cpl						
503 26 30-22	H	O-ring	506 31 91-01	H	Stabilizer blade	888-634-4289					
503 26 30-24	A	O-ring	506 32 00-01	D	Shaft						
503 26 30-25	H	O-ring	506 32 01-01	H	Pin						
506 09 56-02	A	Clamp	506 32 08-01	F	Drive wheel, cpl						
506 09 75-07	H	Hose	506 32 41-01	B	Support roller, cpl						
506 10 55-01	H	Spring	506 32 43-01	B,C	Engagement roller						
506 10 95-02	H	Hose	506 32 44-01	B	Support roller						
506 10 96-21	H	Coupler 3/8" (fem) FF, BSP	506 32 47-01	B	Screw, 6 x 22						
506 10 98-21	H	Coupler 3/8" (male) FF, BSP	720 13 13-06	A	Pin, 5x28				888-634-4289		
506 11 03-01	E	O-ring	725 53 27-55	H	Screw, MC6 5x12						
506 11 04-01	E	O-ring	725 53 72-55	B	Screw, 6x25						
506 11 05-01	E	Bearing	725 53 76-55	F	Screw, 6x35						
506 13 95-02	F	Washer	725 53 79-05	C	Screw, 6x45						
506 17 83-01	F	Drive disc	725 53 80-05	H	Screw, 6x50						
506 19 87-01	D,E,F	Hydr. motor, compl	725 53 81-05	B	Screw, 6x55						
506 20 31-01	E	Lever	725 54 57-55	B	Screw,, 8x40						
506 20 38-01	E	Spring	725 54 69-05	H	Screw, 8x90						
506 21 59-01	E	Valve spindle	732 25 12-01	E	Nut, M4	888-634-4289					
506 21 60-01	E	Sleeve	735 31 08-20	E	E-ring 4						
506 21 80-01	D	Valve	735 31 14-00	E	Seeger clip						
506 21 81-01	D	Spring	735 31 31-10	E	Retaining ring						
506 21 82-01	E	Piston	735 88 06-00	F	Woodruff key						
506 21 83-01	E	Spring	738 22 01-25	E	Ball bearing 6201-C3						
506 21 85-01	D	Valve seat	740 38 27-01	H	Washer, 1/4"						
506 24 52-01	A	Handle, left	740 38 34-01	H	Washer, 3/8"						
506 24 53-01	A	Handle, right	740 42 03-00	D	O-ring						
506 24 58-01	C	Bellow	740 43 02-00	E	O-ring						
506 24 59-01	C	Sleeve	740 43 03-00	H	O-ring	888-634-4289					
506 24 61-01	C	Bushing	740 43 11-00	D	O-ring						
506 24 63-01	C	Guide roller, cpl									
506 24 69-01	H	Blade guard, cpl									
506 24 72-01	H	Screw									
506 24 84-01	A	Valve, water, cpl									
506 24 90-01	H	Handle, cpl									
506 24 95-01	H	Spring									
506 24 97-01	H	Locking handle									
506 25 60-01	C	Spring									
506 25 65-01	F	Drive disc support									
506 25 68-01	C	Splash guard									
506 25 70-01	A	Control, water									
506 25 75-01	C	Spring									
506 26 22-01	H	Roller									
506 26 26-01	A	Spring									
506 26 27-01	A	Window									
506 27 28-01	A	Spring									
506 27 34-01	F	Sealing									
506 27 65-01	A	Decal, right									
506 27 66-01	A	Decal, left									
506 28 08-02	B	Holder, upper									
506 28 08-03	B	Holder, lower									
506 28 51-02	B	Support roller cover, cpl									
506 28 78-01	E	Rod									
506 28 99-01	C	Bellow									
506 29 23-01	H	Spring									
506 29 31-01	A	Water hose, cpl									
506 29 40-01	C	Stop screw									
506 29 41-01	C	Stop screw									
506 29 59-01	H	Warning decal									
506 29 64-01	B	Plug									
506 29 88-01	A	Screen									
506 29 96-01	G	Tool kit									
506 30 07-01	C	Handle, upper									
506 30 07-02	C	Handle, lower									
506 30 08-01	C	Shaft, cpl									
506 30 09-01	C	Locking device									