




# ***TRADESMAN***

## ***Portable Forced Air Heaters***

# Portable Forced Air Heaters

## MODELS CP380A & CP380B



# Portable Forced Air Heaters



## PARTS IDENTIFICATION

Item	Description	Model	
		CP380A	CP380B
1	Regulator	-----400-08997-----	-----400-08997-----
2	Adapter, 1/4 NPT x 1/2 NPS	-----310-06771-----	-----310-06771-----
3	Hose, 1/2 In. x 10 Ft.	-----550-20719-----	-----550-20719-----
4	Adapter, 3/8 NPT x 1/2 NPS	-----310-03536-----	-----310-03536-----
5	Knob, Thermostat	-----130-04805-----	-----130-04805-----
6	Cord, Power	-----120-05795-----	-----120-05795-----
7	Switch, On/Off	-----120-08240-----	-----120-08240-----
8	Thermostat	-----550-05829-----	-----550-05829-----
9	L.E.D. w/ Leads	-----120-08811-----	-----120-08811-----
10	Solenoid Valve Assembly (Includes Items 10a - 10c)	-----400-08814-----	-----400-08814-----
10a	Ell, Brass	-----130-08011-----	-----130-08011-----
10b	Valve, Throttle	-----130-06871-----	-----130-06871-----
10c	Ell, Black Pipe	-----130-01175-----	-----130-01175-----
10d	Nipple	-----130-02421-----	-----130-02421-----
10e	Nipple	-----130-03121-----	-----130-03121-----
10f	Bracket	-----225-08010-----	-----225-08010-----
11	Elbow	-----130-08816-----	-----130-08816-----
12	Manifold, Tube w/ Nuts & Sleeves	-----550-08815-----	-----550-08815-----
13	Terminal Board	-----120-08253-----	-----120-08253-----
14	Control, Ignition	-----120-08810-----	-----120-08810-----
15	Transformer	-----120-08958-----	-----120-08958-----
16	Boot, Capacitor	-----120-04938-----	-----120-04938-----
17	Capacitor	-----120-04720-----	-----120-04720-----
18	Switch, Air Proving, w/ Bracket	-----400-06739-----	-----400-06739-----
19	Guard, Fan	-----225-06307-----	-----225-06307-----
20	Switch, Backflash	-----400-06664-----	-----400-06664-----
21	Wire, Igniter	-----120-09347-----	-----120-09347-----
22	Igniter	-----500-20312-----	-----500-20312-----
23	Orifice, w/ Retaining Rings	-----550-20410-----	-----550-20410-----
24	Burner Plate	-----260-06314-----	-----260-06314-----
25	Heat Chamber, w/ Burner Plate & Igniter	-----400-20416-----	-----400-20416-----
26	Mount, Motor	-----260-06717-----	-----260-06717-----
27	Motor	-----120-04719-----	-----120-04719-----
28	Fan Blade	-----130-06697-----	-----130-06697-----
29	Handle	-----550-03941-----	-----550-03941-----
30	Nut, Acorn	-----130-03938-----	-----130-03938-----
31	Case, Top	-----271-08013-----	-----271-08013-----
32	Case, Front	-----271-08577-----	-----271-08577-----
33	Case, Panel, Right	-----271-08017-----	-----271-08017-----
34	Case, Bottom & Back	-----271-08578-----	-----271-08578-----
35	Case, Panel, Left	-----271-08016-----	-----271-08016-----
36	Bracket	-----225-08579-----	-----225-08579-----
37	Case, Barrel, Bottom	-----271-08012-----	-----271-08012-----