

IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.




**Stocked  
at Depot**

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	
1	Firebrick Set (see following page)		832-0550	
2	Ceramic Blanket		832-3401	Y
3	Baffle		832-0530	Y
4	Hinge Pins		832-0250	
5	Glass Assembly		7000-012	Y
6	Spring Handle	1/2" Gold	832-0620	Y
7	Handle Assembly		832-0540	Y
8	Manifold Tube		832-3310	Y
9	Legs	No longer available	WS-GL	
	Door Rope		832-1680	Y
	Spring Handle (Air control)	1/4" Gold	832-0630	Y

Additional service parts on following page

When ordering new brick pieces, please mark the piece to be replaced and fax this page with your order.

### Brick Pattern for WS-250-L



### Brick Pattern for WS-250-P

