

Operator / Parts Manual




Vibratory Screed

Models: VS400 & VS800




Vibratory Screed





SCREED ASSEMBLY

Item	Part No	Qty	Description	Descripción	Description	Descrizione
1	26430-2	1	Frame			
2	80083	6	Wing Nut			
3	26453	6	L-Bolt			
4	34617	1	Belt			
5	34633	1	Sheave			
6	42863	1	Eccentric Guard (VS400)			
6a	26448-2	1	Eccentric Guard (VS800)			
7	32208	2	Pillowblock			
8	26644-2	1	Eccentric (VS400)			
8a	26442-2	1	Eccentric (VS800)			
9	26640-2	2	Nut Plate			
10	47343	8	Shock Mount			
11	26441-2	1	Motor Base			
12	30317	1	Engine 3.5 HP B&S			
12a	30586	1	Engine 5 HP B&S			
12b	30159	1	Engine 5.5 HP Honda			
12c	30318	1	Engine 5 HP B&S IP			
13	34627	1	Clutch			
14	29310	1	Bracket			
15	26452-2	1	Handle Upper			
16	26445-2	1	Belt Guard			
18	26652-2	2	Handle Lower			
19	80343	2	Washer WSHR ½ SAE			






SCREED ASSEMBLY

Item	Part Nbr	Qty	Description	Descripción	Description	Descrizione
20	27189-2	2	Handle Bracket			
21	24543-2	1	Lift Eye (3 hp)			
21a	28318-2	1	Lift Eye (5.5 hp Honda)			
21b	42451-2	1	Lift Eye (5.5 hp B&S)			
22	26326	4	Spacer (VS800 only)			
23	30166	1	Exhaust Deflector (5.5 hp Honda)			
23a	38055	1	Exhaust Deflector (5 hp B&S)			
23b	30427	1	Exhaust Deflector (5.5 hp B&S)			
^	21335	1	Spreader Assembly includes 2, 3, 24-27			
24	24141	2	Grip			
25	47009	20 ft	Rope			
26	26528-2	1	Spreader Left Side			
27	26523-2	1	Spreader Right Side			
28^	80956	1	Screw HWHST 8 x 1/2 (B&S IP)			
29^	21335	1	Spreader Assembly			

^ Not shown





SCREED ASSEMBLY HARDWARE

Item	Part Nbr	Qty	Description	Descripción	Description	Descrizione
A	26325	4	Washer WSHR .375ID x 1.00 OD x .187 ZN	Arandela	Rondelle	Rondella
B	80051	2	Nut NUTNY ½-13 ZN	Tuerca	Écrou	Dado
C	80058	4	Washer WSHRL 3/8 Med Split ZN	Arandela de seguridad	Rondelle-frein	Rondella di sicurezza
D	80072	4	Screw HHCS 3/8-16 x 1-3/4 GR5 ZN	Tornillo	Vis	Vite
E	80075	2	Screw HHCS 1/2-13 x 1-1/2 GR5 ZN	Tornillo	Vis	Vite
F	80085	5	Screw HWHST 5/16-18 x 3/4 GR5 ZN	Tornillo	Vis	Vite
G	80086	4	Washer WSHRL 5/16 Med Split ZN	Arandela de seguridad	Rondelle-frein	Rondella di sicurezza
H	80100	1	Key Sq ¼ x 1 Pln			
I	80113	16	Screw HHCS 1/2-13 x 3/4 ZN	Tornillo	Vis	Vite
J	80114	9	Nut NUTNY 5/16-18 ZN	Tuerca	Écrou	Dado
K	80117	16	Washer WSHRL 1/2 Med Split ZN	Arandela de seguridad	Rondelle-frein	Rondella di sicurezza
L^	80159	1	Screw (3.5 B&S only) HHCS 5/16-18 x 3/4 GR5 ZN	Tornillo	Vis	Vite
M	80161	5	Screw HHCS 5/16-18 x 1 GR5 ZN	Tornillo	Vis	Vite
N	80171	4	Screw (All Except 3.5 B&S) FHSCS 5/16-24 x 3/4 GR5 ZN	Tornillo	Vis	Vite
O	80348	5	Washer WSHR 5/16 Wrot ZN	Arandela	Rondelle	Rondella
P	80472	4	Screw HHCS 5/16-18 x 1-3/4 GR5 ZN	Tornillo	Vis	Vite

^ Not shown



1

IDLE ENGINE 5 MINUTES
BEFORE STOPPING
TO IMPROVE SERVICE LIFE

DEJE FUNCIONAR EL MOTOR EN
VACIO DURANTE 5 MINUTOS ANTES
DE DETENERLO PARA EXTENDER SU
VIDA DE SERVICIO.

55546

4

This engine has been tested with
fuel treated with
STA-BIL®
to prevent gum and varnish
residue in tank.

2

NOTICE

LIFT POINT



55551

AVISO

Punto de izamiento

5

NOTICE

If safety or hazard decals or operator's
manual are missing from this equipment,
contact the manufacturer immediately at
1-800-888-9926 or (585) 229-5141

AVISO

Si las etiquetas de seguridad o peligro o el
manual del operador faltan en este equipo,
contactar inmediatamente al fabricante al
1-800-888-9926 o al (585) 229-5141.

55541

3

CAUTION

When equipment is not in use turn
the fuel valve to the OFF position.

PRECAUCIÓN

Cuando el equipo no esté en uso
gire la válvula de combustible a la
posición OFF (apagado)

55570

6



DECAL IDENTIFICATION

Item	Part Nbr	Qty	Description	Descripción	Description	Descrizione
1	55058	1	Decal Stone Logo with Star			
2	55214	1	Decal Sta-Bil			
3	55541	1	Decal Notice Missing Decals			
4	55546	1	Decal Instruction Engine Idle			
5	55551	1	Decal Notice Lift Point			
6	55570	1	Decal Caution Turn Off Fuel Valve			