



**NOTE: Seal Minder (Pos#27-2,33,50-33) is an optional component.
SV Series pumps come with Seal Minder cap only (Pos#27-3)**

Pos No	Part #	Description	Pos No	Part #	Description
01-2	202035	Bottom Plate	32	203161	Power Cord Line Clip
05	202116	Impeller Vortex	33	203163	Seal Minder Cable Line Clip
07	202187	Pump Housing w/ Bottom Plate	34	202517	Handle
07-1	202634	O-Ring (Kit Only)	35	202668	Rods Bolts
08	202211	Oil Chamber Cover	38	202534	Discharge Nipple 3"
08-1	202634	O-Ring (Kit Only)	38E	202557	Discharge Elbow
09	202231	Lip Seal Buna-N	38E-1	203208	Gasket, Disch. Elbow, Buna-N
13	200501	Mechanical Seal Buna-N	38F	203188	Discharge Flange 3"
13	200500	Mechanical Seal FKM**	38F	202606	Discharge Flange 4"
14	200958	Lower Ball Bearing	38F-1	201564	Gasket, Disch. Flange, Buna-N
17	203091	Rotor w/ Shaft 230V, 1 PH	50-01-2	203216	Screw for Bottom Plate
18	200514	Stator Coil w/ Casing 230V, 1PH	50-07	203283	Screw for Pump Housing
19	202360	Governor Switch w/ Switch Plate	50-08	203219	Screw for Oil Chamber Cover
20	200967	Upper Ball Bearing	50-11	203218	Screw for Oil Fill
21A	203019	Oil Chamber Housing	50-11-1	202634	O-Ring (Kit Only)
21A-1	202634	O-Ring (Kit Only)	50-12	203218	Screw for Pressure Check
21B	202368	Motor Cover Upper	50-12-1	202634	O-Ring (Kit Only)
23	202383	Overload Protector 0V, 1PH	50-19	202693	Screw for Gov. Switch
24	202420	Capacitor 230V	50-23	202700	Screw for Overload
26	202433	Pump Top Cover	50-27	203216	Screw for Power Cord
26-1	202634	O-Ring (Kit Only)	50-27-2	203216	Screw for Seal Minder Cable
27	201694	Power Cable w/ Gland-230V, 1PH, No F	50-31E	202692	Screw for Ground Wire
27-1	202634	O-Ring (Kit Only)	50-32	203214	Screw for Line Clip
27-2	202763	Seal Minder Cable	50-33	203214	Screw for Line Clip
27-2-1	202634	O-Ring (Kit Only)	50-34	203219	Bolt for Handle
27-3	203139	Oil Sensor Cap	50-38E	203267	Bolt for Discharge Elbow
31D	202409	Seal Minder Probe	50-38F	203277	Bolt for Discharge Flange
31E	203145	Ground Wire w/ Ring Term.			