




Ref#	Part#	Description	Qty Reqd
1	10009234	LOG SET	1
2	10009238	EMBER LAVA ROCK	1
3	10009626	CIRCUIT BOARD	1
4	10009199	REFRACTORY RIGHT SIDE	1
5	10009200	REFRACTORY LEFT SIDE	1
6	10001978	DC MOTOR (VARIABLE SPEED 12V DC)	1
7	10003350	FLAME GENERATOR ASSEMBLY	1
8	10009271	GLASS OPERABLE DOOR - LEFT	1
9	10009272	GLASS OPERABLE DOOR - RIGHT	1
10	10006454	SOCKET WITH WIRE ASSEMBLY	1
11	10003095	POWER CORD	1
12	10006538	FAN /HEATER ASSEMBLY- NOT AVAILABLE- SUBSTITUTE 10006404 + RE-USE EXISTING BRACKET	1
13	10006422	SCREEN DIFFUSOR	1

14	10009275	TRANSMITTER	1
1	10009235	LOG SET	1
2	10009238	EMBER LAVA ROCK	1
3	10009626	CIRCUIT BOARD	1
4	10009199	REFRACTORY RIGHT SIDE	1
5	10009200	REFRACTORY LEFT SIDE	1
6	10001978	DC MOTOR	1
7	10003350	FLAME GENERATOR ASSEMBLY	1
8	10009271	GLASS OPERABLE DOOR ASSEMBLY - LEFT	1
9	10009272	GLASS OPERABLE DOOR ASSEMBLY - RIGHT	1
10	10006454	SOCKET W/WIRE ASSEMBLY	1
11	10003095	POWER CORD	1
12	10006538	FAN /HEATER ASSEMBLY- NOT AVAILABLE- SUBSTITUTE 10006404 + RE-USE EXISTING BRACKET	1
13	10006422	SCREEN DIFFUSER	1
14	10009275	TRANSMITTER (REMOTE)	1

iBuyFireplaceParts.com 888-634-4289

iBuyFireplaceParts.com

iBuyFireplaceParts.com 888-634-4289