


PARTNER

ConstructionParts.com



888-634-4289

IPL, K 650 Active III, K 700 Active III, 2004-08, 106 27 55-65

K 650 Active III

K 700 Active III

Reservdelar

Spare parts

Ersatzteile

Pieces de rechange

Piezas de repuesto

Ricambi

Peças

sobresselente

ConstructionParts.com

ConstructionParts.com

888-634-4289

106 27 55-65


PARTNER

No.	Pos.	Description	No.	Pos.	Description
501 22 02-01	N	PLUG	503 23 00-11	F	WASHER
501 22 03-01	N	PLUG	503 23 00-42	J	WASHER
501 22 04-01	N	BALL	503 23 00-42	L	WASHER
501 22 05-01	N	SPRING	503 23 00-73	C	WASHER
501 22 08-01	N	GASKET, METERING SIDE	503 23 01-04	A	WASHER
501 22 09-01	N	METERING DIAPHRAGM	503 23 51-09	J	SPARK PLUG RCJ6Y
501 22 12-01	N	FUEL PUMP DIAPHRAGM	503 25 00-01	CE	BALL BEARING
501 22 13-01	N	GASKET, PUMP SIDE	503 25 21-01	A	BALL BEARING
501 22 14-01	N	CAP	503 26 02-04	C	SEALING RING
501 22 15-01	N	SCREW	503 26 30-21	P	O-RING
501 22 20-01	N	LEVER	503 28 90-17	D	PISTON RING
501 22 21-01	N	SHAFT	503 40 13-02	F	BRACKET LEFT
501 22 24-01	N	FILTER	503 40 17-01	F	CONTACT SPRING
501 22 25-01	N	SPRING	503 41 18-02	J	CABLE
501 42 71-01	N	BUSHING	503 49 10-01	D	GASKET
501 48 52-01	N	SCREW	503 53 40-01	N	NIPPLE
501 48 54-02	J	SPARK PLUG CONN. KIT	503 55 22-01	D	PLUG
501 49 48-02	N	DIAPHRAGM SET	503 57 86-01	N	BALL
501 53 16-01	J	CABLE	503 57 87-01	N	SCREW
501 63 48-01	J	SPRING	503 57 89-01	C	HOLDER
501 67 32-03	J	PAWL	503 65 27-01	N	SCREW
501 69 17-02	M	COMB.TOOL	503 65 30-01	N	WASHER
501 76 83-04	C	HOSE	503 65 31-01	N	WASHER
501 76 83-26	C	HOSE	503 71 53-01	D	VALVE DEKOMPR.
501 81 99-01	J	SCREW	503 74 43-01	C	SPRING
501 82 18-01	N	RETAINING RING	503 74 44-04	C	CLUTCH
503 12 79-02	H	STARTER HANDLE	503 77 98-01	N	VALVE
503 14 29-02	Q	WASHER	503 89 16-01	F	SPRING
503 15 59-02	F	BRACKET RIGHT	503 90 17-01	J	IGNITION MODULE
503 20 00-01	F	SCREW	504 35 72-01	C	FUEL FILTER
503 20 00-02	F	SCREW	505 26 76-73	F	SPACER
503 20 00-03	K	SCREW	505 26 94-27	F	THROTTLE ROD
503 20 00-04	G	SCREW	505 27 75-16	J	INSULATING CAP
503 20 00-05	D	SCREW	505 27 90-60	L	INSUL. FLANGE
503 20 00-07	CG	SCREW	505 27 91-03	F	THROTTLE CONTROL
503 20 00-08	CFG	SCREW	505 27 91-04	F	THROTTLE CATCH
503 20 00-10	F	SCREW	505 29 56-14	F	SPRING
503 20 00-16	G	SCREW	505 30 23-33	E	SUPPORT BUSHING
503 20 00-43	D	SCREW	505 30 24-15	C	SUPPORT BUSHING
503 20 00-45	A	SCREW	505 31 61-14	N	THROTTLE FLAP
503 20 02-12	B	SCREW	505 31 64-95	N	SEALING RING
503 20 02-16	Q	SCREW	505 31 65-50	N	INLET NEEDLE
503 20 02-35	G	SCREW	505 31 66-05	N	SPRING
503 20 02-90	K	SCREW	505 31 66-19	N	THROTTLE SHAFT
503 20 21-75	L	SCRUW	505 34 11-62	D	PISTON CPL 50 MM
503 20 25-20	J	SCREW	506 02 87-01	B	WASHER
503 20 30-11	A	SCREW	506 02 88-30	B	BUSHING
503 20 34-19	CGH	SCREW	506 03 88-01	B	WARNING LABLE
503 20 34-25	H	SCREW	506 07 08-01	A	SPACER
503 20 34-42	K	SCREW	506 07 11-13	C	HOSE
503 21 06-19	P	SCREW	506 09 56-02	P	CLAMP
503 21 06-25	G	SCREW	506 09 64-01	L	GASKET
503 21 06-43	G	SCREW	506 09 75-02	P	HOSE
503 21 07-22	H	SCREW	506 09 90-01	D	PISTON CPL
503 21 28-10	FH	SCREW	506 09 92-12	D	CYLINDER CPL.
503 22 04-01	J	NUT	506 13 95-11	B	WASHER
503 22 05-01	G	NUT	506 13 96-01	B	SCREW
503 22 65-04	Q	NUT	506 14 32-01	A	CATCH
503 22 65-04	FG	NUT	506 21 77-14	K	CYLINDER COVER
503 22 66-01	A	NUT	506 21 78-12	K	BASE
ConstructionParts.com			888-634-4289		


No.	Pos.	Description	No.	Pos.	Description
506 21 79-01	K	FILTER COVER	506 29 75-02	Q	HANDLE
506 21 86-02	J	FLYWEEL COMPL.	506 29 76-01	Q	HARNESS
506 21 89-02	H	STARTER DEVICE	506 29 83-63	A	SHAFT
506 21 90-01	H	AIR CONDUCTOR	506 29 88-01	P	SCREEN
506 21 91-01	C	GROMMET	506 30 23-01	Q	DECAL
506 21 98-01	K	AIR JET	506 30 25-02	Q	BRACKET
506 22 23-01	K	SEALING	506 30 40-22	Q	DECAL
506 22 24-01	K	SEALING	506 30 40-31	Q	DECAL
506 22 42-01	K	AIR FILTER	506 30 40-33	Q	DECAL
506 22 44-01	F	GUIDE	506 31 15-01	N	INSERT
506 22 45-01	F	CHOKE CONTROL	506 31 61-01	N	COVER
506 22 48-01	F	HOLDER	506 31 74-01	C	BUSHING
506 22 63-01	K	FILTER	506 31 77-11	P	VALVE CPL
506 23 54-02	H	DECAL	506 31 88-01	L	KNUCKLE
506 23 61-01	C	TANK VENT.	506 31 96-01	G	BRACKET
506 23 83-01	N	CHOKE FLAP	506 32 02-01	L	GASKET
506 23 93-01	K	DECAL	506 32 03-01	L	GASKET
506 24 37-13	D	CYLINDER	506 32 12-01	N	REPAIR KIT
506 25 14-01	H	WASHER	506 32 15-03	L	CARBURETOR
506 25 30-01	H	SPRING	506 32 15-03	N	CARBURETOR
506 25 59-32	C	TANK CAP	506 32 21-02	K	DECAL
506 25 61-01	C	TANK UNIT	506 32 22-01	Q	DECAL
506 25 81-02	H	STARTER PULLEY	506 32 48-01	B	FLANGE
506 25 82-01	K	GUARD	506 32 87-01	P	TUBE, Y
506 25 89-01	H	RETURN SPRING	506 32 89-03	P	WET CUTTING KIT
506 25 95-01	H	STARTER DEVICE	506 32 91-02	C	PROTECTOR
506 26 28-01	F	SPRING	506 33 16-01	C	SUPPORT BUSHING
506 26 30-02	F	STOP SWITCH	506 33 56-15	H	STARTER ROPE
506 26 31-01	H	SLEEVE	506 33 57-01	G	HANDLE
506 26 35-13	A	HOUSING	506 33 58-01	G	SUPPORT
506 26 41-01	C	FILTER	506 33 59-01	G	SUPPORT
506 26 41-11	C	FILTER	506 33 60-01	G	SUPPORT
506 26 63-02	BQ	LONING	506 33 61-01	G	SUPPORT
506 26 64-01	B	FLANGE	506 33 68-01	G	BRACKET
506 26 65-01	B	FLANGE	506 33 69-01	G	BRACKET
506 26 66-01	A	TENSIONER	506 33 94-01	C	COVER
506 26 68-01	A	SPRING	506 33 97-01	K	DECAL
506 26 85-01	L	SEALING	506 33 97-02	K	DECAL
506 27 11-01	C	PENDULUM	506 33 98-01	C	DECAL
506 27 14-01	N	SCREW	506 34 05-12	B	PROTECTOR
506 27 56-01	N	SHAFT	506 34 05-14	B	PROTECTOR
506 27 57-01	N	SEALING	506 34 05-28	Q	PROTECTOR
506 27 61-01	N	HOLDER	506 34 06-01	D	GASKET
506 27 84-32	K	DECAL	506 34 07-01	D	PLATE
506 27 84-41	K	DECAL	506 34 28-02	C	CRANCASE
506 27 84-43	K	DECAL	506 34 40-01	C	GASKET
506 27 94-01	A	SEALING	506 34 46-01	BQ	HANDLE
506 28 39-30	K	SEALING	506 34 56-01	C	PROTECTOR
506 28 40-02	B	LABEL	506 34 78-01	A	PULLEY
506 28 40-04	B	LABEL	506 34 82-01	G	CLAMP
506 28 40-12	B	LABEL	506 34 84-01	G	HANDLE WRAP
506 28 40-14	B	LABEL	506 34 88-01	M	GASKET SET
506 28 44-01	A	BOLT	506 35 08-03	F	HANDLE
506 28 73-01	A	NUT	506 35 08-04	F	HANDLE
506 28 84-01	B	FLANGE	506 35 10-01	E	CRANKSHAFT
506 29 21-01	C	GASKET	506 35 27-01	P	SPRING
506 29 56-01	P	NIPPLE	506 35 33-01	G	SPRING PCL
506 29 57-01	P	NIPPLE	506 35 37-01	G	SUPPORT
506 29 57-02	P	NIPPLE	506 35 51-01	G	HANDLE WRAP CPL
506 29 65-01	G	BRACKET	506 35 81-01	C	WHEEL CPL
ConstructionParts.com			888-634-4289		

No.	Pos.	Description	No.	Pos.	Description
506 36 80-01	C	PARTITION	888-634-4289		
506 37 27-06	A	BELT			
506 37 66-01	Q	DECAL			
506 37 96-20	B	BUSHING			
506 37 96-25	B	BUSHING			
506 38 08-14	D	MUFFLER			
506 38 59-01	P	HOSE			
506 38 69-01	F	VIBRATION ABSORBER			
506 38 78-34	J	CABLE			
506 39 48-01	F	HANDLE			
720 13 07-10	C	PIN			
721 42 58-20	F	SPRING PIN			
725 52 95-55	K	SCREW			
725 53 29-55	AB	SCREW			
725 53 31-55	BQ	SCREW			
735 58 18-00	F	LOCK WASHER			
735 88 06-00	E	WOODRUFF KEY			
737 43 12-00	D	RETAINING			
740 42 01-00	L	O-RING			
740 43 13-00	H	O-RING			
740 48 07-03	C	O-RING			
ConstructionParts.com			888-634-4289		

A



B



C**Crankcase:*****compl 506 34 28-02**

503 20 34-19

506 33 98-01

PARTNER

503 20 34-19 506 33 98-01

ConstructionParts.com

888-634-4289

506 32 91-02

503 74 43-01

compl 503 74 44-04**compl 506 35 81-01**

503 23 00-73

505 30 24-15

740 48 07-03

506 33 16-01

506 34 56-01

503 57 89-01

506 29 21-01

506 25 59-32

*****compl 506 07 11-13**

504 35 72-01***

501 76 83-04***

506 23 61-01***

506 21 91-01***

501 76 83-26

506 25 61-01

503 20 00-07 (x2)**503 20 00-08 (x5)****① *503 26 02-04**

506 36 80-01

ConstructionParts.com

720 13 07-10* (x2)

503 25 00-01*

*506 33 94-01

506 27 11-01**

506 26 41-01**

****compl 506 26 41-11****① *506 34 40-01**

*503 25 00-01

ConstructionParts.com

888-634-4289



① *503 26 02-04

*506 31 74-01

D

*compl 506 09 92-12


*compl 506 24 37-13 (EPA)

**E**


F

ConstructionParts.com

888-634-4289



ConstructionParts.com




ConstructionParts.com

888-634-4289

ConstructionParts.com

888-634-4289



ConstructionParts.com


888-634-4289

H


*compl 506 25 95-01

ConstructionParts.com

888-634-4289



J



ConstructionParts.com

888-634-4289

K

ConstructionParts.com

888-634-4289

ConstructionParts.com

ConstructionParts.com

888-634-4289




506 27 84-32
CE



506 27 84-43
EPA Canada



506 27 84-41
EPA USA




506 32 21-02

506 21 79-01

**506 25 82-01




**506 28 39-30




506 22 63-01

**compl 506 21 78-12

503 20 02-90




506 22 42-01



506 28 39-30*

*compl 506 21 77-14



506 23 93-01*

506 22 23-01



506 33 97-02




506 33 97-01



506 22 24-01

725 52 95-55



506 21 98-01


503 20 00-03

L

Carburettor kit:
*compl 506 32 15-03

ConstructionParts.com

888-634-4289




ConstructionParts.com

M



506 34 88-01 ①



ConstructionParts.com

888-634-4289


N

compl 506 32 15-03


Tillotson HS 175L

ConstructionParts.com

888-634-4289




506 32 12-01



*compl 501 49 48-02

ConstructionParts.com





ConstructionParts.com

888-634-4289

P Wet cutting kit
 *compl 506 32 89-03

ConstructionParts.com 888-634-4289



ConstructionParts.com 888-634-4289

		A, B, C mm		
Product		A (mm)	B (mm)	C (mm)
K650A-III	12"	240	45	240
K700A-III	14"	240	45	280

Q Rescue
*compl 506 34 05-28 (12")

ConstructionParts.com

888-634-4289

503 14 29-02

506 29 75-02

506 30 23-01

Rescue

PARTNER K650 **Rescue**
max 5100 rpm
Ø25,4(Ø1") - Ø300(Ø12")

506 37 66-01

506 32 22-01

⚠ ATTENTION ⚠
This product has been modified for use by
trained fire rescue personnel only.

506 30 40-22 (CE)



506 30 40-31 (EPA USA)



506 30 40-33 (EPA Canada)



ConstructionParts.com

*

506 29 76-01

**503 22 65-04 (x2)

ConstructionParts.com

**compl 506 30 25-02

**503 20 02-16 (x2)

888-634-4289