

PARTNER

ConstructionParts.com



888-634-4289

IPL, K950 Active, 2006-07, 544 08 64-02

ConstructionParts.com

K950 Active

Reservdelar

Spare parts

Ersatzteile

Pieces de rechange

Piezas de repuesto

Ricambi

***Peças
sobresselente***

ConstructionParts.com

888-634-4289

544 08 64-02


PARTNER®

No.	Pos.	Description	No.	Pos.	Description
501 22 03-01	M	PLUG	505 31 65-50	M	INLET NEEDLE
501 22 04-01	M	BALL	505 39 75-13	B	INFORMATION LABEL
501 22 05-01	M	SPRING	506 02 87-01	B	WASHER
501 22 12-01	M	FUEL PUMP DIAPHRAGM	506 02 88-30	B	BUSHING
501 22 13-01	M	GASKET, PUMP SIDE	506 07 08-01	A	SPACER
501 22 15-01	M	SCREW	506 07 09-01	B	WASHER
501 22 20-01	M	LEVER	506 07 18-02	A	PULLEY
501 22 21-01	M	SHAFT	506 09 56-02	P	CLAMP
501 22 25-01	M	SPRING	506 09 58-24	P	HOSE 800 MM
501 48 52-01	M	SCREW	506 09 75-02	P	HOSE
501 48 54-02	J	SPARK PLUG CONN. KIT	506 13 35-01	L	BRACKET
501 63 48-01	J	SPRING	506 13 95-11	AB	WASHER
501 67 32-03	J	PAWL	506 13 96-01	AB	SCREW
501 69 17-02	N	COMB.TOOL	506 14 32-01	A	CATCH
501 76 83-05	G	HOSE	506 15 55-06	E	CYLINDER CPL.
501 76 83-31	G	HOSE	506 15 56-02	E	PISTON
501 81 99-01	J	SCREW	506 15 82-01	E	GASKET
501 82 18-01	M	RETAINING RING	506 16 91-01	E	CONDUCTOR
501 83 98-01	J	SHORTING LEAD	506 21 68-12	G	TANK UNIT
502 21 58-01	N	ALLEN KEY	506 22 16-13	K	CYLINDER COVER
503 12 79-02	H	STARTER HANDLE	506 22 17-01	K	COVER
503 14 29-02	Q	WASHER	506 22 18-12	K	BASE
503 14 51-01	C	CLUTCH SPRING	506 22 19-01	L	PIPE
503 20 00-45	A	SCREW	506 22 22-02	H	AIR CONDUCTOR
503 20 02-12	B	SCREW	506 22 27-01	G	THROTTLE TRIGGER
503 20 02-16	EGKLQ	SCREW	506 22 28-01	G	THROTTLE LOCK
503 20 02-30	K	SCREW	506 22 29-01	G	SPRING
503 20 02-55	L	SCREW	506 22 31-01	L	ROD
503 20 25-20	J	SCREW	506 22 39-01	L	FLANGE
503 20 30-11	A	SCREW	506 22 94-01	K	JET
503 20 34-42	K	SCREW	506 23 12-01	L	GUIDE
503 20 59-20	CH	SCREW	506 23 13-01	G	HANDLE
503 21 05-22	G	SCREW	506 23 14-01	C	WHEEL
503 21 05-45	G	SCREW	506 23 14-02	C	WHEEL
503 21 06-19	P	SCREW	506 23 19-01	K	FILTER
503 21 28-06	J	SCREW	506 23 20-11	L	CHOKE CONTROL
503 21 28-10	H	SCREW	506 23 24-01	D	GASKET
503 21 67-22	H	SCREW	506 23 30-01	G	SUPPORT
503 22 10-11	J	NUT	506 23 33-05	D	CRANKCASE
503 22 65-04	Q	NUT	506 23 59-07	H	STARTER DEVICE
503 22 66-01	A	NUT	506 23 61-01	G	TANK VENT.
503 23 00-42	J	WASHER	506 23 75-01	G	SPRING
503 23 01-01	J	WASHER	506 24 39-01	K	DECAL
503 23 01-04	A	WASHER	506 25 14-01	H	WASHER
503 23 04-02	E	WASHER	506 25 30-01	H	SPRING
503 23 51-08	J	SPARK PLUG	506 25 59-32	G	TANK CAP
503 25 00-02	DF	BALL BEARING	506 25 64-02	M	INSERT
503 25 21-01	A	BALL BEARING	506 25 81-02	H	STARTER PULLEY
503 25 38-01	C	NEEDLE BEARING	506 25 84-01	M	GASKET
503 25 61-01	EF	TANK UNIT	506 25 85-01	M	DIAPHRAGM
503 26 02-05	D	SEALING RING	506 25 88-01	M	GASKET SET
503 26 30-21	P	O-RING	506 25 89-01	H	RETURN SPRING
503 26 60-01	P	FEMALE QUICK COUPLER	506 26 31-01	H	SLEEVE
503 28 04-02	LM	CARBURETOR	506 26 35-13	A	HOUSING
503 28 90-24	E	PISTON RING	506 26 41-01	G	FILTER
503 28 90-24	E	PISTON RING	506 26 41-11	G	FILTER
503 40 06-07	L	HOSE	506 26 54-01	C	CLUTH COVER
503 45 46-01	G	CONNECTION	506 26 63-02	BQ	LINING
503 46 85-01	G	ANTIVIBE ELEMENT	506 26 64-01	B	FLANGE
503 53 36-01	M	COVER	506 26 65-01	B	FLANGE
503 53 39-01	M	NIPPLE	506 26 66-01	A	TENSIONER
503 56 00-02	L	CLAMP	506 26 68-01	A	SPRING
503 57 76-02	G	HOSE	506 27 11-01	G	PENDULUM
503 57 86-01	M	BALL	506 27 14-01	M	SCREW
503 57 87-01	M	SCREW	506 27 23-01	H	DECAL
503 57 89-01	G	HOLDER	506 27 24-01	K	DECAL
503 66 56-01	E	VALVE	506 27 25-01	L	PROTECTOR
503 67 80-01	L	SLEEVE	506 27 27-01	J	FLYWHEEL
503 70 15-01	C	CLUTCH KPL.	506 27 31-01	D	BUFFER
503 78 26-74	F	CRANKSHAFT	506 27 63-01	M	REPAIR KIT
503 98 82-01	M	SCREEN	506 27 84-42	K	DECAL
505 27 75-16	J	INSULATING CAP	506 27 84-61	K	DECAL

No.	Pos.	Description	No.	Pos.	Description
506 27 84-63	K	DECAL	725 53 31-55	BQ	SCREW
506 27 92-01	A	COVER	725 53 40-55	D	SCREW
506 27 93-01	A	COVER	725 53 72-55	E	SCREW
506 28 39-30	K	SEALING	737 44 13-00	E	CLIP
506 28 39-30	K	SEALING	740 43 13-00	H	O-RING
506 28 40-02	B	LABEL	740 48 20-03	K	O-RING
506 28 40-04	B	LABEL			
506 28 40-12	B	LABEL			
506 28 40-14	B	LABEL			
506 28 40-22	B	LABEL			
506 28 40-24	B	LABEL			
506 28 44-01	A	BOLT			
506 28 53-01	G	SPRING			
506 28 59-01	C	SPACER SLEEVE			
506 28 63-01	M	SPRING			
506 28 68-01	M	COVER			
506 28 73-01	A	NUT			
506 28 84-01	B	FLANGE			
506 28 95-01	G	NIPPLE			
506 29 05-04	N	SET OF GASKETS			
506 29 09-01	M	THROTTLE SHAFT(KIT)			
506 29 10-01	M	SEALING, KIT			
506 29 11-01	M	CHOKE SHAFT (KIT)			
506 29 13-01	M	JET (KIT)			
506 29 21-01	G	GASKET			
506 29 56-01	P	NIPPLE			
506 29 57-02	P	NIPPLE			
506 29 75-01	Q	HANDLE			
506 29 76-01	Q	HARNESS			
506 29 79-01	G	PLATE			
506 29 83-63	A	SHAFT			
506 29 88-01	P	SCREEN			
506 30 23-01	Q	DECAL			
506 30 24-01	Q	DECAL			
506 30 25-01	Q	BRACKET CPL			
506 30 40-22	Q	DECAL			
506 30 40-31	Q	DECAL			
506 30 40-33	Q	DECAL			
506 31 07-01	C	DECAL			
506 31 77-11	P	VALVE CPL			
506 31 86-01	J	STOP SWITCH			
506 32 20-01	Q	DECAL			
506 32 21-01	K	DECAL			
506 32 22-01	Q	DECAL			
506 32 48-01	B	FLANGE			
506 32 87-01	P	Y TUBE			
506 32 89-03	P	WET CUTTING KIT			
506 33 56-15	H	STARTER ROPE			
506 33 72-02	H	STARTER DEVICE			
506 34 05-12	B	GUARD			
506 34 05-14	B	GUARD			
506 34 05-16	B	GUARD			
506 34 05-24	Q	GUARD			
506 34 46-01	BQ	HANDLE			
506 34 70-01	K	AIR FILTER			
506 34 74-03	A	BELT			
506 34 74-04	A	BELT			
506 34 78-01	A	PULLEY			
506 35 27-01	P	SPRING			
506 36 52-01	L	KNUCKLE			
506 37 27-03	A	V-BELT			
506 37 28-02	E	MUFFLER			
506 37 81-01	E	GASKET MUFFLER			
506 37 96-20	B	BUSHING			
506 37 96-25	B	BUSHING			
506 38 59-02	P	HOSE & VALVE CPL			
506 38 78-34	J	HOSE			
544 01 88-01	J	IGNITION MODULE			
544 38 31-01	G	SPRING			
720 12 40-20	G	PIN			
720 13 07-10	D	PIN			
725 53 29-55	AB	SCREW			


A

*compl 506 27 93-01 (12", 14")
*compl 506 27 92-01 (16")



B


*compl 506 34 05-12 (12")
*compl 506 34 05-14 (14")
*compl 506 34 05-16 (16")



• Maskinen får ej användas innan skylt med rätt spindelvarvtal monterats.
• The machine must not be used before the label is mounted stating correct spindle speed.
• Dieses Gerät darf erst nach montage des Typeschildes mit Spindelrehzahl-Angabe benutzt werden.
• La machine ne devra être mise en service qu'après installation préalable d'une plaque indiquant de la broche.

*505 39 75-13


C



ConstructionParts.com

D

Crankcase
*compl 506 23 33-05




E

Cylinder and piston
*compl 506 15 55-06

ConstructionParts.com


888-634-4289

Silencer, spare part
**compl 506 37 28-02



F

*compl 503 78 26-74




ConstructionParts.com

888-634-4289


G

ConstructionParts.com

888-634-4289




ConstructionParts.com




ConstructionParts.com

888-634-4289

H Starter compl 506 23 59-07



J



ConstructionParts.com



506 27 84-63
EPA Canada



503 20 02-16

ConstructionParts.com





888-634-4289

- 503 20 02-55 (x2)

ConstructionParts.com


888-634-4289

- 1 kit 506 25 88-01
- 2 kit 506 29 09-01
- 3 kit 506 29 10-01
- 4 kit 506 29 11-01
- 5 kit 506 27 63-01
- 6 kit 506 29 13-01



506 27 63-01⁵
Repair kit RK-31-HS

1 506 25 88-01
Diaphragm and gasket set DG-10-HS



ConstructionParts.com

888-634-4289



N Accessories
Zubehöre
Accessoires
Acessorios
Tillbehör

ConstructionParts.com

888-634-4289


501 69 17-02 (13-19mm)

502 21 58-01 (4mm)



506 29 05-04 (10)

Set of gaskets
Dichtungssatz
Jeu de joints
Juego de juntas
Packningssats





ConstructionParts.com

ConstructionParts.com

888-634-4289

P Wet cutting kit
 *compl 506 32 89-03

ConstructionParts.com 888-634-4289



		A, B, C mm		
Product		A (mm)	B (mm)	C (mm)
K950A	12"	240	45	240
	14"	240	45	280
	16"	270	45	360

ConstructionParts.com 888-634-4289

Q

Rescue
*compl 506 34 05-24 (14")

ConstructionParts.com

K12 FD
FIRE-RESCUE

506 29 75-01

506 32 20-01

503 14 29-02

506 30 23-01

Rescue

725 53 31-55*

506 34 46-01*

506 26 63-02*

ConstructionParts.com

*

506 29 76-01

**503 22 65-04 (x2)

ConstructionParts.com

**compl 506 30 25-01

**503 20 02-16 (x2)

506 30 24-01

PARTNER K950 Rescue
Max 5400 rpm
Ø 25,4(Ø1") - Ø350(Ø14")

506 32 22-01

ATTENTION
This product has been modified for use by
trained fire rescue personnel only.


506 30 40-22 (CE)



506 30 40-31 (EPA USA)



506 30 40-33 (EPA Canada)



888-634-1289