




IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.



**Stocked
at Depot**

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	
1	Face, Top Front (overlay only)	No longer available	24009	
2	Face, Upper Front (overlay only)	No longer available	12125E	
3	Smokeshield	No longer available	16759D	
4	Firescreen Assembly - Qty. 2 req.		11855A	Y
5	Refractory, Side - Qty. 2 req.		11821A	
6	Refractory, Back		11819A	
7	Grate		GR41	Y
8	Face, Bottom Front (overlay only)	No longer available	23922A	
9	Face, Lower Front (overlay only)	No longer available	12184D	
10	Refractory, Hearth		11822A	
	Ashlip Ceramic	No longer available	11820A	
	Ashlip Metal	No longer available	16762A	
	Damper Repair Kit		SRV32828	Y
	Firescreen Hairpin Clip	Pkg of 24	101025/24	Y
	Firescreen Rod	Qty 2 req	SRV11866	Y
	Smoke Baffle	No longer available	14078B	
	Smokeshield Extended	No longer available	12830A	
	Installation Instructions & Owner's Manual		12054i	