


# Earthquake®

## PARTS MANUAL **9800H 2-Person Earth Auger Powerhead** (Insert to OM9800B)



*Shown with optional  
14" tree potting auger*

TM9800H  
Rev. 10/16/06  
© 2006 Ardisam, Inc.  
All Rights Reserved. Printed in USA.

# EARTHQUAKE MODEL 9800H



MINIMUM ORDER ..... \$10.00

Part #	Description	Qty.
1423	BOLT, 5/16-18 X 2" HHCS GR5 .....	3
420	BOLT, 5/16-24 X 3/4" C-BORE .....	4
4814	BOLT, 10-24 X 1-1/4" PHILLIPS TRUSS HD .....	1
4819	TRIGGER ASSEMBLY LONG THROW .....	1
48300	BOLT, 5/16-18 X 2-1/4" HHCS GR5 .....	1
503	BOLT, 5/16-18 X 1-1/2" HH .....	8
504	LOCKWASHER, 5/16" SPRING .....	8
53596A	CLAMP, CABLE YELLOW ZINC .....	1
53664	TAB, THROTTLE .....	1
60G56	NUT-LOC, 5/16-18 BI-WAY .....	12
60G70	TOGGLE SWITCH, ON-OFF .....	1
8912	GEAR, 44T 3/4" HOLE .....	1
8913	SHAFT, OUTPUT 7/8" .....	1
8914	GEAR, 48T HARD .....	1
8915	DOWEL PIN, STEEL 1/4" X 1/2" .....	2
8919	GASKET, POWERHEAD TRANSMISSION .....	1
8922	BEARING, BALL R12 DOUBLE LIP .....	3
8923	BEARING, BALL R10 .....	2
8924	RING, SNAP EXTERNAL 3/4" .....	3
8929	BOLT, 1/4-20 X 1-1/2" SHCS .....	2
8935	BOLT, 1/4-20 X 2-1/2" SHCS .....	4
8939	GEAR CASE, LOWER HALF W/BEARINGS .....	1
8985	GEAR CASE, UPPER HALF W/BEARINGS .....	1
9016	CLUTCH DRUM, 3" THREADED .....	1
9211	HANDLE GRIP, 7/8" ID FLANGELESS .....	4
9214A	GEAR, 10T CLUSTER PINION HT .....	1
92TRAN	TRANSMISSION ASSEMBLY 30:1 .....	1
9805	CABLE ONLY, THROTTLE .....	1
9805A	CABLE ASSEMBLY, THROTTLE CONTROL .....	1
	(includes 9805, 4819, 4814)	
9814	GEAR, 7T PINION THREADED .....	1
9816	HANDLE .....	3
9817	HANDLE W/THROTTLE HOLE .....	1
9819	HANDLEBAR FRAME WELDMENT .....	1
9822	BEARING, BALL R14-2RS .....	1
9825	ROTOR ASSEMBLY, CENTRIFUGAL CLUTCH ..	1
9832	SPRING, THROTTLE CONTROL .....	1
9837A	MOUNT RING .....	1
9840	PLATE ADAPTER, MOUNT RING .....	1
9841	BRACKET, THROTTLE CABLE CLAMP .....	1
GCV160	ENGINE, 5.5 HP HONDA VERT SHAFT .....	1
IB5810	BOLT, 5MM X 0.8 X 10MM HH .....	1
IN58	NUT, 5MM X 0.8 NYLOC .....	1
WK6	WOODRUFF KEY #6 .....	1

