




Pos No	Part #	Description	Pos No	Part #	Description
01	201969	Strainer	27	204258	Power Cable w/ Gland-115V, 1PH
01-2	202007	Bottom Plate	27	201694	Power Cable w/ Gland-230V, 1PH,
02	202026	Suction Cover	27-1	202628	O-Ring (Kit Only)
05	202930	Impeller	27-2	202763	Seal Minder Cable
07	202163	Pump Housing	27-2-1	202628	O-Ring (Kit Only)
07	202628	O-Ring (Kit Only)	27-3	203139	Oil Sensor Cap
08	202211	Oil Chamber Cover	31D	202409	Seal Minder Probe
08	202628	O-Ring (Kit Only)	31E	203145	Ground Wire w/Ring Term.
09	202231	Lip Seal Buna-N	32	203161	Power Cord Line Clip /Strain-Relief
09	202233	Lip Seal FKM (Optional)	33	203163	Seal Minder Cable Line Clip
09	203053	Lip Seal EPDM (Optional)	34	202517	Handle
13	200501	Mechanical Seal Buna-N	35	202666	Holding Rods
13	200500	Mechanical Seal FKM**	38	202531	Discharge Nipple -
14	200958	Lower Ball Bearing	50-01	203238	Bolt - Strainer/Stand
15	200481	Impeller Shim Kit (Required)	50-02	203216	Screw
17	203086	Rotor w/ Shaft 115/230V, 1PH	50-08	203219	Screw
18	200511	Stator w/Casing,115V, 1PH	50-11	203218	Screw
18	200570	Stator w/Casing, 230V, 1PH	50-11-1	202628	O-Ring (Kit Only)
19	202360	Governor Switch w/Switch Plate	50-12	203218	Screw
20	200967	Upper Ball Bearing	50-12-1	202628	O-Ring (Kit Only)
21B	202368	Motor Cover	50-19	202693	Screw
23	202383	Overload 115V, 1PH	50-23	202700	Screw
23	202395	Overload 230V, 1PH	50-27	203216	Screw
24	202417	Capacitor 115V	50-27-2	203216	Screw for Seal Minder Cable
24	202418	Capacitor 230V	50-31E	202692	Screw
26	202433	Pump Top Cover	50-32	203214	Screw
26-1	202628	O-Ring (Kit Only)	50-33	203214	Screw
			50-34	203219	Screw