



HH1810 & HH2010 HYDRAPAK INSTRUCTIONS

6 PARTS LIST

The following parts list applies to the HH1810 & HH2010 HydraPaks only. Each item number on this parts list can be matched with the item number shown on the Figure 6-1 assembly drawing.

Item Number	Part Number	Quantity	Description
1	5625423	1	FEMALE FUEL QUICK DISCONNECT 1/4"
1	5625424	1	MALE FUEL QUICK DISCONNECT 1/4"
2	2542334	1	MAIN FRAME
3	2501743	1	FUEL TANK 6 GALLON
4	6403597	1	FUEL TANK RETAINING STRAP
5	2542345	1	HOISTING BRACKET
6	2510872	1	RESERVOIR
7	6000921	1	FILLER BREATHER CAP
8	6000908	1	SUCTION STRAINER ASSY
9	5800138	4	CLEVIS PIN ROUNDED SNAP
10	0514414	2	HANDLE W/GRIP
11	6001885	1	COUPLING 1/2" MALE
12	6001886	1	COUPLING 1/2" FEMALE
13	2514301	1	HEAT EXCHANGER ASSY
14	6010855	1	HEAT EXCHANGER CORE
15	5411513	1	FAN 12"
16	2542182	1	WIRE HARNESS
17	5800387	2	COTTER HAIR PIN
18	6901510	1	HYDRAULIC PUMP
20	5400861	1	BATTERY
20	5401564	1	BATTERY STRAP
21	6901501	1	HYDRAULIC PUMP BRACKET
21	6901502	1	PUMP ACCESS COVER
22	5493623	1	STARTER WIRE
23	5525620	1	ENGINE 20HP HONDA
23	5500672	1	ENGINE 18HP HONDA
24	5525621	1	MUFFLER
25	6015301	1	FLOW CONTROL VALVE
26	6015302	1	FLOW CONTROL HANDLE ASSY 10 POSITION
27	6061132	2	HANDLE ONLY FOR 3 POSITION & 10 POSITION ASSY'S
28	6015304	1	PRESSURE CONTROL HANDLE ASSY 3 POSITION
29	6015303	1	PRESSURE CONTROL VALVE
30	6001530	1	MANIFOLD
31	6015308	3	RELIEF VALVE
33	6015306	1	PILOT LOGIC ELEMENT (HV2310 ONLY)
34	6015305	1	CHECK VALVE
35	5401511	1	FAN RELAY
36	6725422	1	COUPLING HALF 1" – ENGINE
37	6725423	1	COUPLING INSERT
38	6725424	1	COUPLING HALF 3/4" – PUMP
	6725421		COUPLING HALF 5/8" - PUMP
39	2504743	1	AXLE—STANDARD TIRE
40	6004722	1	HYDRAULIC FILTER HEAD
42	6004723	1	HYDRAULIC FILTER ELEMENT
43	7600871	2	TIRE AND RIM ASSY—STANDARD
44	2501540	1	CONTROL PANEL
45	5701571	1	HOUR METER
46	5701972	1	PRESSURE GAGE
47	5701570	1	VOLT METER




Figure 6-1.
HydraPak Assembly Drawing