



Log Set Assembly




IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.



**Stocked
at Depot**

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	
	Log Assembly	No longer available	19877	
1	Log, Front	No longer available	19744A	
2	Log, Left	No longer available	19743A	
3	Log, Back	No longer available	20684A	
4	Log, Top Middle	No longer available	SRV18781	
5	Log, Bottom Middle	No longer available	SRV18757	
6	Log, Right	No longer available	SRV18780	
7	Face, Upper Front	No longer available	15674B	
8	Hood	No longer available	15675C	
9	Glass Panel		SRV15573	Y
10	Glass Frame	Qty 2 req	15687	
11	Firescreen Assembly		19196C	
	Burner Assembly	No longer available	18788A	
	Glass Seal	10 FT	28091/10	Y
	Lava Rock - 2 lbs.		4021-296	
	Vermiculite Shield	No longer available	18377F	
	Installation Instructions and Owner's Manual		20064	

#12 Electronic Ignition Wiring Diagram



IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.



**Stocked
at Depot**

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	
12.1	High Limit Switch		SRV4021-383	Y
12.2	Ignition Control Box		SRV15695	Y
12.3	Transformer		SRV20947	Y
12.4	Valve (R/S) - NG		71512	Y
	Valve (R/S) - LP	No longer available	71514	
	Valve (W/R)		SRV71511	Y
12.5	Ignitor		26542	Y
	Burner Orifice (.093) - NG		SRV16752	Y
	Burner Orifice (.052) - LP		SRV14047	Y
	Burner Tube (R/S)	No longer available	18115B	
	Burner Tube (W/R)	No longer available	18613A	
	Valve Bracket (W/R) - NG	No longer available	18795D	