

# EXCALIBUR 3S Manual

PLEASE NOTE THIS IS A TEMPORARY MANUAL


**KEENCUT**  
THE WORLD'S FINEST CUTTING MACHINES



Thank you for choosing the Keencut Excalibur 3S. Every effort has been made to bring you a precision engineered product with the promise of many years of valuable service. In order to obtain maximum benefit from your machine please read these instructions carefully. For advice and assistance or replacement parts please contact your distributor or Keencut.

Single language versions and parts diagrams can be down loaded from [www.keencut.co.uk](http://www.keencut.co.uk)

## 2.1 Unpacking your machine



**NOTE:** \* When lifting the main body from the box, DO NOT lift using the black handles on the cutters.

- |    |   |     |  |
|----|---|-----|--|
| 1. | Main body *                               | 7.  | Short support arm screws               |
| 2. | Squaring arm                              | 8.  | Long support arm fixing screws         |
| 3. | Left & right hand support arms            | 9.  | Leg fixing screws & washers            |
| 4. | Vertical scale & spare sightline strip    | 10. | Left hand production stop              |
| 5. | Wall mounting bracket                     | 11. | Right hand production stop             |
| 6. | Hexagon wrenches<br>2.0, 3.0, 5.0, 6.0 mm | 12. | Squaring adjuster block & fixing screw |
|    |   | 13. | Spare blades                           |