


Comfort Glow®

VENT-FREE FREESTANDING PEDESTAL STOVE SYSTEM OWNER'S OPERATION AND INSTALLATION MANUAL



We recommend that our products be installed and serviced by professionals who are certified in the U.S. by NFI (National Fireplace Institute).
www.nficertified.org

THERMOSTATICALLY - CONTROLLED MODELS CS26PT AND CS26NT 20,000 TO 26,000 BTU/HR


WARNING: If the information in this manual is not followed exactly, a fire or explosion may result causing property damage, personal injury, or loss of life.

- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- **WHAT TO DO IF YOU SMELL GAS**
 - Do not try to light any appliance.
 - Do not touch any electrical switch; do not use any phone in your building.
 - Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
 - If you cannot reach your gas supplier, call the fire department.
- Installation and service must be performed by a qualified installer, service agency, or the gas supplier.

Save this manual for future reference.

ILLUSTRATED PARTS BREAKDOWN

MODELS CS26PT AND CS26NT (Shown)



PARTS LIST


This list contains replaceable parts used in your heater. When ordering parts, follow the instructions listed under *Replacement Parts* on page 26 of this manual.

KEY NO.	PART NUMBER		DESCRIPTION	QTY.
	CS26PT	CS26NT		
1	113067-01	113067-01	Log Set	1
2	104286-01	104285-01	ODS Pilot	1
3	098249-01	098249-01	ODS Nut	2
4	112380-01	111331-15	Burner Outlet Tube	1
5	098522-28	098522-29	Thermostat Gas Valve	1
6	099056-29	099056-27	Burner Orifice Injector	1
7	101382-01	101382-01	Valve Bracket	1
8	102963-02	102963-02	Burner	1
9	099387-09	099387-09	Pilot Tube	1
10	098271-10	098271-10	Ignitor Cable	1
11	101381-01	101381-01	Piezo Ignitor and Cover	1
12	098867-10	098867-14	Regulator	1
13	112381-01	112381-01	Inlet Tube	1
14	**	**	Stove Firebox Bottom	1
15	099211-01	099211-01	Screw 10-26 x 2	2
PARTS AVAILABLE – NOT SHOWN				
	100563-01	100563-01	Warning Plate	1
	101054-01	101054-01	Lighting Instructions Plate	1

** Not a field replaceable part.

ILLUSTRATED PARTS BREAKDOWN

MODELS CS26PT AND CS26NT



PARTS LIST

MODELS CS26PT AND CS26NT

This list contains replaceable parts used in your heater. When ordering parts, follow the instructions listed under *Replacement Parts* on page 26 of this manual.

KEY NO.	PART NO.	DESCRIPTION	QTY.
1	112983-01CX	Stove Pedestal	1
2	112984-01CX	Left and Right Stove Sides	2
3	112985-01CX	Stove Top	1
4	112986-01BR	Stove Firebox Back	1
5	112987-01CX	Stove Base	1
6	112988-01BR	Stove Screen Assembly	1
7	099230-02	Screw, HWH Shldr AB 1-x.3	4
PARTS AVAILABLE – NOT SHOWN			
	101054-01	Lighting Instructions Plate	1
	100563-01	Warning Plate	1
	105657-01	Blower Bracket	2