


# PARTS LIST 1 B2435DR

## GENERAL ASSEMBLY



# PARTS LIST 1

## B2435DR


### GENERAL ASSEMBLY

ITEM NO.	PART #	DESCRIPTION	QTY.	REMARK
1	31249	CONTROL VALVE ASSEMBLY	1	
2	31250	HYDRAULIC HOSE ASSEMBLY	1	
3	31251	HANDLE ASSEMBLY	1	
4	14986	SHCS, M8x40	4	
5	11614	WASHER, LOCK, 8MM	9	
6	11667	WASHER, FLAT, 8MM	5	
7	31252	ROLL CAGE ASSEMBLY	1	
8	10176	SHCS, M12x35	4	
9	10735	WASHER, LOCK, 12MM	4	
10	10956	LOCK NUT, M12	4	
11	31173	WASHER, FLAT, 12MM	8	
12	31253	ENGINE MOUNTING PLATE	1	
13	31254	SLEEVE	1	
14	31255	CLUTCH	1	
15	31256	WASHER	1	
16	11619	HHCS, M8x25	1	
17	31257	V-BELT, B1016Li/B40	1	
18	31258	GASKET, INNER BELT GUARD	1	
19	31259	CLUTCH COVER, BELT GUARD	1	
20	11772	SHCS, M8x25	4	
21	31260	WASHER, LOCK, M16	4	
22	60138	LOCK NUT, M16	4	
23	11350	HHCS, M10x55	4	
24	11621	WASHER, LOCK, 10MM	4	
25	11802	LOCK NUT, M10	4	
26		ENGINE	1	
27	11003	KEY (1/4" SQx2")	1	
28	31261	CLAMP	1	
29	31262	CONNECTOR	1	
30	31263	SHCS, M12x150	6	
31	31264	EXCITER ASSEMBLY	1	
32	31265	SHCS, M12x50	4	
33	31266	GASKET	2	
34	31267	HEX PIPE PLUG	2	
35	31268	VIBRATION MOUNT	4	
178	31353	BASE PLATE ASSEMBLY	1	
179	31354	OIL DRAIN HOSE	1	

# PARTS LIST 2

## B2435DR

### BRIDGE ASSEMBLY



# PARTS LIST 2


## B2435DR

### BRIDGE ASSEMBLY

ITEM NO.	PART #	DESCRIPTION	QTY.	REMARK
100	31210	NUT, M16	1	
101	31260	WASHER, LOCK, 16MM	1	
102	31211	WASHER, FLAT, 16MM	1	
103	31269	SHAFT, TENSIONER	1	
104	31270	TENSION PULLEY	1	
105	31271	RETAINING RING, 42MM	1	
106	31272	BEARING	2	
107	31273	RETAINING RING, 20MM	1	
108	11515	SHCS, M8x15, HHCS, M8x16	9	
109	11614	WASHER, LOCK, 8MM	15	
110	11667	WASHER, FLAT, 8MM	15	
111	31274	SWITCH	1	
112	31275	COVER	1	
113	14447	WASHER, FLAT, 6MM	4	
114	11620	WASHER, LOCK, 6MM	4	
115	11618	HHCS, M6x12	4	
116	11841	HHCS, M6-1x45	2	
117	31276	CLAMP	1	
118	11620	WASHER, LOCK, 6MM	2	
119	50622	NUT, M6	1	
120	31277	BRIDGE PLATE	1	
121	11515	HHCS, M8x16	2	
122	10997	HHCS, M8x20	2	
123	31278	BRACKET	1	
124	11681	FHSCS, M8x16	9	
125	31246	VIBRATION MOUNT	4	
126	31279	BATTERY TRAY	1	
127	31280	SUPPORT ROD	1	
128	31287	BATTERY	1	
129	31282	BATTERY STRAP	1	
130	11617	LOCK NUT, M8	2	

# PARTS LIST 3 B2435DR

## ROLL CAGE ASSEMBLY



BartellParts.com  
800-889-0661

BartellParts.com  
800-889-0661

# PARTS LIST 3

## B2435DR


### ROLL CAGE ASSEMBLY

ITEM NO.	PART #	DESCRIPTION	QTY.	REMARK
85	31283	COVER PLATE, BACK	1	
86	14989	HHCS, M10x30	16	
87	31177	WASHER, FLAT, 10MM	16	
88	11621	WASHER, LOCK, 10MM	16	
89	11622	HEX NUT, M10	16	
90	31284	ROLL CAGE	1	
91	31285	HEX NUT, M18	2	
92	31286	PULL HANDLE	1	
93	31287	RUBBER COVER PLATE	1	
94	31288	MOUNTING STRIP	1	
95	11614	WASHER, LOCK, 8MM	2	
96	10997	HHCS, M8x20	2	
97	31289	COVER PLATE, LEFT	1	
98	31290	COVER PLATE, RIGHT	1	
99	31291	COVER PLATE, FRONT	1	

BartellParts.com  
800-889-0661

# PARTS LIST 4 B2435DR

## HANDLE ASSEMBLY



# PARTS LIST 4

## B2435DR


### HANDLE ASSEMBLY

ITEM NO.	PART #	DESCRIPTION	QTY.	REMARK
65	11635	HHCS, M6x30	2	
66	11620	WASHER, LOCK, 6MM	2	
67	14447	WASHER, FLAT, 6MM	2	
68	31284	THROTTLE CONTROL LEVER	1	
69	31292	HANDLE	1	
70	31293	THROTTLE CONTROL CABLE	1	
71	31294	SHCS, M8x20	4	
72	10997	WASHER	4	
73	31295	SLEEVE	1	
74	31296	VIBRATION MOUNT	1	
75	31297	VIBRATION MOUNT	2	
76	31298	STOP PLATE	2	
77	31299	NYLON SLEEVE	2	
78	31300	SLEEVE	2	
79	31260	WASHER, LOCK, 16MM	2	
80	31301	HHCS, M16x60	2	
81	31216	HEX NUT, M10	2	
82	14497	HHCS, M10x45	2	
83	11621	WASHER, LOCK, 10MM	1	
84	11802	LOCK NUT, M10	1	

BartellParts.com  
800-889-0661

# PARTS LIST 5 B2435DR

## CONTROL VALVE ASSEMBLY



# PARTS LIST 5


## B2435DR

### CONTROL VALVE ASSEMBLY

ITEM NO.	PART #	DESCRIPTION	QTY.	REMARK
36	14986	SHCS,M8x30	4	
37	11614	WASHER, LOCK, 8MM	8	
38	31302	HANDLE	2	
39	31303	SLEEVE	2	
40	31304	VIBRATION MOUNT	2	
41	10176	SHCS, M12x35	2	
42	10735	WASHER, LOCK, 12MM	2	
43	31305	MOUNTING PLATE	2	
44	11769	SHCS, M8x6	4	
45	31306	NYLON WASHER	2	
46	31307	SLEEVE	2	
47	31247	ORING, 26x2.65	4	
48	31248	ORING, 38.7x2.65	2	
49	31308	GEAR SHAFT	1	
50	31357	HYDRAULIC HOUSING	1	
51	31309	HEX PIPE PLUG	1	
52	31310	GASKET	1	
53	31311	SLEEVE	1	
54	31312	SPRING, OUTER	1	
55	31313	SPRING, INNER	1	
56	31314	RIVET, 6x6	2	
57	31315	SCREW, M6x8	1	
58	31316	GEAR RACK	1	
59	31317	PISTON	1	
60	14985	SHCS, M12x30	1	
61	31318	PACKING	1	
62	31319	ORING, 60x3-1	1	
63	31320	SEAL PLATE	1	
64	14986	SHCS, M8x30	4	

# PARTS LIST 6 B2435DR

## EXCITER ASSEMBLY



# PARTS LIST 6

## B2435DR

### EXCITER ASSEMBLY

ITEM NO.	PART #	DESCRIPTION	QTY.	REMARK
131	11028	SHCS, M6x30	1	
132	31321	CLAMP	1	
133	31322	WASHER	1	
134	11620	WASHER, LOCK, 6MM	16	
135	60731	SHCS, M6x20	16	
136	14447	WASHER, FLAT, 6MM	16	
137	31323	BEARING COVER	2	
138	31324	ORING, 90x2.65	4	
139	31325	BEARING	4	
140	31326	DRIVEN SHAFT	1	
141	31327	KEY, 10x32	1	
142	31328	RETAINING RING, 50MM	2	
143	31329	ECCENTRIC WEIGHT	2	
144	31330	WASHER, LOCK, 16MM	5	
145	11842	SHCS, M16x40	4	
146	31331	DRIVEN GEAR	1	
147	31332	ECCENTRIC WEIGHT	2	
148	31333	GEAR	1	
149	31334	RETAINING RING, 100MM	1	
150	31335	PIN	1	
151	31355	BEARING	1	
152	31336	RETAINING RING, 52MM	2	
153	31337	VIBRATION BOX	1	
154	31338	ECCENTRIC WEIGHT	1	
155	11843	SHCS, M16x60	1	
156	31339	COVER	1	
157	31340	SHAFT	1	
158	31341	LIP SEAL	1	
159	31342	INNER BEARING	1	
160	31343	CYLINDER COVER	1	

# PARTS LIST 6

## B2435DR

### EXCITER ASSEMBLY - cont.

ITEM NO.	PART #	DESCRIPTION	4QTY.	REMARK
161	31344	GASKET	1	
162	11618	HHCS, M6x12	1	
163	31345	GASKET, RUBBER	1	
164	31346	CONNECTING SLEEVE	1	
165	80054	SHCS, M5x12	1	
166	11844	WASHER, LOCK, 5MM	1	
167	30846	WASHER, FLAT, 5MM	1	
168	31356	BEARING	2	
169	31347	RETAINING RING, 25MM	1	
170	31348	DRIVE SHAFT	1	
171	31349	ORING, 36x2.65	1	
172	31350	BELT GUARD	1	
173	31351	PULLEY	1	
174	31352	COVER PLATE	1	
175	11667	WASHER, FLAT, 8MM	4	
176	11614	WASHER, LOCK, 8MM	4	
177	11515	HHCS, 8x16	4	

BartellParts.com  
800-889-0661

# PARTS LIST 4 B1728R

## LABELS



ITEM NO.	PART NO.	DESCRIPTION	QTY.	REMARK
A	PC230	WARNING LABEL - HOT BESIDE	1	
B	PC231	WARNING LABEL - HOT BELOW	1	
C	PC140	DANGER LABEL - GENERAL	1	
D	PC110	WARNING LABEL - PPE	1	
E	PC400	WARNING LABEL - FINGER HAZARD	1	
F	109dB	NOTICE LABEL - NOISE	1	
G	PC220	INSTRUCTION LABEL - THROTTLE	1	
H	PC200	INSTRUCTION LABEL - LIFT POINT	1	
J	PC221	INSTRUCTION LABEL - THROTTLE	1	
K	PC211	CAUTION LABEL - READ INSTRUCTIONS	1	