


VCS3505BI/VCS5005BI ASSEMBLY DRAWING



iBuyGrillParts.com

888-634-4289

VCS3505BI/VCS5005BI PARTS LIST

ITEM	DESCRIPTION	No. Req'd.	VCS5005BI
1	Base Assembly BI	1	50003241
2	Heat Shield Console	1	50003060
3	Ignitor Assembly Kit	1	50001619
4	Console Bent & Printed BI	1	50003224
5	Bottom Cover BI	1	50001946
6	Bracket Right BI	1	50001947
7	Facia Assembly BI	1	50002106
8	Cover Rear BI	1	50001949
9	Grease Tray	1	50001950
10	Front Grease Tray	1	50001951
11	Console Reinforcement	1	50003024
12	Lid Assembly Rear	1	50001538
13a	Valve 20 Deg. Manifold Assembly-LP	1	50002826
13b	Valve 20 Deg. Manifold Assembly-NG	1	50002827
14a	Regulator LP	1	50000804
14b	12" Hose Assembly-Natural Gas	1	50000198
14c	Connector Hose-Natural Gas	1	50000915
15	Bezel	4 / 6	50003002
16	Ignitor Push button	1	50001011
17	Main Burner Assembly	3 / 5	50000835
18	Gasket Burner	3 / 5	50000892
19	Flash Tube	1	50000880
20	Rotisserie Housing/Screen Assembly	1	50003120
21	Burner Rotisserie Assembly	1	50003127
22a	Tube & Orifice Assembly-LP	1	50000819
22b	Tube & Orifice Assembly-NG	1	50000818
23	Electrode Rotisserie	1	50003129
24	Plate Heat-S/S	3 / 5	50000777
25	Hardware Lid Set	1	50000355
26	Lid Assembly Front-S/S	1	50003070
27	Harness - Backlit Knob H5 + Rotisserie	1	50003000
28	Lid Bumpers	4 / 6	50000177
29	Warming Rack Enamel	1	50000889
30	Cook Grate Set	1	50001227
31	Griddle Plate	1	50002241
32	Rotisserie Kit	1	50002102
33	Handle Grip Set - Charcoal	1	50000642
34	Battery Case - Backlit Knob	1	50003110
35	Spit Rod	1	50000962
36	Knob Valve	4 / 6	50003003
37	Handle Door	1	50000313
38	Hardware Bag	1	50002105
39	Flexible connector 28"	1	50000672