



Log Set Assembly



IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.

ITEM	DESCRIPTION	COMMENTS	PART NUMBER
	Log Set Assembly (sold as complete log set only)		LOGS-MS
1	Door Assembly - Side	No longer available	418-240A
2	Glass Door Assembly - Side		GLA-PIER
3	Flex Assembly		302-330A
4	Burner Orifice NG		506-800
	Burner Orifice LP		446-801
5	Tube Assembly		567-301A
6	Log Grate		674-364
7	Burner Assembly - NG		501-272A
	Burner Assembly - LP		501-273A
8	Door Assembly - End		DF-PTRCE
9	Glass Door Assembly - End		GLA-PTRC-E
10	Base Refractory	No longer available	SRV504-738-UM
11	Refractory, Rear	No longer available	SRV504-737-UM
	Piezo Ignitor		291-513
	Pilot Assembly - NG		529-540A
	Pilot Assembly - LP		529-541A
	Pilot Orifice - NG		529-512
	Pilot Orifice - LP		529-513
	ON/OFF Rocker Switch		SRV060-511
	Valve - NG		060-524
	Valve - LP		060-526