PARTS LIST FOR FRHR-100N/P/PQD

Part Number	Part Description	
FRHP-01NG	GAS CONTROL VALVE C/W THERMOSTAT - NG	
FRHP-01LP	GAS CONTROL VALVE C/W THERMOSTAT - LP	
FRHP-01WR	GAS CONTROL VALVE NO THERMOSTAT	
FRHP-02NG	PILOT ASSEMBLY - NG	
FRHP-02LP	PILOT ASSEMBLY - LP	
FRHP-03	PILOT LINE (1999 - 2003)	
FRHP-03A	PILOT LINE (CURRENT)	
FRHP-03WR	PILOT LINE (FOR USE WITH WR CONTROL)	
FRHP-04A	CUT-OFF SWITCH	
T-18	18" THERMOCOUPLE	
FRHP-05	BURNER ASSEMBLY (FOR OLD FRH-100)	
FRHP-05RLP	BURNER ORIFICE LP (CURRENT)	
FRHP-05NG	BURNER ORIFICE NG (CURRENT)	
FRHP-06LP	BURNER ORIFICE LP (FOR OLD FRH-100)	
FRHP-06NG	BURNER ORIFICE NG (FOR OLD FHH-100)	
FRHP-07RLP	BURNER ASSEMBLY- LP (CURRENT)	
FRHP-07RNG	BURNER ASSEMBLY - NG (CURRENT)	
FRHP-08R	STAINLESS EMITTER GRID (CURRENT)	
FRHP-09	TIP-OVER SWITCH C/W WIRE	
FRHP-10	3/8" LOW PRESSURE FIRE LINE C/W FLARE NUTS	
FRHP-10WR	3/8" LOW PRESSURE FIRE LINE C/W FLARE NUTS (FOR WR CONTROL)	
FRHP-11	REDUCING NIPPLE 1/2" X 3/8"	
FRHP-12	SAFETY SCREEN ASSEMBLY (TWO REQUIRED)	
FRHP-13A	TWO STAGE REGULATRO - LP	
FRHP-13A	SINGLE STAGE REGULATOR - C/W POL	
FRHP-14	BRASS ELBOW C/W TEST POINT (USE FOR WR CONTROL)	
FRHP-15	NG REGULATOR (USE FOR WR CONTROL)	
FRHP-16	3/8" X 5" NIPPLE (USE FOR WR CONTROL)	
FRHP-17	1/2" NG REGULATOR (5PSI MAX)	
FRHP-18	THERMO BULB BRACKET C/W GROMMETS	
FRHP-19	BLACK CONTROL KNOB (FOR WR CONTROL)	
FRHP-20	3/4" NG REGULATOR (5 PSI MAX)	

FRHP-21	1/4" COMPRESSION NUT & SLEEVE FOR PILOT LINE	
FRHP-22	1/4" EXTENDED BREAKAWAY FOR PILOT LINE	
FRHP-50	CONVERSION KIT FOR FRHR NG TO LP (CDN)	
FRHP-51	CONVERSION KIT FOR FRHR LP TO NG (CDN)	
FRHP-52	CONVERSION KIT FOR FRHR LP TO NG (USA)	
FRHP-53	CONVERSION KIT FOR FRHR NG TO LP (USA)	
S52600-12	3/4ID MNPT X MNPT 50FT HOSE ASSEMBLY	
2103-E-CGA	3/4" FNPT BALL VALVE	
100-006	3/8" QUICK DISCONNECT SOCKET - FEMALE	
100-506	3/8" QUICK DISCONNECT PLUG - MALE	
100-008	1/2" QUICK DISCONNECT SOCKET - FEMALE	
100-508	1/2" QUICK DISCONNECT PLUG - MALE	
100-010	3/4" QUICK DISCONNECT SOCKET - FEMALE	
100-510	3/4" QUICK DISCONNECT PLUG - MALE	

	ACCESSORIES	
FRHP-101	NG HOSE ASSEMBLY - C/W 50FT X 3/4" TYPE 1 , 3/4" BALL VALVE, 1/2" FEMALE QD SOCKET & 3/4" MALE QD PLUG	
FRHP-101600LP	LP HOSE ASSEMBLY - C/W 50FT 1/2" TYPE 1 HOSE, 1/2" BALL VALVE, 3/8" FEMALE QD SOCKET & FITTED REGULATOR	
MAN-E1	SINGLE MANIFOLD - ENBRIDGE	
MAN-E2	DUAL MANIFOLD - EMBRIDGE	
MAN-U1	SINGLE MANIFOLD - UNION GAS	
MAN-U2	DUAL MANIFOLD - UNION GAS	

FRHR-100 Parts List



FRHR-100 Parts List



FRHR-100 Parts List



FRHR-100 Parts List



FRHR-100 Parts List

Item #	*Description*	*P/N*
1	Removable Screen Assy	FRHP-12
2	SS Emitter Grid Assy	FRHP-08R
3	3/8" Low Pressure Line	FHRP-10
4	3/8" Flare x 3/8" MP Elbow	49-6C
5	Gas Control Valve	FRHP-01 LP/NG
6	Green Control Knob/Black Knob	FRHP-23/FRHP-19
7	Pilot Line	FRHP-03A
8	Propane QD Model	122-CD/100-506
9	Natural Gas QD Model	122-DC/100-506
10	Propane SAE Model	48-6C
11	Propane Burner Assy	FRHP-07RLP
12	Natural Gas Burner Assy	FRHP-07RNG
13	Burner Fitting	46-6C
14	Tipover Switch	FRHP-09
15	ECO Cutoff Switch	FRHP-04A
16	Main Burner Orifice-NG	FRHP-05RNG
17	Main Burner Orifice-LP	FRHP-05RLP
18	Thermocouple	T-18
19	Pilot Assembly- LP	FRHP-02LP
20	Pilot Assembly- NG	FRHP-02NG
21	50 FT Propane Hose	FRHP-101600LP
22	50 FT NG Hose	FRHP-101
23	Union Gas Single Manifold	MAN-U1
24	Union Gas Douible Manifold	MAN-U2
25	Enbridge Manifold	MAN-E1
26	Enbridge Double Manifold	MAN-E2
27	Enbridge Nipple	MAN-NP
28	Enbridge Meter Key	MAN-Key

Accessories

HOSES

21

22

MANIFOLDS

23





25

24 Not shown

26 Not shown

METER

27





28