




IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.



**Stocked
at Depot**

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	
1	Starter Collar		30399	
2	Top Standoff		SRV4044-111	
3	Screen Rod		31375	Y
4	Screen Assembly	Qty 2 req	30371	
6	Grate		GR21	Y
6	Refractory Retainer	Qty 3 req	SRV11847	
7	Back Refractory		28394	
8	Side Refractory	Qty 2 req	28393	
9	Hearth Refractory with Ashlip		28391	
	Chrome-plated Screw with Gripper Head	Qty 6 req	SRV31076	
	Damper Blade Assembly	No longer available	30378	
	Door Clips	Qty 2 req	30407	
	Door Pivot Clip	Qty 2 req	SRV31527	
	Hearth Filler		30403	
	Nailing Flange	Qty 4 req	31190	
	Smoke Shield		30402	
	Strip Protector	Qty 2 req	SRV18320	
	Top Door Track		30400	
	Installation Instructions		35035	