




PARTS ORDER FORM

Doc # VC9086

iBuyGrillParts.com

888-634-4289



iBuyGrillParts.com

888-634-4289



PARTS ORDER FORM

Doc # VC9086

✓	REF	DESCRIPTION	QTY	PART #
☐	1	CABINET END HD - BLACK	2	50001929
☐	2	CABINET FORM - BLACK	4	50002198
☐	3	STRUT	3	50001841
☐	4	PANEL TANK	1	50001936
☐	5	PANEL BACK	1	50001879
☐	6	HEAT SHIELD CABINET	1	50001877B
☐	7	HEAT SHIELD HOSE	1	50001817
☐	8	BASE ASSY - NEEDS MANAGER APPROVAL	1	50001816
☐	9	GREASE PAN SUPPORT	2	50001844B
☐	10	GREASE PAN ASSY	1	50002157
☐	NS	GREASE CUP - SALE ONLY (Wear & tear item)	1	50001845
☐	11	HEAT SHIELD	1	50000857B
☐	12	FRONT LIP	1	50001819B
☐	13	FLASH TUBE	1	50000880B
☐	14	BURNER TUBE with SHORT ELECTRODE	2	50003100
☐		BURNER TUBE with LONG ELECTRODE	3	50003133
☐	NS	BURNER REPAIR KIT - to be sent out when the base assembly has rusted through at the point of attachment with the burner.	1	50003457
☐	15	ELECTRODE MAIN LONG	3	50000523
☐	16	ELECTRODE MAIN SHORT	2	50000431
☐	17	BURNER GASKET	5	50000892
☐	18	CONSOLE ASSY	1	50001223
☐	19A	VALVE ASSY - LP - NEEDS TECH APPROVAL	1	50000803
☐	19B	VALVE ASSY - NG - NEEDS TECH APPROVAL	1	50000852
☐	20B	REGULATOR ASSY	1	50000804
☐	20C	HOSE 12' - NG	1	50000198
☐	20D	CONNECTOR HOSE - NG	1	50000915
☐	21	BEZEL	6	50001327
☐	22	PANEL, UPPER REAR	1	50000854
✓	REF	DESCRIPTION	QTY	PART #
☐	23	IGNITOR MODULE (Push button <u>NOT</u> included)	1	50001619



PARTS ORDER FORM

Doc # VC9086

☐	24	IGNITOR PUSH BUTTON (send with 50001619)	1	50001011
☐	25	ROTISSERIE HOUSING/SCREEN ASSY	1	50000961
☐	26	BURNER ASSY - ROTISSERIE	1	50000875
☐	28	ELECTRODE ROTISSERIE	1	50003129
☐	29	LID ASSY REAR - Also send p/n 50000355.	1	50003516
☐	30	PIVOT PIN & BOLT SET - Send with lid assembly	1	50000355
☐	31	LID ASSY FRONT - Also send p/n 50000355.	1	50000861
☐	32	LID BUMPERS	6	50000177
☐	33	BRACKET, LOWER DOOR ASSY PIVOT	2	50002034B
☐	34	BRACKET, UPPER DOOR - OBSOLETE	2	50002032B
☐	35	1/4" NYLON WASHER	2	50002029
☐	36	DOOR ASSY S/S - PIVOTED	2	50002036
☐	37	ANCHOR NUT	2	50000326
☐	38	SHOULDER SCREW #8-15 PAN QUAD X 5/8	2	50000191
☐	39	FRONT WARMING DRAWER ASSY	1	50001942
☐	40	WARMING RACK (ENAMEL) - Not warrantied against chipping, scratching or rust (must chip to rust).	1	50000889
☐	41	SPIT ROD	1	50000962
☐	42	TEMPERATURE GAUGE	1	50001643
☐	43	SHELF, FRONT RIGHT S/S	1	50000984B
☐	44	SHELF, FRONT LEFT S/S	1	50000986B
☐	45	SUPPORT SHELF BLACK - Left rear & right front	2	50001418
☐	46	SUPPORT SHELF BLACK - Right rear & left front	2	50001419
☐	47A	SHELF TOP SOLID - FOR SIDE TABLE	1	50001413B
☐	47B	SHELF TOP - SIDE BURNER	1	50000824
☐	47C	SHELF INSERT	1	50000826B
☐	48	CASTER (POP IN)	4	50000090
✓	REF	DESCRIPTION	QTY	PART #
☐	49	DOOR HANDLE, DELUXE	3	50000313
☐	50	HEAT PLATE S/S	5	50000777
☐	51	COOKING GRIDS (PACK OF 4 ONLY) - Not warrantied against chipping, scratching or rust (must chip to rust).	1	50001227



PARTS ORDER FORM

Doc # VC9086

☐	52	ROTISSERIE BRACKET MOTOR	1	50000885
☐	53	ROTISSERIE SPIT ROD SUPPORT	1	50000399
☐	54	ROTISSERIE MOTOR - NA, send 5-3116 instead.	1	50000161
☐	N/S	HARDWARE BAG	1	50002130
☐	N/S	CONSOLE REPAIR KIT - to be sent out to the customer if they complain that the cooking grids are falling into the tub. Attaches to the back of the tub.	1	50003433
☐	N/S	BBQ COVER - SALE ITEM	1	VC303-3666
☐	N/S	ROTISSERIE - NEED TO SEND THE SPIT ROD P/N 50000962. SALE ITEM.	1	50003116
☐	N/S	SPIT ROD (SEND WITH ABOVE)	1	50000962
☐	N/S	➔ TOTAL ROTISSERIE COST		BOTH
☐	N/S	GRIDDLE - replaces one cooking grid. SALE ITEM.	1	VCGP1A

iBuyGrillParts.com

iBuyGrillParts.com

888-634-4289