



# Main Frame Assembly



## Main Frame Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	125-8685-03	1	Frame	17	ST27144-03	1	Guard-Pinion
2	ST32032	2	Bushing-Nylon	18	104-8300	1	Nut-Flange, NI
3	ST22029	1	Shaft-Tilt	19	ST46042	2	Fitting-Grease
4	ST22096-03	1	Handwheel	20	ST47001	2	Cap-Plug
5	32121-27	1	Pin-Roll	24	ST21875-03	1	Post-Foot
6	ST27559-03	2	Bracket-Handle	25	ST21874-03	2	Leg-Stabilizer
7	ST27619-03	1	Dog-Brake	26	ST80039	2	Pin-Clevis, Lanyard
8	127-5593	1	Handle-Brake	27	3290-500	2	Screw-PPH
9	3234-24	1	Screw-HHF	28	3296-2	2	Nut-Lock, NI
10	104-8301	1	Nut-Flange, NI	30	99-5107	2	Nut-Lock
11	701243	4	Screw-HWHTF	31	325-22	2	Screw-HH
12	ST24349-03	2	Trunnion	33	ST80031	4	Screw-HWH
13	125-6308	1	Yoke ASM	35	99-4693	1	Decal
14	ST27617-03	1	Guard-Brake, Upper	36	125-8175	2	Decal-Grease
16	ST27618-03	1	Guard-Brake, Lower				


# Axle Assembly



## Axle Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	ST26971	2	Spring-Leaf	7	ST34972	2	Spring-Coil
2	ST26195	2	Bolt-U	8	125-8171	2	Hub ASM
3	ST21873-03	1	Axle-Spring	9	ST32307	2	Tire And Rim ASM
4	100-6116	4	Screw-HHF	10	3256-28	2	Washer-Flat
5	99-5107	10	Nut-Lock	11	ST80054	2	Nut
6	325-33	2	Screw-HH	12	3272-13	2	Pin-Cotter

# Hub Assembly No. 125-8171




## Hub Assembly No. 125-8171 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2	ST39190	4	Stud-Wheel
3	ST32233	2	Bearing-Roller
4	ST80045	4	Nut-Lug

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
5	ST34573	1	Cap-Dust
6	ST32052	1	Seal-Hub, Wheel

# Engine and Belt Assembly




## Engine and Belt Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	ST21487	1	Shaft-Drive	8	ST34984	1	Sheave
2	127-7579-03	1	Base-Engine, 95Cm	9	127-0075	2	Belt-V
3	125-4812	1	Engine-Honda, Gx240 ●	10	100-6116	4	Screw-HHF
4	108-3742	4	Screw-HHF	11	ST26326	4	Washer-Flat
5	104-8301	4	Nut-Flange, NI	12	99-5107	4	Nut-Lock
6	5-7280	2	Key	13	909546	2	Screw-Set
7	ST34986-03	1	Sheave				

● Obtain parts from [www.honda-engines.com](http://www.honda-engines.com)


# Drum Assembly



## Drum Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	125-6306-01	1	Drum	9	ST27413	1	Washer-Flat
2	325-6	1	Screw-HH	10	ST32086	1	Bearing
3	325-7	6	Screw-HH	11	ST32161	1	Bearing-Roller
4	327-4	1	Screw-HH	12	ST46022	1	Plug
5	99-5107	6	Nut-Lock	13	ST46057	1	Fitting
6	ST26317-01	1	Gear-Ring	14	ST47001	1	Cap-Plug
7	ST26326	6	Washer-Flat	15	3256-6	12	Washer-Flat
8	ST27267	1	Spindle				

# Cowl Assembly



## Cowl Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	127-2811	1	Stationary Cowl ASM	8	125-4877	1	Harness-Wire, Mixer
1:2	125-4940	1	Decal-Stop, Engine	9	ST47182	3	Latch-Rubber
1:3	117-2718	1	Decal-Arrester, Spark	10	67-7320	2	Decal
2	701243	2	Screw-HWHTF	14	125-4937	2	Decal
3	3234-38	4	Screw-HHF	15	125-8218-03	1	Plate-Engine
4	99-5107	4	Nut-Lock	16	110-9380	2	Screw-HWH
5	127-1685	1	Movable Cowl ASM	17	125-4942	1	Decal
5:2	125-4939	1	Decal-Warning	19	3256-4	2	Washer-Flat
6	ST44368	1	Pin	20	3256-6	2	Washer-Flat
7	95-8999	1	Switch				

# Attachments and Accessories

## For 68007 CM-958H-SED Concrete Mixer

**Product Name**

**Model/Part**

Trailer Light Kit..... 68063