


EXPLODED PARTS



PART #	DESCRIPTION	Qty
1	Knob of Angle Guide	1
2	Angle Guide	1
3	Base of Angle Guide	1
4	Nut (M6)	2
5	Shank w/ Square Neck	1
6	Shank Sleeve	1
7	Cam	1
8	Spanner of Rip Guide	1
9	Elastic Pin (3x25)	1
10	Holddown Block	1
11	Round Pin	2
12	Rip Guide	1
13	Compression Spring	1
14	Anti-Slip Pad	1
15	Block of Rip Guide	1
16	Measure Guide (A)	1
17	Handle Grip (Upper)	1
18	Master Table	1
19	Measure Guide (B)	1
20	Knob of Blade Guard	1
21	Blade Guard	1
22	Bracket of Blade Guard	1
23	Cross Recessed Pan Head Screw (M5X10)	4
24	Right Table	1
25	Positioning Spring of Right Table	1
26	Elastic Washer 5	1
27	Cross Recessed Countersunk Head Screw (M5X10)	1
28	Miter Table Support	1
29	Side Spray Baffle	1
30	Cross Recessed Pan Head Tapping Screw (ST4.2x15)	13
31	Spray Baffle	1
32	Capacitor	1
33	Capacitor Clamp	1
34	Cross Recessed Countersunk Tapping Head Screw (ST4.2X15)	4
35	Cross Recessed Countersunk Tapping Head Screw (ST2.9x15)	2

PART #	DESCRIPTION	Qty
36	Handle Grip (Lower)	1
37	Cover of Motor	1
38	Wind Guard Board	1
39	Fixing Clip of Cord	1
40	Base	1
41	Nut	1
42	Outer Flange	1
43	Blade	1
44	Inner Flange	1
45	Sealing Pad	1
46	Outer Hexagon Screw (M5 x 15)	2
47	Flat Washer 5	2
48	Water Proof Washer	2
49	Cross Recessed Tapping Screw (ST4.2x30)	4
50	Cross Recessed Pan Head Screw (M4x8)	1
51	Elastic Washer 5	1
52	Lock washers internal Teeth	1
53	Motor	1
54	Power Cord	1
55	Power Cord Storage Rack	1
56	Plate of Switch Protection	1
57	Overload Protector	1
58	Water-Proof Cap of Overload Protector	1
59	Switch Protector	1
60	Switch	1
61	Rubber Washer	4
62	Flat Washer 8	4
63	Inner Hexagonal Bolt M8x18	4
64	Feet	4
65	Bast of Feet	4
66	Anti-Bending Sleeve	1
67	Block of Bench Stop	1
68	Bench Stop	1
69	Fix Cap of Plug	1
70	Plug	1
71	O-Shaped Seal Loop	1